


Wide Bank 28 DS3

USER MANUAL



Fan Faceplate Option (FFO)

Document: 770-0074-AT

Product Release: 2.4

July 2004

Copyright© 2004 Carrier Access Corporation. All rights reserved.

The information presented in this manual is subject to change without notice and does not represent a commitment on the part of Carrier Access Corporation. The hardware and software described herein are furnished under a license or non-disclosure agreement. The hardware, software, and manual may be used or copied only in accordance with the terms of this agreement. It is against the law to reproduce, transmit, transcribe, store in a retrieval system, or translate into any medium - electronic, mechanical, magnetic, optical, chemical, manual, or otherwise - any part of this manual or software supplied with the Wide Bank for any purpose other than the purchaser's personal use without the express written permission of Carrier Access Corporation.

Wide Bank, Network Valet, and the Carrier Access logo are registered trademarks of Carrier Access Corporation. All other brand or product names are trademarks or registration trademarks of their respective companies or organizations.

Contact Information:

Carrier Access Corporation
5395 Pearl Parkway
Boulder, CO 80301-2490
Corporate Phone: (800) 495-5455
Fax: (303) 443-5908
www.carrieraccess.com

Customer Support Direct: (800) 786-9929
E-mail: tech-support@carrieraccess.com

PREFACE

In this Preface

- Compliance ... iv
- Safety Precautions ... vi
- Notices ... vi
- Electrostatic Discharge Guidelines ... vii
- Warranty ... viii

Compliance

FCC Requirements, Part 15

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the Federal Communications Rules. These limits are designed to provide reasonable protection against harmful interference when equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at the user's own expense.

The following cables, when connected to this equipment, must be shielded to maintain FCC Part 15 compliance:

- The Ethernet cable.
- Both Low-Speed (DS1 or E1) cables (LOW-SPEED IN and LOW-SPEED OUT).
- Both RS-232 cables (CLI and TL1).

IMPORTANT NOTE: Unused and unterminated DS1 channels must be turned off to maintain FCC Part 15 compliance. See *Turning Off Unused or Unterminated Low-Speed Channels* on page 6-22.

FCC Requirements, Part 68 Exhibit J1

This equipment complies with Part 68 of the FCC rules. The silkscreen on the top cover of the housing of the Carrier Access Corporation Wide Bank 28 DS3 Multiplexer contains, along with other information, the FCC registration number. You must supply this information to the telephone company, if they request it.

FCC Registration Number: 2Z6USA-32309-XD-N

Service Center in the USA:
Carrier Access Corporation
5395 Pearl Parkway
Boulder, CO 80301-2490

If the Wide Bank 28 DS3 causes harm to the telephone network, the telephone company will notify you in advance. If advance notice proves impractical, the telephone company will notify you as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe such action is necessary.

The telephone company may make changes in its facilities, equipment operations, or procedures that could effect the operation of the Wide Bank 28 DS3. If this occurs, the telephone company will provide advance notice so that you may make necessary modifications to maintain uninterrupted service.

If you need to make repairs or modifications to the Wide Bank 28 DS3, please first contact Carrier Access Corporation for repair and modification information and for warranty information.

If the trouble is causing harm to the telephone network, the telephone company may request that you remove the Wide Bank 28 DS3 from the network until the problem is resolved. User repairs must not be made. Doing so will void your warranty.

To minimize damage caused by local lightning strikes and other electrical surges, it is recommended that the customer install an AC surge arrestor in the AC outlet to which the optional AC to -48VDC Power Converter/Battery Charger is connected.

Safety Requirements for Telecommunications Equipment

The Wide Bank 28 DS3 complies with the following product safety requirements for telecommunications equipment installed in customer premises.

- **National Electrical Code** – overvoltage and power-cross protection on DS1 and E1 lines

For unit cover with CSA logo

- **Canadian Standards Association** – CSA-C22.2 No. 950-95, Standard for Safety for Information Technology Equipment.
- **Underwriters Laboratories** – UL 1950 third edition, Information Technology Equipment



For unit cover with UL logo

- **Underwriters Laboratories** – (Bi-National) Standard for Information Technology Equipment, Including Business Equipment, CAN/CSA 22.2, No. 60950-00 / UL 60950, third edition, dated December 1, 2000.



Industry Canada Requirements

Certification Procedure 01 (CP-01), Issue 8

“**Notice:** This equipment meets telecommunications network protective, operational and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). This is confirmed by marking the equipment with the Industry Canada certification number. The Department does not guarantee the equipment will operate to the user’s satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves but should contact the appropriate electric inspection authority, or electrician, as appropriate.”

Japan Approvals Institute for Telecommunication Equipment (JATE)

In Japan, approvals for connection of telecommunications equipment to the public network are granted by JATE, the Japan Approvals Institute for Telecommunications Equipment. The Wide Bank 28 DS3 JATE file numbers are, CD99-1124JP and L99-1396.

Network Equipment Building System (NEBS) Requirements

The Wide Bank 28 DS3 is certified to meet Network Equipment Building Specifications Level 3 (earthquake Zone 4), Type 2 and 4 requirements for central office/customer-premise products including electrical safety, emissions and immunity requirements for intrabuilding use. This equipment conforms to the Telcordia NEBS standards GR-63 and GR-1089 for intrabuilding only.

Safety Precautions

Refer to the installation chapters of this manual for safe and proper installation procedures.

Notices

This manual contains information and warnings that must be followed to ensure safe conditions for personnel while operating or maintaining the Wide Bank 28 DS3. Safety labels and notes have the following format and definitions:

DANGER! THE ***DANGER!*** SIGN DENOTES A HAZARD TO THE USER AND CALLS ATTENTION TO A PROCEDURE, PRACTICE, OR THE LIKE, WHICH, IF IMPROPERLY PERFORMED, COULD RESULT IN INJURY OR LOSS OF LIFE. DO NOT PROCEED BEYOND A ***DANGER!*** SIGN UNTIL THE NOTED CONDITIONS ARE FULLY UNDERSTOOD AND MET.

CAUTION! THE ***CAUTION!*** SIGN DENOTES THE POSSIBILITY OF NETWORK SERVICE INTERRUPTION AND CALLS ATTENTION TO A PROCEDURE OR PRACTICE, WHICH, IF IMPROPERLY PERFORMED, COULD RESULT IN INTERRUPTION OF NETWORK SERVICE.

WARNING! THE ***WARNING!*** SIGN DENOTES THE POSSIBILITY OF EQUIPMENT DAMAGE AND CALLS ATTENTION TO A PROCEDURE OR PRACTICE, WHICH, IF IMPROPERLY PERFORMED, COULD RESULT IN EQUIPMENT DAMAGE.

NOTE: The NOTE sign precedes explanatory comments or supplementary instructions.

Electrostatic Discharge Guidelines

ESD can damage processors, circuit cards, and other electronic components. Always observe the following precautions before installing a system component.

1. Do not remove a component from its protective packaging until ready to install it.
2. Wear a wrist grounding strap and attach it to a metal part of the system unit before handling components. If a wrist strap is not available, maintain contact with the system unit throughout any procedure requiring ESD protection.
3. For detailed instructions, see *Static-Sensitive Equipment Handling Procedures* on [page 5-3](#).

WARNING! INTEGRATED CIRCUITS (ICs) ARE EXTREMELY SUSCEPTIBLE TO ELECTROSTATIC DISCHARGE. UNLESS YOU ARE A QUALIFIED SERVICE TECHNICIAN WHO USES TOOLS AND TECHNIQUES THAT CONFORM TO ACCEPTED INDUSTRY PRACTICES, DO NOT HANDLE ICs.

The ESD warning label below appears on packages and storage bags that contain static-sensitive products and components. Static electricity is always present, and using general anti-static procedures will minimize the chances of damage to the Wide Bank.



Warranty

Carrier Access Corporation conditionally warrants to BUYER that PRODUCTS are free from substantial defect in material and workmanship under normal use given proper installation and maintenance for the period of five years from the date of shipment by Carrier Access. An exception is the Battery Unit product, which is warranted for 90 days.

BUYER will promptly notify Carrier Access Corporation of any defect in the PRODUCT. Carrier Access Corporation or its agent will have the right to inspect the PRODUCT or workmanship on BUYER'S or BUYER'S customer premises. Carrier Access Corporation has the option to: (a) repair, replace or service at its factory or on the premises the PRODUCT or workmanship found to be defective; or (b) credit BUYER for the PRODUCT in accordance with Carrier Access Corporation's depreciation policy. Refurbished material may be used to repair or replace the PRODUCT. PRODUCTS returned to Carrier Access for repair, replacement, or credit will be shipped prepaid to BUYER.

Limitations of Warranty and Remedies

Correction of defects by repair, replacement, or service will be at Carrier Access's option and constitute fulfillment of all obligations to Distributor for breach of warranty.

Carrier Access assumes no warranty liability with respect to defects in the Product caused by:

- a. modification, repair, installation, operation, or maintenance of the Product by anyone other than Carrier Access or its agent, except as described in Carrier Access's documentation; or
- b. the negligent or other improper use of the Product; or
- c. handling or transportation after title of the Product passes to Distributor.

Other manufacturer's equipment purchased by Carrier Access and resold to Distributor will be limited to that manufacturer's warranty. Carrier Access assumes no warranty liability for other manufacturer's equipment furnished by Distributor.

Distributor understands and agrees as follows: THE WARRANTIES IN THIS AGREEMENT REPLACE ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND ALL OTHER OBLIGATIONS OR LIABILITIES OF CARRIER ACCESS, INCLUDING ANY WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. ALL OTHER WARRANTIES ARE DISCLAIMED AND EXCLUDED BY CARRIER ACCESS.

THE REMEDIES CONTAINED IN THIS AGREEMENT WILL BE THE SOLE AND EXCLUSIVE REMEDIES WHETHER IN CONTRACT, TORT, OR OTHERWISE, AND CARRIER ACCESS WILL NOT BE LIABLE FOR INJURIES OR DAMAGES TO PERSONS OR PROPERTY RESULTING FROM ANY CAUSE WHATSOEVER, WITH THE EXCEPTION OF INJURIES OR DAMAGES CAUSED BY THE GROSS NEGLIGENCE OF CARRIER ACCESS.

THIS LIMITATION APPLIES TO ALL SERVICES, SOFTWARE, AND PRODUCTS DURING AND AFTER THE WARRANTY PERIOD. IN NO EVENT WILL CARRIER ACCESS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OR COMMERCIAL LOSSES EVEN IF CARRIER ACCESS HAS BEEN ADVISED THEREOF.

No agent, Distributor, or representative is authorized to make any warranties on behalf of Carrier Access or to assume for Carrier Access any other liability in connection with any of Carrier Access's Products, software, or services.

Warranty Product Returns

Before returning any equipment to Carrier Access Corporation, first contact the distributor or dealer from which you purchased the product.

A Return Material Authorization (RMA) number is required for all equipment returned to Carrier Access Corporation. Call Carrier Access Customer Support at (800) 786-9929 or (303) 442-5455 for RMA number, repair/warranty information and shipping instructions. Be prepared to provide the following information:

- Carrier Access Corporation serial number(s) from the system chassis or circuit card(s)
- Name of distributor or dealer from which you purchased the product
- Description of defect

TABLE OF CONTENTS

Preface

Compliance	iv
FCC Requirements, Part 15	iv
FCC Requirements, Part 68 Exhibit J1	iv
Safety Requirements for Telecommunications Equipment	v
Industry Canada Requirements	v
Japan Approvals Institute for Telecommunication Equipment (JATE)	vi
Network Equipment Building System (NEBS) Requirements	vi
Safety Precautions	vi
Notices	vi
Electrostatic Discharge Guidelines	vii
Warranty	viii
Limitations of Warranty and Remedies	viii
Warranty Product Returns	ix

1 Introduction

System Overview	1-2
Features, Functions, and Options	1-3
Wide Bank 28 DS3 Features	1-3
DS3 Ports	1-4
DS1 and E1 Ports	1-4
Independent Clocking and Transparent Framing	1-4
Manageability	1-5
Security	1-5
Basic Security	1-5
Security Upgrade Option	1-6
Management Capabilities	1-7
Command Line Interface	1-8
SNMP	1-8
NetworkValet Software	1-9
Transaction Language 1 (TL1)	1-9

2 Product Description

Overview	2-2
Features	2-2
Redundant Architecture	2-4
Physical Characteristics	2-5
Connector Panel Interfaces	2-6

Table of Contents

Framing Modes	2-8
Additional Functions Available in C-Bit Mode	2-8
DS3 Multiframe Structure	2-9
X-Bits - Error Message from Far-End to Near-End	2-10
Application Identification Channel (AIC) Bit	2-10
Reserved Network Application (Na) bit	2-10
Far End Alarm (FEA) Bit	2-11
CP Bits	2-11
P-Bits	2-11
Far-End Block Error (FEBE) Bits	2-11
DLt Bits	2-13
LED Test and Status Indicators.	2-14
Critical and Major/Minor Alarm Definitions.	2-15
Line Code Violations and Bipolar Violations	2-15
Controller and DS3 Redundancy.	2-17
Protection Modes	2-17
Electronics Protection Mode	2-17
Setting the Arm and Revertive Software Switches	2-18
Electronics and Network Protection Mode	2-19
Operator-Initiated Switch.	2-20
Restoring to Original Status (Revertive Switching)	2-20
Revertive Switching with Electronics Protection	2-20
Revertive Switching with Electronics and Network Protection	2-20
Low-Speed (LS) Redundancy.	2-22
Low-Speed Automatic Switchover	2-22
Low-Speed Circuit Groups	2-22
Switchover Lockouts Within Groups.	2-22
Maintenance Service Option (MSO)	2-24
Failures that Cause a Low-Speed Switchover	2-26
Enabling and Disabling Low-Speed Switchovers	2-26
Restoring to Original Status (Revertive Switching)	2-27
Hot-Swapping a Failed Standard Low-Speed Card	2-27
Hot-Swapping a Failed MSO Low-Speed Card.	2-27
MSO Conflicts with Spare Card	2-28
Tests and Loopbacks	2-29
Transmission Path Verification	2-29
Low-Speed Loopback Modes	2-30
Low-Speed Line Loopback	2-30
Low-Speed Equipment Loopback	2-30
Low-Speed Metallic Loopback	2-31
C-bit FEAC Loopback Code Word Detection	2-31
NIU Loopcode Detection.	2-31
Low-Speed Performance Monitoring.	2-32
LS Alarm Signals	2-32

DS3 Loopback Modes	2-32
DS3 Line Loopback	2-32
DS3 Payload Loopback	2-33
DS3 Equipment Loopback	2-33
DS3 Loopcode Detection	2-34
Internal Tests.	2-34
DS3 Alarm and Performance Monitoring.	2-34
DS3 Alarm Signals	2-34
DS3 Errors	2-34

3 Technical Specifications

Specifications	3-2
System Parameters	3-2
DS3 (44.736 Mbps) Interface	3-3
DS1 (1.544 Mbps) Interface	3-4
E1 (2.048 Mbps) Interface	3-4
Cable Compensation.	3-5
Management	3-5
Alarms.	3-5
DS3 Transmit Clock Source.	3-5
Power	3-6
Environmental.	3-6
Physical Dimensions.	3-6
Standards Compliance	3-7
Safety	3-7
Industry	3-7
Installation	3-8

4 Physical Installation

Installation Preparation and Requirements	4-2
Mounting the Wide Bank 28 DS3	4-3
Attaching Mounting Brackets to the Units	4-4
Rack Mounting - Non-FFO Equipped Units.	4-6
Horizontal Mounting in a Standard EIA or WECO Rack	4-6
Vertical Mounting in a Standard EIA or WECO Rack	4-7
Rack Mounting - FFO-Equipped Units	4-9
Fan Faceplate Option	4-9
Rack Mounting (High-Density)	4-10
Mounting the Power Converter/Battery Charger.	4-11
Mounting the Battery Unit.	4-11
Wall-Mounting the Battery Unit.	4-11
Rack Mounting the Power Converter & Battery Unit	4-14

5 **Electrical Installation and Cabling**

Cabling and Compliance Requirements	5-2
Maintaining NEBS 1089 and FCC Part 15 Compliance	5-2
Static-Sensitive Equipment Handling Procedures	5-3
Connector Panel Interface and Power Connectors	5-4
Cable and Wiring Layout	5-5
Ground Connection	5-6
Low-Speed DS1/E1 Cables	5-7
High-Speed DS3 Cables	5-9
External Clock Cable	5-9
Management Cables	5-10
CLI RS-232 Management Cable	5-10
TL1 RS-232 Port Cable	5-11
Ethernet Management Port	5-11
External Alarm Wiring	5-12
Power Wiring	5-13
DC Power Connector Input Requirements	5-13
Wiring the Power Plugs	5-14
Connecting to Power Source	5-15
Applying Power	5-16

6 **Configuration**

Configuration Overview	6-2
Basic Configuration	6-2
Connecting to the Management Port	6-3
Logging On	6-4
Working Configurations	6-4
Saving a Temporary Copy of Configuration	6-5
Restoring a Temporarily Saved Configuration	6-5
Saving the Configuration to a User File System	6-5
Restoring Saved Configuration from User File System	6-5
Restoring Factory Defaults	6-6
Validating Equipment	6-6
Setting the Time and Date	6-7
Set System Time	6-7
Set System Date	6-7
Setting System Security, Users, and Login Passwords (Basic Security)	6-7
Access Levels (Basic Security)	6-8
Password Protection (Basic Security)	6-8
Display Current Security Status (Basic Security)	6-9
Change the Security Status (Basic Security)	6-9
Add a User (Basic Security)	6-9
Assign or Change a User's Password (Basic Security)	6-9
Set a User's Access Level (Basic Security)	6-9
Delete a User (Basic Security)	6-9
Show Current User Settings (Basic Security)	6-9

Setting System Security, Users, and Login Passwords (Security Upgrade Option)	6-10
Access Levels (Security Upgrade Option)	6-11
Password Protection (Security Upgrade Option)	6-11
User Interface Access (Security Upgrade Option)	6-12
Display Current Security Status (Security Upgrade Option)	6-13
Change the Security Status (Security Upgrade Option)	6-13
Add a User and Assign a Password (Security Upgrade Option)	6-13
Change a User's Password (Security Upgrade Option)	6-13
Set a User's Access Level (Security Upgrade Option)	6-13
Delete a User (Security Upgrade Option)	6-13
Show Current User Settings (Security Upgrade Option)	6-14
Set CLI Time-Out (Security Upgrade Option)	6-14
Disable Ethernet Port (Security Upgrade Option)	6-14
Disable 9-Pin RS-232 CLI Port (Security Upgrade Option)	6-14
Disable 25-Pin RS-232 TL1 Port (Security Upgrade Option)	6-14
Disable SNMP Management (Security Upgrade Option)	6-15
Disable TL1 Management (Security Upgrade Option)	6-15
Configuring IP and PPP Addresses	6-15
Verify Network Settings	6-16
IP Routing With Point-to-Point Protocol (PPP)	6-17
IP over PPP Applications	6-17
Configuring DS3	6-17
Configuring Low-Speed Ports	6-19
Saving the Configuration	6-19
Verify All System Parameters	6-20
Verifying Autocopy to Secondary Controller	6-22
Turning Off Unused or Unterminated Low-Speed Channels	6-22
Logging Off	6-22
Downloading New Software	6-23
Configurations for Downloading Firmware	6-23
Management Connections for Downloading Firmware	6-23
Protocol Options for Downloading Firmware	6-24
Downloading to a Redundant Wide Bank 28 DS3	6-26
Downloading to a Non-Redundant Wide Bank 28 DS3	6-32
Xmodem Download Initiated Via RS-232	6-32
TFTP Download Initiated Via RS-232 or Ethernet	6-35

7 *Diagnostics & Troubleshooting*

LED Test and Status Indicators	7-2
Power LED	7-3
Alarm Cutoff (ACO) LED and Pushbutton	7-3
Critical (CR) Alarms	7-4
Major/Minor (MJ/MN) Alarms	7-4
Controller Status (CS) LED	7-5
High Speed (HS) Line Condition LED	7-5
Low-Speed DS1/E1 Line Status LEDs (one per span)	7-6
Ethernet Status LED	7-6

Table of Contents

Determining Performance and Status	7-7
DS3 Far-End Statistics	7-7
DS3 Path Maintenance Data Link	7-7
Functional Description of DS3 Path Maintenance Data Link	7-7
Point-to-Point Protocol Status	7-8
General Troubleshooting	7-9
Thermal Shut-Down	7-10
Self-Tests	7-11
Low-Speed Circuit Self-Test	7-11
The DS1/E1 Test	7-12
Low-Speed Card Self-Test	7-12
DS3 Card Self-Test	7-12
The DS3 Test	7-12
FFO Test and Monitoring	7-13
Complete Self-Test (Power-Up Test)	7-14
The Complete Self-Test	7-14
Looptests Using Built-in PRBS BERT	7-15
Low-Speed CSU Loopup Drop with PRBS BERT	7-15
Low-Speed NIU Loopup Network with PRBS BERT	7-16
DS3 Loopup Network with PRBS BERT	7-17
Testing Low-Speed Interface Operation	7-18
Testing Low-Speed Near-End with Loop Tests	7-19
DS1 Line Loopback	7-20
DS1 Equipment Loopback	7-20
DS1 Metallic Loopback	7-21
DS1 NIU Loopback	7-22
DS1 NIU Loopback Using Two Wide Banks	7-23
DS1 Send CSU Loopback Toward Drop	7-24
DS1 Send NIU Loopup Code Toward Drop	7-25
DS1 Send NIU Loopup Code Toward Network	7-26
Testing the Low-Speed Far-End with Loop Tests	7-27
Activating Far-End Loopbacks in M23 Framing Mode	7-27
Activating Far-End Loopbacks in C-Bit Framing Mode	7-27
Testing the Network to the Far-End Through a Low-Speed Drop	7-28
Running Maintenance Tests on a Low-Speed Circuit	7-29
Testing DS3 Interfaces	7-32
Testing DS3 Framing and Loop Timing	7-32
DS3 Non-Redundant Test Setup	7-32
DS3 Test with M23 Framing	7-33
DS3 Test with C-bit Framing	7-33
DS3 Tests with Line Timing	7-34
Testing the DS3 Near-End with Loopback Tests	7-35
DS3 Equipment Loopback	7-35
DS3 Line Loopback with M23 Framing	7-35
DS3 Line Loopback with C-bit Framing	7-36
DS3 Payload Loopback with M23 Framing	7-36
DS3 Payload Loopback with C-bit Framing	7-36

Testing the DS3 Far-End with Loopback Tests	7-37
Far-End Loop Codes	7-37
Testing DS3 Redundancy	7-39
Testing Electronics Protection	7-39
DS3 Test Setup	7-39
DS3 Manual Switch Test	7-40
DS3 Automatic Protection Test	7-40
DS3 Revertive Switching Test	7-41
Testing Electronics and Network Protection	7-42
DS3 Test Setup	7-42
DS3 Network Protection Test	7-42
DS3 Electronics Protection Test	7-43

8 *CLI Commands and Messages*

Management Overview	8-2
Management Interfaces	8-2
Redundant DS3 Network Interfaces	8-3
Telnet Interface	8-3
Security Levels	8-4
Basic Security	8-4
Security Upgrade Option	8-4
Security Integrity	8-5
SNMP Traps	8-5
Command Line Interface	8-6
Using the Command Line Interface	8-6
Context Sensitive Help	8-7
CLI Command List	8-9
CLI Command Syntax	8-10
CLI Shortcuts (Recall and Edit)	8-10
ACO	8-11
ALARMS	8-11
ALARMS STANDBY	8-11
ALARMOUT	8-13
ARM	8-13
AUTOCOPY	8-14
CLEAR	8-14
CONFIG	8-15
CONTROLLER	8-17
COPY	8-18
DATE	8-18
DAY	8-19
DS1	8-21
DS1 AINS	8-22
DS1 CIRCUITID	8-23
DS1 ENABLE/DISABLE	8-23

Table of Contents

DS1 EQUIPMENT	8-24
DS1 LENGTH	8-25
DS1 LINE	8-25
DS1 LINECODE	8-26
DS1 LOOPDETECT	8-27
DS1 METALLIC	8-27
DS1 MOVE	8-28
DS1 PM THRESHOLD	8-29
DS1 PROTECT	8-30
DS1 SEND	8-30
DS3	8-32
DS3 CIRCUITID	8-33
DS3 CLOCK	8-33
DS3 CLOCKREVERT	8-34
DS3 EQUIPMENT	8-34
DS3 EQUIPMENTID	8-35
DS3 FACILITYID	8-35
DS3 FRAMEID	8-35
DS3 FRAMING	8-36
DS3 GENNUMBER	8-36
DS3 LENGTH	8-37
DS3 LINE	8-37
DS3 LOCATIONID	8-37
DS3 LOOPDETECT	8-38
DS3 PAYLOAD	8-38
DS3 PM THRESHOLD	8-39
DS3 PORTNUMBER	8-41
DS3 PROTECT	8-41
DS3 SEND	8-42
DS3 THRESHOLD	8-42
DS3 UNIT	8-43
EQUIPMENT	8-43
EXIT	8-45
FFO PRESENT	8-45
HELP, ?	8-46
HOUR	8-47
IP	8-48
LOAD	8-49
LOG	8-50
LS	8-50
LS AINS	8-51
LS CIRCUITID	8-53
LS ENABLE/DISABLE	8-53

LS EQUIPMENT	8-54
LS LENGTH	8-55
LS LINE	8-56
LS LINECODE	8-56
LS LOOPDETECT	8-57
LS METALLIC	8-57
LSMODE	8-58
LS MOVE	8-59
LS PM THRESHOLD	8-59
LS PROTECT	8-61
LS SEND	8-61
PING	8-63
PROGRAM FLASH	8-63
RESTORE	8-63
RESULTS	8-66
REVERTIVE	8-67
SAVE	8-68
SCREEN	8-69
SECURITY	8-69
SECURITY CLI	8-70
SECURITY ETHERNET	8-71
SECURITY RS232CLI	8-71
SECURITY RS232TL1	8-72
SECURITY SNMP	8-73
SECURITY TL1	8-73
SNMP	8-74
STATUS	8-75
SWITCH	8-78
TEMP COPY	8-79
TEST	8-79
TIME	8-80
TL1	8-81
USER	8-82
VERSION	8-85

9 TL1 Commands and Messages

TL1 Overview	9-2
General Syntax	9-3
Command Syntax	9-3
Grouping Values as Lists and Ranges	9-4
Response Syntax	9-4
Multiple Output Responses	9-5
Error Responses	9-6
Command Categories	9-7
Security Commands	9-7
Transport Surveillance Commands	9-7
Memory Administration Commands	9-7
Network Maintenance Commands	9-7
Command Modifiers	9-7
FacilityType	9-7
LSType	9-7
AIDType	9-8
Security Levels	9-8
TL1 Shortcuts (Recall and Edit)	9-8
TL1 Setup and Configuration	9-9
Connecting and Configuring for TL1	9-9
Establishing a TL1 Session Via a TCP/IP Socket	9-9
Establishing a TL1 Session Via the RS-232 TL1 Port	9-10
Establishing a TL1 Session Using Terminal-to-Terminal Link	9-10
Setting the Network/Prompt/Source/Target Identifier	9-10
Using CLI to Set the Network Identifier	9-10
Using TL1 to Set the Identifier	9-10
Setting the Initial TL1 Admin Password	9-11
Activating a TL1 User Session	9-11
TL1 Commands and Response Messages	9-11
Activating Users	9-12
Normal Response to Activate User Command	9-12
Error Response for Incorrect Password	9-13
Adding Users	9-13
Deleting Users	9-13
Normal Response to Delete User Command	9-14
Changing User Properties	9-14
Changing User Password	9-14
Retrieving Users	9-14
Retrieving Alarms	9-15
Response if No Alarms are Present	9-15
Response if Alarms are Present	9-15
Retrieve Header Command	9-15
Testing TL1 Alarming	9-16
Canceling the TL1 User Session	9-16
Error Message in Response to Commands Not Recognized or Supported	9-16
Error Response to Valid Commands Received When a User Is Not Logged In	9-16

TL1 Command List	9-17
ACT-USER	9-18
ALW-AUTORST	9-18
ALW-LOG-SECU	9-19
ALW-LPBK-<FacilityType>	9-20
ALW-MSG-<AIDType>	9-20
ALW-PMREPT-<FacilityType>	9-22
ALW-SWTOPROTN-<FacilityType>	9-22
ALW-SWTOWKG-<FacilityType>	9-23
CANC-USER	9-23
CANC-USER-SECU	9-24
CONN-LPBK-<LSType>	9-24
CONN-LPBK-T3	9-25
CPY-MEM	9-25
DGN-<AIDType>	9-26
DISC-LPBK-<FacilityType>	9-27
DLT-<LSType>	9-28
DLT-USER-SECU	9-28
ED-<AIDType>	9-29
ED-DAT	9-31
ED-PID	9-31
ED-USER-SECU	9-32
ENT-<LSType>	9-33
ENT-USER-SECU	9-34
INH-AUTORST	9-35
INH-LOG-SECU	9-35
INH-LPBK-<FacilityType>	9-36
INH-MSG-<AIDType>	9-37
INH-PMREPT-<FacilityType>	9-38
INH-SWTOPROTN-<FacilityType>	9-38
INH-SWTOWKG	9-39
INIT-LOG	9-39
INIT-REG-<FacilityType>	9-40
INIT-SYS	9-41
OPR-ACO-ALL	9-41
OPR-ARC-<LSType>	9-41
OPR-LPBK-<FacilityType>	9-43
RD-MEM-FILE	9-43
RLS-ARC-<LSType>	9-44
RLS-LPBK-<FacilityType>	9-45
RMV-<AIDType>	9-46
RST-<AIDType>	9-46
RTRV-<FacilityType>	9-47

Table of Contents

RTRV-ALM-<AIDType>	9-51
RTRV-ALM-ENV	9-53
RTRV-AO	9-54
RTRV-ARC-<LSType>	9-55
RTRV-ATTR-<AIDType>	9-56
RTRV-COND-<AIDType>	9-59
RTRV-EQPT	9-61
RTRV-HDR	9-62
RTRV-LOG	9-62
RTRV-NETTYPE	9-63
RTRV-PM-<FacilityType>	9-64
RTRV-PMSCHED-<FacilityType>	9-67
RTRV-STATUS	9-70
RTRV-TH-<FacilityType>	9-71
RTRV-TOD	9-72
RTRV-USER-SECU	9-72
SCHED-PMREPT-<FacilityType>	9-74
SET-ATTR-<AIDType>	9-75
SET-ATTR-SECUDFLT	9-77
SET-SID	9-78
SET-TH-<FacilityType>	9-79
STA-LOCL-RST	9-80
SW-TOPROTN-<FacilityType>	9-80
SW-TOWKG-<FacilityType>	9-81
WRT-MEM-FILE	9-82
TL1 Parameter Descriptions	9-83
Access Identifier <aid>	9-84
Error Response: Invalid Access Identifier	9-85
Access Identifier Types <AIDType>	9-85
Error Response: Invalid Access Identifier Type	9-85
Additional Access Identifier Information <aiddet>	9-86
Alarm Code <almcde>	9-86
Alarm Message <almmsg>	9-86
ATAG Segment <atagseg>	9-86
Automatic Message Tag <atag>	9-86
Command Mode <cmdmde>	9-86
Completion Codes	9-87
Condition Description <conddescr>	9-87
Condition Effect <condeff>	9-87
Condition Type <condtype>	9-87
Alarmed Condition Types	9-87
Error Response: Invalid Condition Type	9-88
Correlation Tag <ctag>	9-89
Data Segment <data_seg>	9-89
Date <date>	9-89

Direction of Alarm or Condition <dirn>	9-89
Error Response: Invalid Direction	9-90
DS1/E1 Properties	9-90
Error Message: Invalid T1/E1 Parameter or Value	9-90
DS3 Properties	9-91
Error Message: Invalid T3 Parameter or Value	9-91
Environment Access Identifier (EnvAID)	9-91
Equipment Parameters	9-92
Error Message: Invalid Equipment Parameter Value	9-92
Error Message: Invalid Test Session Number	9-92
Location of Alarm or Condition <locn>	9-92
Error Response: Invalid Location	9-92
Log Identifier <lognm>	9-93
Error Response: Invalid Log Identifier	9-93
Loopback Type <lpbktype>	9-93
Error Response: Invalid Loopback Type	9-93
Memory <frommem> and <tomem>	9-94
Message Type <msgtype>	9-94
Monitor Date <mondat>	9-94
Monitor Level <monlev>	9-94
Monitor Time <montm>	9-94
Monitored Parameter Type <montype>	9-95
Error Response: Invalid Monitored Parameter Type	9-95
Notification Code <ntfncode>	9-96
Error Response: Invalid Notification Code	9-96
Number of Reports <numrept>	9-96
Occurrence Date <ocrdat>	9-96
Occurrence Time <ocrtm>	9-96
Phase <ph>	9-96
Private Identifier <pid>	9-97
Reporting Interval <reptinvl>	9-97
Reporting Start Time <reptstatm>	9-97
Restoration Function Codes	9-97
Security Alarm Type <secualmtype>	9-97
Service Effect of Alarm or Condition <srveff>	9-98
Error Response: Invalid Service	9-98
Target Identifier <tid> and Source Identifier <sid>	9-98
Threshold Level <thlev>	9-98
Time <time>	9-99
Time Offset <tmofst>	9-99
Time Period <tmper>	9-99
Error Response: Invalid Time Period	9-99
Type or Request <typereq>	9-99
User Access Privilege <uap>	9-99
Error Response: Illegal User Access Privilege	9-100
Error Response: Insufficient Privilege to Execute Command	9-100
User Identifier <uid>	9-100

TL1 Automatic Messages	9-101
Report Alarm Message Format	9-101
Report Alarm Clear Message Format	9-103
Report Event Message Format	9-104
Report Performance Monitoring Message Format	9-105
Cancel User Session Event Message Format	9-106
DS3 Far-End Alarms	9-106
Message Summary Table	9-106

10 Maintenance

Card Maintenance	10-2
Card Locations	10-2
Removing and Installing Faceplates	10-3
Standard Faceplates	10-3
Fan Faceplates	10-3
Replacing Low-Speed Cards	10-5
Maintenance Practices for Low-Speed Cards	10-5
Standard Low-Speed Card Maintenance Practice	10-5
MSO Low-Speed Maintenance Practice	10-5
Replacing a Standard Low-Speed Card	10-6
Replacing an MSO Low-Speed Card	10-7
Removing the Electronics Section of an MSO Card	10-8
Inserting the Electronics Section of an MSO Card	10-9
Replacing DS3 Controller Cards	10-10
Turning Off Unused or Unterminated Low-Speed Channels	10-11

11 SNMP

Configuration for SNMP	11-2
Basic Configuration Parameters	11-2
Wide Bank IP Address	11-2
Subnet Mask	11-2
Default Gateway	11-2
Network Management Station (NMS) IP Address	11-2
System Name	11-2
Location	11-3
Contact	11-3
Basic Configuration from the CLI	11-3
Validate Link	11-4
Carrier Access DS3 Multiplexer Enterprise MIBs	11-5
SNMP Traps Supported by Wide Bank 28 DS3	11-6
Interface Index (ifIndex) Numbers	11-6
Standard Traps	11-6
Authentication Failure Trap	11-6
Warm Start Trap	11-7
Link Down Trap	11-7
Link Up Trap	11-7

Enterprise Traps	11-8
DS3 Controller State Trap	11-8
DS1 Card State Trap	11-8
Failed CLI Login Trap	11-8
Power Status Trap	11-8
DS1 Protect Switch Trap	11-8
DS1 Move Home Trap	11-8
DS1 Internal Hardware Failure Trap	11-9
DS1 Internal Hardware Failure Clear Trap	11-9
DS1 Internal Hardware Failure Spare Trap	11-9
DS1 Internal Hardware Failure Spare Clear Trap	11-9

12 Alarm Reporting

Overview	12-2
Critical, Major and Minor Alarms	12-2
LEDs That Report Alarms	12-3
DS3 Far-End Alarms and Control (FEAC)	12-4
Far-End Alarm Transmission	12-4
Far-End Alarm Reporting	12-4
TL1 Alarm Reporting	12-4
TL1 Automatic Messages	12-4

A Connector Pinouts

DC Power Connectors	A-2
Alarm Contacts	A-3
Low-Speed DS1/E1 (DSX-1) Connector Pinouts	A-4
Low-Speed Connector Pinout Chart	A-4
CLI RS-232 Management Port Pinout	A-7
Male DB9 Connector	A-7
Female DB9 Connector	A-7
TL1 RS-232 Management Port Pinout	A-8
Male DB25 Connector	A-8
Female DB25 Connector	A-8
Ethernet RJ-45 (10Base-T) Pinout	A-9
RJ-45 Connector	A-9

Glossary

Index

Table of Contents


CHAPTER 1

Introduction

In this Chapter

- System Overview ... 1-2
- Features, Functions, and Options ... 1-3
 - Wide Bank 28 DS3 Features ... 1-3
 - DS3 Ports ... 1-4
 - DS1 and E1 Ports ... 1-4
 - Independent Clocking and Transparent Framing ... 1-4
 - Manageability ... 1-5
 - Security ... 1-5
- Management Capabilities ... 1-7
 - Command Line Interface ... 1-8
 - SNMP ... 1-8
 - Valet and NetworkValet Software ... 1-9
 - Transaction Language 1 (TL1) ... 1-9

System Overview



Fan Faceplate Option (FFO)

Carrier Access' Wide Bank 28 DS3 Multiplexer provides a standards-based M1-3 multiplexing function. This product converts a framed Digital Signal Level 3 (DS3) network connection to 28 Digital Signal Level 1 (DS1) connections to T1 facilities, or 21 connections to E1 facilities.

The Wide Bank's modular design provides up to seven active quad DS1 (QDSX) cards or seven active three-channel E1 cards, and one spare circuit card (DS1 or E1), connecting from 4 to 28 DS1 (3 to 21 E1) circuits, as needed. The spare circuit card provides software-controlled redundancy of low-speed interfaces on a 1 to 7 basis. The DS3 Controller Card provides all common electronic functions of power conversion, processing and management, and a single DS3 interface. An optional spare DS3 Controller card in the Wide Bank provides redundancy and protection for both electronic common equipment and a second, redundant, DS3 network connection.

The Wide Bank does not re-frame or re-clock the connected low-speed inputs. It allows T1 or E1 framing to be provided independently by the connected communications equipment at both the near-end and the far-end of the DS3 line. Each T1 or E1 is also independently clocked within the M1-3 formatted DS3 composite. Because of independent clocking and framing capabilities for each of the T1 or E1 connections, the Wide Bank can provide asynchronous T1 or E1 to DS3 multiplexing functions.

The Wide Bank is designed for compact size (one rack unit) and convenient mounting either in standard 19-inch and 23-inch racks or on a wall. It is designed to provide total circuit redundancy and easy maintenance. Integrated self-tests and line tests provide advanced fault isolation. SNMP, command line interfaces, and TL1 connection allow remote management. The Wide Bank is also designed for quick and easy installation. An optional AC to -48VDC power converter and battery backup unit provide protected power. Cabling to the Wide Bank uses connectors to save installation labor.

Features, Functions, and Options

Wide Bank 28 DS3 Features

The Wide Bank 28 DS3 provides:

- Up to 28 DS1 ports with four optional, redundant DS1 circuits
- Up to 21 E1 ports with three optional, redundant E1 circuits
- Up to 2 DS3 ports with network and common electronics redundancy
- Bellcore and ANSI Standards compliance, including Network Equipment Building System (NEBS) standards
- UL 1950 Safety approval and fuseless protection
- There are 3 ports for system management and surveillance: one 9-pin RS-232 port for delivering Command Line Interface (CLI), one 10Base-T Ethernet port for SNMP, Telnet, and TL1, and one 25-pin RS-232 port for TL1 management and Automatic Outbound Alarm Reporting
- Low-speed (DS1 or E1) Network Interface Unit (NIU) loop-up response, loop-down response, and DSX-1 line buildout for DS1 (no line buildout for E1)
- Control Panel LED Test & Status Indicators
- Internal DS3 and low-speed Bit Error Rate Tester (BERT) with industry standard Pseudo-Random Bit Sequence (PRBS) patterns
- Internal self-tests with BERT verification of transmission data paths
- DS3 C-bit application for Far-End terminal alarming, status reporting, and remote loopback initiation
- DS3 C-bit application terminal-to-terminal data link for identification message support and management of the remote terminal using Telnet, SNMP, or TL1 over PPP

DS3 Ports

There are four DS3 connections, two transmit and two receive (75 ohm unbalanced BNC) in the redundant configuration, that make up two DS3 ports. These ports connect to two DS3 interfaces, called Primary and Secondary (the secondary DS3 interface is optional). Each Controller card, also called primary and secondary (the secondary Controller card is optional), has a single DS3 interface.

DS1 and E1 Ports

The Wide Bank's low-speed ports are accessible through two 64-pin connectors. You can use two of Carrier Access' low speed cables to connect 28 DS1s or 21 E1s from standard low-speed patch panels to the Wide Bank 28 DS3.

Any digital equipment may be terminated on both ends at a standard level crossconnect. The crossconnect provides a convenient central facility for circuit rearrangements, patching, and testing.

The Wide Bank's DS1 interfaces provide crossconnects at Digital Signal Crossconnect Level 1 (DSX-1) per ANSI T1.102. The E1 interfaces meet the crossconnect requirements of ITU-T/G.703.

Independent Clocking and Transparent Framing

Because of independent timing and transparent framing, the installation and maintenance of the DS1 or E1 connections are easily managed. Because the Wide Bank 28 DS3 transmits DS1 or E1 streams transparently into a DS3 composite, there are no framing or timing options to set on the 28 DS1 or 21 E1 connections. The Wide Bank transparently passes the framing and clocking as applications change. DS1 line coding, optioned as either AMI or B8ZS, is the only Wide Bank 28 DS3 T1 configuration normally needed to access DS3 carrier services. E1 line coding is fixed as HDB3 and need not be configured to access DS3 carrier services.

By using M1-3 multiplexers, independently clocked DS1 and E1 carrier service connections can be carried in the same DS3 line. Each Wide Bank connection derives clocking from either end of the DS1 or E1 connection, as appropriate for the network requirements.

The Wide Bank 28 DS3 transmits all possible DS1 and E1 framing formats transparently on each of the low-speed connections. Framing transparency allows the customer and end-carriers to frame (or not frame) each of the low-speed connections appropriately for the voice or data application desired. Mixed carrier services can share the same DS3 access line.

DS1 end-to-end transparency for Extended Superframe (ESF) also provides important management capabilities from the end-carriers to the customer. The Wide Bank allows complete ESF communications to each end of the DS1 connection.

Manageability

Carrier Access' Wide Bank 28 DS3 Multiplexer provides configuration management and testing and surveillance using any of the following:

- Command Line Interface (CLI) through a 9-pin RS-232 CLI port
- Command Line Interface using a Telnet session over a 10Base-T connection
- Embedded SNMP agent over a 10Base-T Ethernet connection
- NetworkValet[®] Enhanced Management System provides network and element management over a 10Base-T Ethernet connection
- TL1 management interface over either a 25-pin RS-232 port or a 10Base-T Ethernet connection
- TL1 Automated Outbound Alarming over either a 25-pin RS-232 port or a 10Base-T Ethernet connection

Security

To control access to user interface functions, the Wide Bank 28 DS3 Multiplexer supports a multiple-level user security system. Basic security, which allows users to be assigned access levels and passwords, is supported by all Wide Banks. Enhanced security, available as the “Security Upgrade” option, provides additional security features, including the ability to disable user interfaces.

Basic Security

Basic security allows CLI users to be assigned access levels based on their requirements. The access level determines which commands are available to the user. The basic security user access levels are:

- **admin** – The *admin* user has access to all commands and has the sole authority to grant others access to the system by adding and deleting user names and passwords. There can be only one *admin* user within the system.
- **rw (read/write)** – An *rw* user has access to all commands except those for adding users, deleting users, and setting user levels. The *rw* users are typically responsible for the day-to-day operation of the system.
- **ro (read only)** – An *ro* user is limited to commands that display status and reports. The *ro* access level permits technicians to monitor system operation and performance, but prevents them from altering settings.

NOTE: In previous releases of the Wide Bank, the security access levels were Level 1, Level 2, and Level 3. These levels correspond to *admin*, *rw*, and *ro*, respectively. If you are upgrading firmware in a Wide Bank that supports the numerical access levels, the Level 1 user is automatically converted to *admin*; Level 2 users are converted to *rw*; and Level 3 users are converted to *ro*.

Introduction

Features, Functions, and Options

With basic security, each user can be assigned a password. If security is on and passwords have been assigned, the login process requires both a user name and password. Users can modify their own passwords. If passwords have not been assigned, a user name is required but no password.

When security is off, no password is required, and each user is considered to be at the *admin* level.

Security Upgrade Option

The Wide Bank's Security Upgrade option provides enhanced security features. In addition to the features described for basic security, the Security Upgrade option provides:

- One additional user access level (*secu*, described below)
- Restrictions on the number and types of characters allowed in user names and passwords
- The ability to set a time-out value for CLI sessions
- The ability to individually disable the user interface ports: Ethernet port, 9-pin RS-232 CLI port, and 25-pin RS-232 TL1 port
- The ability to disable SNMP management
- The ability to disable TL1 management

The user access levels available with the Security Upgrade option are:

- ***secu*** – The *secu* user has access to all commands and has the sole authority to grant others access to the system by adding and deleting user names and passwords. The *secu* user also has sole authority to perform such functions as clearing all statistics and logs, configuring IP settings, restoring factory default or previously saved configurations, and configuring the TL1 interface. There can be only one *secu* user within the system.
- ***admin*** – An *admin* user has access to all commands except those assigned exclusively to the *secu* user. Functions available to the *admin* user that are not available to lower-level users include clearing DS1 and DS3 statistics, copying a configuration from the active to standby Controller, setting the system time and date, programming the flash memory, saving a configuration to a TFTP server file, setting various security functions, configuring SNMP, and copying the current configuration to temporary storage.
- ***rw (read/write)*** – An *rw* user has access to all commands except those assigned exclusively to the *secu* and *admin* users. The *rw* users are typically responsible for the day-to-day operation of the system.
- ***ro (read only)*** – An *ro* user is limited to commands that display status and reports. The *ro* access level permits technicians to monitor system operation and performance, but prevents them from altering settings.

NOTE: In previous releases of the Wide Bank, the security access levels were Level 1, Level 2, and Level 3. These levels correspond to *secu*, *rw*, and *ro*, respectively. If you are upgrading firmware in a Wide Bank that supports the numerical access levels, the Level 1 user is automatically converted to *secu*; Level 2 users are converted to *rw*; and Level 3 users are converted to *ro*.


With the Security Upgrade option, passwords are required when security is on. Each user is assigned a password by the *secu* user. Passwords can be modified only by the *secu* user.

When security is off, no password is required, and each user is considered to be at the *secu* level.

Management Capabilities

The Wide Bank 28 DS3 currently provides three management ports for full configuration and monitoring. These ports are:

- One 9-pin RS-232 port for local Command Line Interface (CLI) control
- One 10Base-T Ethernet port for remote SNMP agent, NetworkValet management, Telnet sessions, or TL1 management and Automated Outbound Alarming
- One 25-pin TL1 port for management and Automated Outbound Alarming



Command Line Interface

The command line interface is a simple user interface that controls configuration and maintenance operations. There are two ways to use the command line interface:

- A VT-100 terminal (or a PC running terminal emulation software such as HyperTerminal) connected to the 9-pin (DB9) RS-232 port. The port runs at 9600 baud, 8 data bits, 1 stop bit, no parity, and no flow control.
- A Telnet connection using the 10Base-T Ethernet port. To use Telnet, you must first assign an IP address to the Wide Bank using the RS-232 interface

SNMP

The Wide Bank 28 DS3 contains an embedded SNMP v1 agent that offers the standard MIB II (RFC 1213) in addition to the DS1/E1 MIB (RFC 1406) and the DS3 MIB (RFC 1407).

Also resident are Carrier Access' Wide Bank 28 DS3 enterprise MIBs that provide additional MIB objects.

- DS3 Controller Status
- DS3 identification settings
- DS3 clock settings
- DS3 far-end status
- DS3 line length
- Low-Speed Card Status
- Low-Speed to Low-Speed card association table
- External Power source status
- Traps for CLI Login Failures
- Traps for status changes of DS3 and Low-Speed cards
- Traps for status changes of External Power sources

The network manager can use any SNMP-compatible network management system such as SunConnect's SunNet Manager™, HP OpenView™, or Castle Rock's SNMPc™ to monitor and control the Wide Bank 28 DS3.

You can connect to the SNMP agent through the 10Base-T Ethernet port. Before using the Ethernet port, you must set the IP, mask, gateway, and NMS addresses using the RS-232 command line interface. See Chapter 6 for instructions on how to configure these addresses.

NetworkValet Software

NetworkValet Enhanced Management System provides network and element management with simple graphical user interfaces. The full-featured NetworkValet with alarms and performance monitoring is intended for Network Operations Centers (NOCs).

NetworkValet provides easy management of Carrier Access products including the Wide Bank 28 DS3. It provides the same management functions as CLI, SNMP, and TL1. NetworkValet is a cross-platform Java application that runs on either Microsoft Windows or Solaris based computer systems. Java Runtime Engine (JRE) software for Windows or Solaris is included with the NetworkValet installation program.

NetworkValet sends commands over the carrier's IP network to communicate with the SNMP agent in the Wide Bank 28 DS3. The Wide Bank includes a standard 10Base-T Ethernet port for connection to the hub or network interface, or laptop computer. The Wide Bank 28 DS3 must have FLASH software version 2.00 or higher.

Transaction Language 1 (TL1)

The TL1 Interface provides surveillance and control, provisioning, and testing capabilities between the Wide Bank 28 DS3 and remote operating systems.

- Surveillance includes real-time alarm reports, event reports, threshold crossing alerts, logs, and performance statistics. Control functions include automatic and forced switching of both the low-speed and high-speed circuits.
- Provisioning includes most of the same configuration functions available through the CLI
- Testing includes the ability to initiate, terminate, and get results from all available loop tests

In addition, TL1 provides TL1 Automatic Outbound Alarm Reporting. Automatic outbound alarm messaging is a standards-based ASCII management language defined for TL1-based operations and support systems such as the Telcordia NMA™ network monitoring and analysis system. With this feature, the Wide Bank 28 DS3 will integrate into TL1 alarm-managed networks to provide notification of network and equipment conditions. TL1 is configured using the standard Wide Bank Command Line Interface (CLI). The Wide Bank supports three simultaneous TL1 sessions via the TCP/IP Ethernet port, one session via the RS-232/TL1 port, and one session via Telnet using the CLI "tl1" command.

CHAPTER 2

Product Description

In this Chapter

- Overview ... 2-2
- Physical Characteristics ... 2-5
- Connector Panel Interfaces ... 2-6
- Framing Modes ... 2-8
- LED Test and Status Indicators ... 2-14
- Controller and DS3 Redundancy ... 2-17
- Low-Speed (LS) Redundancy ... 2-22
- Tests and Loopbacks ... 2-29

Overview

- Features ... 2-2
- Redundant Architecture ... 2-4

The Wide Bank 28 DS3 Multiplexer is available in increments up to the maximum of seven four-channel DS1 cards supporting 28 DS1 connections, or with seven three-channel E1 cards supporting 21 E1 connections. Built-in options include 1:7 low-speed electronic redundancy, 1:1 Controller electronics redundancy and electronics redundancy with 1+1 network protection. The unit features solid-state fuseless protection, low power consumption, hot card swapping, DS3 and low-speed (DS1 or E1) loopbacks for fault isolation, built-in PRBS Bit Error Rate Testing (BERT), and integrated Network Interface Unit (NIU) functionality. Configuration and maintenance testing is provided by a command-line interface or an SNMP interface.

The Wide Bank 28 DS3 Multiplexer supplies clear-channel DS1/E1 transport, is transparent to DS1/E1 framing, and provides basic DS1/E1 performance monitoring.

Features

- Single Standard Rack Unit (1 RU) size
WxDxH: 17 x 10 x 1.75 inches (43.2 x 25.4 x 4.45 cm)
- 75 ohm unbalanced BNC DS3 input standard
- Dual independent –48 VDC power feeds with optional AC to DC power converter/battery charger and eight-hour battery backup system
- High-level integration reduces power consumption to less than 36W for a fully-redundant configuration with fan faceplate
- Solid-state, fuseless, overvoltage/overcurrent protection with automatic reset and alarmed overcurrent protectors
- Optional DS3 redundancy for either:
 - Protected electronics (1:1), or
 - Protected electronics and “hitless” network protection (1+1). Requires second independent DS3 input.
- 1:7 by 4 DS1 electronic redundancy, or 1:7 by 3 E1 redundancy
- Built-in automatic self-tests for all internal circuitry and transmission data paths to determine network vs. electronic faults
- Integrated Network Interface Unit (NIU) functionality provides DS3 loopbacks with AIS toward the low-speed CPE
- IP routing with Point-to-Point Protocol over a C-bit data link for management of remote unit
- DS3 C-bit path maintenance data link

- DS3 C-bit far-end alarm, statistics, and control
- Ability to use TFTP to upload and download a configuration file to a file system on an IP host (This function provides the ability to easily load multiple Wide Banks with the same configuration).
- Remote and local low-speed loopbacks with built-in *PRBS* for fault isolation on all active and standby low-speed interfaces
- Remote and local DS3 loopbacks with built-in *PRBS* test pattern generation for fault isolation
- Transparent framing for DS1 or E1 channels
- Individual DS1 support for AMI or B8ZS line coding
- Individual E1 support for HDB3 line coding
- Individual DS1 transmit line buildout (LBO) adjustments to 655 feet
- DS3 line buildout (LBO) adjustments to 450 feet
- DS1 transmit jitter attenuation and receive jitter tolerance
- External critical and major/minor alarm relay contacts
- DS3 clock source from DS3 network, internal Stratum 4E, or external coax input
- Maintenance Service Option (MSO) that maintains T1 or E1 service on the spare low-speed card while swapping failed electronics
- Fan Faceplate Option (FFO), with dual independent fan design, allows direct metal-to-metal stacking of Wide Banks in high-density applications where passive cooling is not sufficient. (Direct stacking of Wide Bank products with other unapproved equipment is not recommended and could lead to excessive heat buildup.)
- Automatic monitoring for fan presence and fan failure, fault-tolerant fan redundancy, and in-service hot swapping of FFO assembly in less than 30 seconds eliminates traditional fan maintenance concerns

Redundant Architecture

The Wide Bank 28 DS3 multiplexer uses two DS3 processors, which handle the DS3 interfaces, and a backplane bus that accesses the low-speed interfaces. It also contains up to seven active low-speed circuit boards and one optional spare circuit board that connect to the low-speed interfaces.






Figure 2-1 Functional Block Diagram

Physical Characteristics



Connector Panel Interfaces

The connector panel on the rear of the chassis housing contains the following connectors and power connection terminals.



- **Low-Speed Connectors.** Together these two 64-pin Champ type connectors support 28 DS3 or 21 E1 ports. One is designated as LOW SPEED IN, and the other is designated as LOW SPEED OUT. The cable connecting to these ports (the same cable is used on both ports) has a male 64-pin Amphenol® connector on both ends for connections between the patch panel or other equipment, and the Wide Bank 28 DS3. (Cables are available in 10-foot and 25-foot lengths.)
- **DS3 Connectors.** There are four DS3 connections: Primary (Active) in and out, and Secondary (Protection) in and out, which make up two DS3 ports. Each Controller card has a single DS3 interface, so the Wide Bank 28 DS3 must have two Controller cards installed to have two DS3 ports available.
- **Ethernet Connector.** The Ethernet interface (RJ-45) provides management access to the Wide Bank 28 DS3. The LED associated with the Ethernet port provides a carrier-detect indicator for the 10Base-T connection when green.
- **RS-232 Monitor Connector.** This is an RS-232 port (DB-9 female) that can connect to a VT-100 terminal or a PC with terminal emulation software to manage the active Controller card via the Command Line Interface (CLI).
- **RS-232 TL1 Connector.** This is an RS-232 port (DB-25 female) for Automated Outbound Alarming and Wide Bank management from a remote operating system.

- **External Clock Connector.** An external DS3 clock connector (75-ohm unbalanced BNC) is provided for clocking the unit from an external 44.736 MHz timing source, when required.
- **Alarm Connector.** The alarm contacts are on a 4-position wiring block connector. There are contacts for a critical alarm and for a combined major/minor alarm. The contacts can be programmed to be normally open or normally closed. One cable connector, which can be wired to externally-powered alarm monitor or indicator, is provided with each Wide Bank 28 DS3. For wiring information, see *External Alarm Wiring on page 5-12*.
- **Power Connectors.** Power connections are made to the –48 VDC power connector input with a three-position removable wiring connector. An 8-foot DC power cord is provided with each Carrier Access Corporation 120 VAC to –48 VDC Power Converter/Battery Charger. There are two independent power receptacles on the rear of the Wide Bank, labeled A and B. Power connector A supplies –48 VDC to the power supply on Controller card A, and power connector B supplies –48 VDC to the power supply on Controller card B. For wiring information, see *Wiring the Power Plugs on page 5-14*.

The Controller cards are designed to provide power to each other if a power failure occurs. If only power connector A has a power source plugged into it, the power converter for Controller card A will supply power to the entire system including Controller card B. However, if Controller card A is removed, Controller card B will no longer receive power. The same is true (in reverse) if only power connector B has a power source.

WARNING! FOR REDUNDANT OPERATION BOTH CONTROLLER CARDS MUST RECEIVE POWER AND BOTH POWER CONNECTORS MUST HAVE A POWER SOURCE PLUGGED INTO THEM. IT IS RECOMMENDED, AND IS STANDARD PRACTICE, THAT THE TWO –48V POWER SOURCES BE INDEPENDENT TO MAINTAIN PROPER REDUNDANCY AND PROTECTION.

Framing Modes

- Additional Functions Available in C-Bit Mode ... 2-8
- DS3 Multiframe Structure ... 2-9

The Wide Bank 28 DS3 can be configured for either M23 or C-bit framing. The major difference between M23 framing and C-bit parity framing is that M23 framing uses the C-bits to indicate stuffing, while C-bit parity framing does not.

With M23 framing, all three C-bits in a subframe are set to one (1) if stuffing occurs, or to zero (0) if stuffing does not occur.

C-bit parity framing does not require stuffing indication (stuffing is always present), so the C-bits are used for other applications. These other applications and how the C-bits are used to accomplish them are described in the following text and figures.

Additional Functions Available in C-Bit Mode

When configured for C-bit framing, the Wide Bank 28 DS3 provides the following functions, which are not available in M23 framing:

- Control of C-bit loopbacks for low-speed and DS3 using the loopup and loopdown commands
- The third C-bit in M-subframe 1 provides a far-end alarm and control signal. This signal is used to send alarm or status information from the far-end to the near-end and to initiate low-speed and DS3 loopbacks at the far-end terminal from the near-end terminal. See *Testing the DS3 Far-End with Loopback Tests* on [page 7-37](#).
- Automatic receipt of far-end alarms
- The alarms are sent automatically and result in a minor alarm indication on the Wide Bank 28 DS3. See *DS3 Far-End Alarms and Control (FEAC)* on [page 12-4](#).
- Controlled receipt of far-end statistics and status
- Separate commands for statistics and status must be issued from the Wide Bank to cause the network to send the information. See *DS3 Far-End Statistics* on [page 7-7](#).
- Point-to-Point Protocol (PPP) IP communication over C-bit link
- This provides an IP connection over the C-bit data link instead of the Ethernet port, and provides management access equal to the Ethernet port. See *Management Interfaces* on [page 8-2](#).
- Controlled receipt of PPP link status
- A command issued from the Wide Bank causes the network to send the information. See *Point-to-Point Protocol Status* on [page 7-8](#).
- A terminal-to-terminal Path Maintenance Data Link

- The Path Maintenance Data Link is a 28.2 Kbps terminal-to-terminal data link embedded in the C-bits. See *DS3 Path Maintenance Data Link* on [page 7-7](#).
- The ability to send a DS3 idle code to the network
- The DS3 idle code means that the DS3 is not carrying traffic

DS3 Multiframe Structure

The DS3 signal is partitioned into multiframes (M-frames) of 4760 bits each. The M-frames are divided into seven M-subframes, each having 680 bits. Each M-subframe is further divided into eight blocks of 85 bits, 84 of which are payload and one bit for frame overhead.

The structure of the DS3 multiframe is the same for both M23 and C-bit framing. As stated above, the C-bits are used for different purposes.

Figure 2-2 shows how the frame is structured with the C-bits highlighted. Figures 2-5 through 2-8 provide details about the individual subframes.




Figure 2-2 Multiframe Structure

X-Bits - Error Message from Far-End to Near-End

The X-bits, located in the first bit position of both M-subframe 1 and M-subframe 2 (see Figure 2-2), are both set to zero (0) if a Loss-of Signal (LOS), Out-of-Frame (OOF), or Alarm Indication Signal (AIS) is detected at the far-end during any one-second interval. This signal is transmitted to the near-end for one second, then the X-bits return to their normal condition (both ones). X-bit states of 01 or 10 are abnormal and are ignored by the near-end.

Application Identification Channel (AIC) Bit

The first C-bit in M-subframe 1, the AIC bit, indicates whether the far-end equipment is set for C-bit parity framing (1), or M23 framing (random 1s and 0s). See Figure 2-3.

Reserved Network Application (Na) bit

This bit is always a one (1). See Figure 2-3.




Figure 2-3 Subframe 1 C-bits

Far End Alarm (FEA) Bit

The FEA bit is used for two purposes: (1) as a far-end channel to send alarm and status information from the far-end to the near-end, and (2) to initiate from the near-end, DS3 and low-speed loopbacks at the far end terminal. A 16-bit code is transmitted serially over this one-bit channel, least-significant (right-end) bit first, to indicate one of eleven conditions. The format of the 16-bit code is: 0XXXXXX0 11111111 (where X can be a 1 or a 0).

Table 2-1 FEA Bit Far-End Alarm and Status Channel Codes

	Alarm or Status Condition	16-Bit Code
1	DS3 equipment failure (service-affecting)	00110010 11111111
2	DS3 LOS	00011100 11111111
3	DS3 out-of-frame	00000000 11111111
4	DS3 AIS received	00101100 11111111
5	DS3 IDLE received	00110100 11111111
6	DS3 equipment failure (not service-affecting)	00011110 11111111
7	Common equipment failure (not service-affecting)	00111010 11111111
8	Multiple LS LOS	00101010 11111111
9	LS equipment failure (service-affecting)	00001010 11111111
10	Single LS LOS	00111100 11111111
11	LS equipment failure (not service-affecting)	00000110 11111111

CP Bits

The three C-bits of Subframe 3, called the CP bits, are used to transport DS3 parity information. At the DS3 transmit location, they are set to the same value as the P-bits of Subframes 3 and 4. See Figure 2-4 and Figure 2-5.

P-Bits

The first bit of both Subframes 3 and 4 are called P-bits. They are used as parity indication bits for information bits, and are monitored for indications of DS3 signal errors. See Figure 2-4 and Figure 2-5.

Far-End Block Error (FEBE) Bits

If an incoming path error (framing error or parity error) is detected at the receiving side, the three FEBE bits are set to any combination of 1s and 0s except 111, and sent to the far-end terminal. A setting of 111 means there are no framing or parity errors. See Figure 2-5.

Product Description

Framing Modes




Figure 2-4 Subframe 3 C-bits




Figure 2-5 Subframe 4 C-bits

DL_t Bits

The three C-bits in Subframe 5, called the DL_t bits, are assigned as a 28.2-Kbit/s terminal-to-terminal path maintenance data link. This link uses a link access procedure on the D-channel (LAPD) to transmit the DS3 path identification number, DS3 idle signal identification, and DS3 test signal identification. See Figure 2-6.





Figure 2-6 Subframe 5 C-bits

LED Test and Status Indicators



CS - CTRL STAT (DS3 CONTROLLER STATUS)	
LED State	Meaning
OFF	Standby
GREEN	Normal (Active) Operation
RED	Alarm Condition
RED Flashing	Self-Test Fail
YELLOW	Network Loopback

CR - CRITICAL ALARM	
LED State	Meaning
OFF	No Alarms
RED	Traffic-Affecting Fault

MJ/MN - MAJOR/MINOR ALARM	
LED State	Meaning
OFF	No Alarms
YELLOW	Minor Alarm
RED	Major Alarm

POWER	
LED State	Meaning
OFF	-48V Input Power Is High, Low or Missing, or -48V Internal Power Failed
GREEN	Normal Operation
RED	5V Onboard Power Supply Failed

ACO - ALARM CUTOFF	
LED State	Meaning
OFF	Alarms Active
YELLOW	Alarms Suppressed

HS - HIGH SPEED LINE CONDITION (DS3 CONDITION)	
LED State	Meaning
GREEN	Normal Operation
RED	Loss of Signal
RED Flashing	LOF or AIS Received
YELLOW	Remote Alarm Detection
YELLOW Flashing	Line Code Violation, Frame Bit Error, or Parity Error

LS - LOW SPEED STATUS (DS1, E1 & SPARE CIRCUITS)	
LED State	Meaning
OFF	Off Line
GREEN	Normal Operation
RED	Loss of Signal or Metallic Loopback
RED Flashing	Self-Test Fail
YELLOW	Line or Equipment Loopback
YELLOW Flashing	Line Code Violation

ETHERNET STATUS (On Rear Panel)	
LED State	Meaning
OFF	No Power or No Link
GREEN	Link OK

Figure 2-7 Wide Bank Test and Status Indicators

Critical and Major/Minor Alarm Definitions

Table 2-2 lists the events that cause critical and major/minor alarms. Any one of the critical alarm events cause the Critical Alarm LED to light red, activate the critical alarm relay contacts, and record appropriate log entries. Any one of the major/minor alarm events cause the Major/Minor Alarm LED to light red (major) or yellow (minor), activate the major/minor alarm relay contacts, and record appropriate log entries. When the alarm event no longer exists, the LED and the relay contacts revert to the non-active state but the log entries remain.

Line Code Violations and Bipolar Violations

Line Code Violations (LCV) are used to determine alarm events that are typically a result of deteriorating transmission line integrity. The calculation of LCVs, and Bit Error Rate (BER) in the Wide Bank 28 DS3 is as follows:

BPV (Bipolar Violations). The occurrence of a pulse of the same polarity that is not part of a zero suppression signature.

EXZ (Excessive Zeros). A string of more than 3 consecutive zeros for E1 and DS3 data, or 7 consecutive zeros for DS1 B8ZS, or 15 consecutive zeros for DS1 AMI

LCV. Total number of BPVs and EXZs.

BER. Number of LCVs in time window divided by number of bits in time window.

LCVs are also used to determine when a DS3 switching event takes place (DS3 threshold). See *DS3 THRESHOLD* on page 8-42.

NOTE: When DS3 protect is turned on and there is a bit error rate (BER) exceeding 1×10^{-3} , the active Controller executes a protection switch to the standby Controller regardless of the DS3 threshold setting.

Table 2-2 lists all possible alarm events. All alarms are recorded in the event log, which can be accessed through the command line interface.

Product Description

LED Test and Status Indicators

Table 2-2 Alarm Events

Critical Alarm Conditions	Major/Minor Alarm Conditions	Status Only (Logged event only)
DS3 Receive AIS	-48V Input Missing or Failed	DS3 Controller Switch occurred
DS3 Loss of Signal	Controller Card Removed	DS1 (E1) Switch occurred
DS3 Loss of Frame	DS1 (E1) Card Removed	
DS3 Receive RAI	DS1 (E1) Hardware Failure	
	DS1 (E1) LOS	
	DS1 (E1) Major LCV	
	DS1 (E1) MSO Electronics Card Removed	
	DS1 (E1) Self-Test failure	
	DS1 (E1) Spare Card Conflict	
	DS1 (E1) Transmit Failure	
	DS3 Far-End alarm	
	DS3 Major LCV Errors > 10 ⁻⁴ (if threshold not set)	
	Fan Faceplate Not Installed (maj) (FFO only)	
	Fan Failure A or B fan (maj) (FFO only)	
	Far-End multiple DS1 (E1) LOS	
	Far-End single DS1 (E1) LOS	
	On Board Power Supply failure	
	Standby Card Failure	
	Temperature too High	

NOTE: These alarms are defined for the control panel LEDs, connector panel Alarm connections, and for the Command Line Interface. AIS, RAI, DS3 Far-End alarm, Far-End single DS1 (E1) LOS, and Far-End multiple DS1 (E1) LOS are reported as events via TL1. DS3 Major LCV Errors are not reported via TL1.

Controller and DS3 Redundancy

- Protection Modes ... 2-17
- Electronics Protection Mode ... 2-17
- Electronics and Network Protection Mode ... 2-19
- Operator-Initiated Switch ... 2-20
- Restoring to Original Status (Revertive Switching) ... 2-20

Protection Modes

The Wide Bank can be provisioned with one or two Controller cards and connections to one or two DS3 lines to provide the following levels of protection:

- Electronics Protection – When provisioned with two Controller cards and only one DS3 line, only the Controller cards can be protected.
- Electronics and Network Protection – When provisioned with two Controller cards and two independent DS3 lines, both the Controller cards and the DS3 lines can be protected.

Electronics Protection Mode

In this mode there are two Controllers available to the Wide Bank but only one DS3 line.

The electronics mode of protection provides Controller card redundancy. Because there is only one DS3 connected, there is no DS3 redundancy. The receive path from the DS3 line is simultaneously applied to the receiver of both Controller cards (see Figure 2-8). This enables both Controllers to monitor the condition of the DS3 line so both are continuously framed up to the incoming signal. The controller-select signal disables the outputs of the low-speed receive paths on the standby Controller and enables the low-speed receive paths on the active Controller. The active Controller's transmit signal is connected to the transmit path of the DS3 line through a relay, while the standby is disconnected until a protection switch occurs.

The automatic redundancy mode is used to enable and disable protection switching. If arm is enabled (*arm on*), and the redundancy control process determines the active Controller is malfunctioning, or a maintenance switch is invoked (the switch command), a protection switch will occur. This means that the active Controller relinquishes control to the secondary Controller. This is done by enabling the standby Controller's receive path and disabling the originally active Controller's low-speed receive path (controller-select signal) and switching the output paths so that the transmit path of the DS3 line is connected to the standby Controller. Service interruptions (hits) will be taken on both the DS3 and low-speed connections during this type of switch. However, because the standby Controller is already framed up to the incoming signal, the hits are minimal.

Product Description

Controller and DS3 Redundancy




Figure 2-8 Electronics Protection Mode of the Wide Bank 28 DS3

If revertive switching is enabled (*revertive ds3 on*), after a five minute delay the Wide Bank will rearm the automatic protection switching. No automatic switchback will occur (as with Network Protection) but if the currently active Controller malfunctions, another protection switch will occur. If revertive switching is not enabled (*revertive ds3 off*), no protection switch-back will occur.

NOTE: Revertive switching (*revertive ds3 on*) has different effects for Electronic Protection and Electronic and Network Protection. Please read both descriptions to determine the differences.

Setting the Arm and Revertive Software Switches

Arm and **revertive** are interactive. They interact as follows:

- Arm and revertive can both be on (factory default)
- Turning revertive on also turns arm on
- Arm can be on when revertive is off
- If both arm and revertive are on, you cannot turn arm off (*arm off* command) without first turning revertive off (*revertive ds3 off* command)
- If both arm and revertive are off, an *arm on* command only turns on arm
- If both arm and revertive are off, a *revertive ds3 on* command turns on both arm and revertive

Electronics and Network Protection Mode

The highest level of protection, electronics and network protection, allows both the Controller cards and the DS3 lines to be switched. This mode is available with two Controllers and two active DS3 lines. Switching must be enabled (*arm on*) and protection must be enabled (*DS3 protect on*). In this mode, the primary Controller is connected to the primary DS3 line and the secondary Controller is connected to the secondary DS3 line. The low-speed transmit streams are multiplexed, framed and simultaneously broadcast on both the primary and secondary DS3 lines, thus transmitting the identical payload to the far-end service and protection line. Also, each Controller is framed up to its respective DS3 line and the controller-select signal determines which Controller has access to the low-speed cards, and thus carries the service.




Figure 2-9 Electronics and Network Protection Mode of the Wide Bank 28 DS3

If the active Controller malfunctions, the DS3 line condition deteriorates, or a maintenance switch is invoked (the *switch* command), a protection switch will occur. The Wide Bank will enable the secondary DS3 path through the other Controller card. If revertive switching is enabled (*revertive ds3 on*), there will be a five minute delay (beginning when the previously-active Controller's error rate equals zero). Then the Wide Bank will switch back to the previously-active Controller and DS3 line, provided that there is no longer a malfunction in that path during the five-minute delay. If revertive switching is not enabled (*revertive ds3 off*), no switch-back will occur.

The Wide Bank switching performance complies with Telcordia TR-TSY-752, paragraph 8.4, subparagraph 1, which states that no more than 10 bit errors are caused by the switching operation, and also that the switching operation is accomplished within 250 ns.

The threshold at which DS3 switching takes place is determined by an LCV count within a certain length of time. This threshold can be set for different values using the *DS3 threshold* command, which is explained in detail in *DS3* in Chapter 8. For a definition of LCVs, see *Line Code Violations and Bipolar Violations* on page 2-15.

NOTE: After a power cycle or switching event, switching cannot occur again until the original Controller and DS3 line have experienced five minutes of error-free operation. The five-minute delay is built-in, and conforms to standards to prevent oscillation during poor DS3 line conditions.

Operator-Initiated Switch

A switch of Controllers can be initiated manually by using the switch command. At the prompt, enter the switch command:

(A: Active)> switch

If the secondary Controller is fully functional, the switch is initiated immediately.

If the secondary Controller is considered non-functional by the processor, a prompt will ask to continue. If the choice is to continue with the switch, the switch is initiated unless the secondary Controller is experiencing catastrophic failure, in which case the switch is aborted. If revertive switching is enabled in network protection mode, the switch will last only five minutes. The Wide Bank will then switch back to the original state if the originally active path is error-free.

Restoring to Original Status (Revertive Switching)

Once a switch has occurred, another switch back to the original status (revertive switching) can sometimes occur, depending on certain configurations and equipment status, described below.

Revertive Switching with Electronics Protection

When using electronics protection (two Controller cards and one DS3 line), a switch to the standby Controller card cannot revert automatically. After five minutes automatic protection switching is rearmed, allowing another switch if subsequent errors occur. Without errors, a switch back to the originally active Controller card must be initiated using a *switch* command.

Revertive Switching with Electronics and Network Protection

When using network protection (two Controller cards and two DS3 lines), switching can be configured so that it can automatically revert to original state (after five minutes of error-free operation on the original Controller). Then the original Controller and the original DS3 line again carry the traffic. To configure revertive switching, set *revertive ds3 on* and *arm on*.

To configure network protection mode for non-revertive (one-shot) switching, set *revertive ds3 off* and *arm on*. Once a switch occurs with this configuration, switching back requires a manual switch (*switch* command) or a configuration change.

To configure electronics protection or network protection modes for no automatic switching, set *revertive ds3 off* and *arm off*. With this configuration a switch will occur only if there is a catastrophic equipment failure or a manual switch is initiated.

NOTE: To facilitate testing of automatic switching, you can reset the five minute delay (wait-to-restore time) by using the *clear wtr* command.

Low-Speed (LS) Redundancy

- [Low-Speed Automatic Switchover ... 2-22](#)
- [Low-Speed Circuit Groups ... 2-22](#)
- [Switchover Lockouts Within Groups ... 2-22](#)
- [Maintenance Service Option \(MSO\) ... 2-24](#)
- [Failures that Cause a Low-Speed Switchover ... 2-26](#)
- [Enabling and Disabling Low-Speed Switchovers ... 2-26](#)
- [Restoring to Original Status \(Revertive Switching\) ... 2-27](#)
- [Hot-Swapping a Failed Standard Low-Speed Card ... 2-27](#)
- [Hot-Swapping a Failed MSO Low-Speed Card ... 2-27](#)

Low-Speed Automatic Switchover

The Wide Bank provides low-speed circuit monitoring and automatic switchover to a spare low-speed circuit card when an error is detected. When an error is detected, traffic is automatically switched to a spare low-speed circuit in the same circuit group. The status LED indicator on the spare circuit will change from yellow to green, and the LED on the failed circuit will turn off. When the failed circuit is replaced (see *Hot-Swapping a Failed Standard Low-Speed Card on page 2-27*) the traffic is switched back to the original circuits, leaving the spare card available for subsequent error switching.

Any traffic carried by the spare circuits will be dropped when a failed standard low-speed circuit card is removed. Any traffic carried by the spare circuits will not be dropped when a failed MSO Electronics card is removed, provided that the spare is not already in use before pulling failed MSO card.

Low-Speed Circuit Groups

The Wide Bank 28 DS3 employs a one to seven (1:7) electronics redundancy scheme using four spare DS1 circuits (or three spare E1 circuits) to protect up to 28 active DS1 circuits (or 21 active E1 circuits). Circuit groups are arranged so that each of the circuits on the spare card can replace a corresponding circuit on each of the seven active cards (see Figure 2-1 *Functional Block Diagram on page 2-4* and Table 2-3 *Low-Speed Circuit Groups for Spare Switching on page 2-23*).

Switchover Lockouts Within Groups

A resource conflict occurs when more than one circuit fails in the same low-speed circuit group. Because redundancy is limited to one spare per circuit group, a second failed circuit within the same group is not covered, so it will be locked out.

- If a second failure occurs in the same circuit group, automatic switchover will not occur and the second failed circuit will not be spared. A minor failure alarm will be activated for the second failed circuit, and its card status LED will turn red.

Pulling or “hot-swapping” a card when circuit failures exist on other cards produces the following lockout behavior, depending on the card type.

- If a Standard card is pulled when the spare is already being used, all four circuits on the Standard card will be dropped. The spare circuits will not be affected.
- If an MSO Electronics card is pulled when the spare is already being used, the low-speed circuits using the spare will be kicked off the spare and will be dropped. All four circuits on the pulled card will be moved to the spare card.

Table 2-3 Low-Speed Circuit Groups for Spare Switching

Group	Active Circuit	Spare Circuit
A	01 (First circuit on Card 1) 05 (First circuit on Card 2) 09 (First circuit on Card 3) 13 (First circuit on Card 4) 17 (First circuit on Card 5) 21 (First circuit on Card 6) 25 (First circuit on Card 7)	1 (first circuit on spare)
B	02 (Second circuit on Card 1) 06 (Second circuit on Card 2) 10 (Second circuit on Card 3) 14 (Second circuit on Card 4) 18 (Second circuit on Card 5) 22 (Second circuit on Card 6) 26 (Second circuit on Card 7)	2 (Second circuit on spare)
C	03 (Third circuit on Card 1) 07 (Third circuit on Card 2) 11 (Third circuit on Card 3) 15 (Third circuit on Card 4) 19 (Third circuit on Card 5) 23 (Third circuit on Card 6) 27 (Third circuit on Card 7)	3 (Third circuit on spare)
D	04 (Fourth circuit on Card 1) 08 (Fourth circuit on Card 2) 12 (Fourth circuit on Card 3) 16 (Fourth circuit on Card 4) 20 (Fourth circuit on Card 5) 24 (Fourth circuit on Card 6) 28 (Fourth circuit on Card 7)	These circuits are not used when low-speed cards are E1 4 (Fourth circuit on spare)

Maintenance Service Option (MSO)

In addition to the circuit failure protection provided by Standard DS1 and E1 cards, MSO DS1 and E1 cards will automatically switch low-speed service to the spare card when the electronics are manually removed from a system. With MSO cards, the service interruption time is less than 50 milliseconds compared to 15 seconds when replacing standard cards.

The Maintenance Service Option (MSO) low-speed circuit card is made up of two separating sections called the MSO Electronics card and the MSO Relay card. By separating these sections, a customer can replace the one-to-four (or one-to-three for E1) failed DS1/E1 electronic circuits of that MSO Electronics card while the MSO Relay card automatically maintains the four DS1 (three E1) circuits by switching them to the spare low-speed circuit card. Once new MSO Electronics are inserted and pass self-test, the four circuits (three E1) currently on the spare card are automatically switched back to the “home” circuits.




Figure 2-10 MSO Electronics and MSO Relay Cards

When joined together, the MSO Electronics and MSO Relay cards fit the same form-factor of the standard low-speed card. Therefore, the MSO DS1 or E1 card is compatible with all Wide Bank 28 DS3 systems. The MSO Electronics card contains all the necessary electronics for full operation of all four circuits of the MSO Quad DS1 card or all three circuits of the MSO E1 card. This section

is replaceable by itself (see Chapter 9 for replacement instructions). The MSO Relay card contains the necessary relays to switch the traffic either to the MSO Electronics card or to the spare low-speed card, as required. The Relay card is only replaceable when combined with the electronics card as a unit to form the MSO DS1 or E1 card.

WARNING! DO NOT INSERT THE RELAY SECTION OF THE CARD BY ITSELF. THE RELAY SECTION AND THE ELECTRONICS SECTION MUST BE LATCHED TOGETHER AS A UNIT FOR ADDED STRENGTH WHEN INSERTING IT INTO THE CARD SLOT CONNECTOR.

You can upgrade a non-MSO Wide Bank to an MSO system. The items necessary to upgrade to MSO functionality are:

1. The desired number of MSO low-speed circuit cards (up to 8) to replace the standard low-speed circuit cards.
2. A code update.
The release code for MSO support is Rev 1.47 or higher and is available for both FLASH-based systems and EPROM-based systems. The FLASH-based systems will support software code updates via both TFTP and XMODEM. The EPROM-based systems require a new EPROM integrated circuit (IC) from Carrier Access Corporation. Both systems, if redundant, will maintain live traffic and configurations while the off-line Controller is updated.

The low-speed circuit card residing in the spare low-speed circuit card position can be either a Standard low-speed circuit card or an MSO low-speed circuit card.

Failures that Cause a Low-Speed Switchover

The Wide Bank checks for the following events every 200 milliseconds, and if one or more of them occur, initiates a low-speed switchover.

- **Transmitter Failure.** A transmitter failure is declared when:
 1. There is a lack of activity on the transmit clock.
 2. There is a lack of activity on the transmit tip and ring outputs (either or both). This event is ignored if AMI line coding is selected.
- **System Clock Failure.** When there are no transitions on the master clock of a low-speed card, a failure is declared for all four DS1 (three E1) circuits on the card.
- **Write/Read/Verify Failure.** If the Controller cannot correctly read and write certain test registers on a DS1 card, it declares a failure for that card.
- **Receiver Failure.** This failure can be caused by either a low-speed receiver failure or an external failure of the low-speed line. This failure is declared when there is either no receive activity (Loss of Signal, or LOS) for 2.5 seconds or a Major Line Code Violation (Major LCV). After the switchover, if no signal improvement is seen, the traffic is automatically returned back to the original circuits to retain the availability of the spare.

Enabling and Disabling Low-Speed Switchovers

The low-speed automatic switchovers can be either enabled or disabled for all circuits by using the *ds1 protect* or *ls protect* commands. The factory default setting of low-speed protection is ON. For more information see *LSMODE* on [page 8-58](#).

Example:

To disable automatic switchovers for all low-speed circuits:

```
(A:Active)> ds1 protect off
```

or

```
(A:Active)> ls protect off
```

To enable automatic switchovers for all low-speed circuits:

```
(A:Active)> ds1 protect on
```

or

```
(A:Active)> ls protect on
```

Restoring to Original Status (Revertive Switching)

Because some circuit failures can look like line failures (LOS or Major LCV), the Wide Bank provides a revertive switching feature to keep spares available for use by other circuits.

When a line failure occurs, the Wide Bank will move the channel to the spare circuit. If the failure remains, the problem is a line failure, so the channel is moved back to the home circuit. However, if the failure clears on the spare circuit, the next action depends on the *revertive ds1* setting.

Revertive Off – the channel will remain on the spare circuit until you replace the home card or manually move the channel back to the home circuit.

Revertive On – a self-test will be performed on the home circuit and one of the following actions will occur:

- Self-Test Fails – the channel will remain on the spare circuit until you replace the home card or manually move the channel back to the home circuit.
- Self-Test Passes – the channel will be moved home after 2 minutes. However, if three failures occur within a 24-hour period, the low-speed circuit will be locked out and will remain on the spare card. If fewer than three failures occur on the same circuit within 24 hours, the failure count will decrement by 1 each day until the count is again zero. If desired, you can reset the locked-out circuit (*revertive ds1 reset*), which will move the channel back to the home circuit.

Hot-Swapping a Failed Standard Low-Speed Card

CAUTION! THIS PROCEDURE CAN CAUSE DROPPED CALLS ON THE LOW-SPEED CIRCUITS THAT HAVE BEEN SWITCHED OVER BY AUTOMATIC ELECTRONIC REDUNDANCY.

A standard (non-MSO) low-speed card that causes a switchover can be hot-swapped (swapped with power on) but any calls on the circuits to the failed card, including those that were switched to the spare low-speed card, will be dropped. The circuits will become active again as soon as the new card has completed self-tests, and the previously switched failing channel will be switched back to the new card. The spare card circuit is now unused and available.

Hot-Swapping a Failed MSO Low-Speed Card

The Maintenance Service Option (MSO) low-speed card consists of two separating portions, the MSO Relay card and the MSO Electronics card. The MSO low-speed card allows the failed DS1 or E1 Electronic circuits of that card to be replaced while the MSO Relay portion automatically maintains service on the spare low-speed card. Once a new MSO Electronics card is inserted and passes self-test, the circuits currently on the spare card are automatically switched back to the “home” circuit.

Priority of service on the spare low-speed card is always given to those DS1 or E1 circuits from the first MSO Electronics card removed from the system. Because removing an MSO Electronics card requires four spare DS1 circuits (three E1) to be available, only one MSO card can be removed at a time (see *Low-Speed (LS) Redundancy* on [page 2-22](#)). If any of the spares are already in use by

Product Description

Low-Speed (LS) Redundancy

other cards, there will be a conflict for resources. The conflict results in any circuits previously switched to the spare low-speed card (and still present there) to be switched back to their home low-speed cards. If the home low-speed cards are not able to maintain the circuits, the circuits will be dropped.

MSO Conflicts with Spare Card

If you remove more than one MSO Electronics card section from a Wide Bank, there will not be enough spares to maintain traffic. This conflict will cause all low-speed circuits handled by the removed electronic sections to be dropped. To resolve the conflict, re-insert all the MSO Electronics card sections, then remove and replace only one card at a time, starting with the card containing the failed low-speed circuits. Removing the relay sections of the MSO cards will also resolve the conflict but will not restore dropped circuits.

Tests and Loopbacks

- Transmission Path Verification ... 2-29
- Low-Speed Loopback Modes ... 2-30
- C-bit FEAC Loopback Code Word Detection ... 2-31
- NIU Loopcode Detection ... 2-31
- Low-Speed Performance Monitoring ... 2-32
- DS3 Loopback Modes ... 2-32
- DS3 Loopcode Detection ... 2-34
- Internal Tests ... 2-34
- DS3 Alarm and Performance Monitoring ... 2-34

Transmission Path Verification

Verification of transmission data paths is a unique self-diagnostic capability of the Wide Bank 28 DS3. The low-speed transceivers include a pseudo-random bit sequence (PRBS unframed $2^{15}-1$ as defined by ITU -T O.151) generator, detector, and bit error counter. Because these have the flexibility of being placed in either the receive or transmit low-speed stream, several Bit Error Rate test modes are available, in conjunction with the DS3 Framer. Individual DS1 or E1 bit error rate testing may be conducted toward the low-speed equipment (the “drop”), in the DS3 line, or internally to the Wide Bank (part of self-test). Following activation of the PRBS pattern generation, received pattern synchronization is displayed along with bit error rate counts for the low-speed circuits under test.

Low-Speed Loopback Modes

NOTE: For details on how to run low-speed loopback tests, see *Testing Low-Speed Near-End with Loop Tests* on page 7-19.

Low-Speed Line Loopback

The *low-speed line loopback* loops the low-speed signal back to the low-speed interface.




Figure 2-11 Low-Speed Line Loopback Mode

Low-Speed Equipment Loopback

The *low-speed equipment loopback* loops the low-speed signal back to the Wide Bank.




Figure 2-12 Low-Speed Equipment Loopback Mode

Low-Speed Metallic Loopback

The *low-speed metallic loopback* loops the received low-speed signal back to the low-speed transmit using a relay. This Carrier Access Corporation-unique loopback provides “point-of-entry” fault-isolation between the Wide Bank and attached DS1 or E1 equipment to detect DS1 or E1 line problems.

A spare low-speed card is required to provide metallic loopbacks toward the low-speed connections. The metallic loopback function may not be available if the spare low-speed channels are in use. If this is the case, the Wide Bank will not execute a metallic loopback on the low-speed channel requested. Also, only four low-speed channels (in different spare groups) can be selected for metallic loopback at one time.




Figure 2-13 Low-Speed Metallic Loopback Mode

C-bit FEAC Loopback Code Word Detection

When the Wide Bank is configured for C-bit framing mode, the DS3 monitors and detects low-speed loopback requests sent over the C-bit far-end alarm and control signal. When a low-speed loopback code word is received an equipment loopback is activated (see *Low-Speed Equipment Loopback Mode* on page 2-30).

NIU Loopcode Detection

Each low-speed circuit on the Wide Bank can monitor and detect Network Interface Unit (NIU) loopback codes originating from the DS3 network. A standard 5 second integration time to declare loop-up or loop-down codes is used. Upon detecting an NIU loop-up code on a DS1 or E1 channel of the DS3, a low-speed equipment loopback will be executed by the Wide Bank for that channel. This provides for standard loop testing from the DS3 end, as if a physical DS1 or E1 NIU (“Smart Jack”) was connected to each of the 28 DS1s or each of the 21 E1s.

Low-Speed Performance Monitoring

The low-speed transceivers continuously monitor the incoming physical DS1 or E1 line quality for Excess Zeros, Loss of Signal, and Bipolar Violations.

LS Alarm Signals

- Loss Of Signal.
- Hardware Failure.
- Far-End DS1 (or E1) Loss of Signal.
- Line Code Violations

DS3 Loopback Modes

NOTE: For details on how to run DS3 loopback tests, see *Testing the DS3 Near-End with Loopback Tests on page 7-35*.

DS3 Line Loopback

DS3 Line Loopback returns the received DS3 signal from the transceiver back to the transceiver output, without being processed by the M13 framer.




Figure 2-14 DS3 Line Loopback

DS3 Payload Loopback

DS3 Payload Loopback returns the received DS3 signal from the transceiver through the framer and back to the transceiver output, overriding the DS3 signal created internally by multiplexing the low-speed signals.




Figure 2-15 DS3 Payload Loopback

DS3 Equipment Loopback

DS3 Equipment Loopback returns the signal received from the M1-3 framer back to the input of the M1-3 framer, replacing the signal received from the DS3 line. This loopback is performed by the DS3 framer and validates a full internal DS3 path through the Wide Bank. This loopback is used to send PRBS test patterns back to the low-speed transceivers during the Wide Bank self-test mode.




Figure 2-16 DS3 Equipment Loopback

DS3 Loopcode Detection

When the Wide Bank is configured for C-bit framing mode the DS3 monitors and detects DS3 loopback requests sent over the C-bit far-end alarm and control signal. When a DS3 loopback code word is received a line loopback is activated.

Internal Tests

Microprocessor and memory data paths are tested within the Wide Bank by using self-tests. A complete self-test runs when power is turned on. Individual self-tests can be run by using the *test* command (see Chapter 7 and Chapter 8).

DS3 Alarm and Performance Monitoring

The Wide Bank is capable of monitoring the following DS3 alarms and performance parameters:

DS3 Alarm Signals

- Alarm Indication Signal
- Loss Of Signal
- Out Of Frame
- Idle Sequences
- Remote Alarm Indication
- Far-End Alarms

DS3 Errors

- Line Code Violations
- Excessive Zeros
- P-bit Parity Errors
- C-bit Parity Errors
- Far-End Block Errors
- Framing Bit Errors

CHAPTER 3

Technical Specifications

In this Chapter

- Specifications ... 3-2
 - System Parameters ... 3-2
 - DS1 (1.544 Mbps) Interface ... 3-4
 - E1 (2.048 Mbps) Interface ... 3-4
 - DS3 (44.736 Mbps) Interface ... 3-3
 - Cable Compensation ... 3-5
 - Management ... 3-5
 - Alarms ... 3-5
 - DS3 Transmit Clock Source ... 3-5
 - Power ... 3-6
 - Environmental ... 3-6
 - Physical Dimensions ... 3-6
- Standards Compliance ... 3-7
- Installation ... 3-8

Specifications

- System Parameters ... 3-2
- DS3 (44.736 Mbps) Interface ... 3-3
- DS1 (1.544 Mbps) Interface ... 3-4
- E1 (2.048 Mbps) Interface ... 3-4
- Cable Compensation ... 3-5
- Management ... 3-5
- Alarms ... 3-5
- DS3 Transmit Clock Source ... 3-5
- Power ... 3-6
- Environmental ... 3-6
- Physical Dimensions ... 3-6

System Parameters

The Wide Bank 28 DS3 has the following system parameters:

- Channel Capacity: Up to 28 DS1 signals or up to 21 E1 signals
- Multiplexed data rate = 44.736 Mbps \pm 20 ppm, full duplex
- Timing: Line Recovered, internally sourced, or externally supplied by BNC
- Reframe time maximum average:
 - Less than 1.5 ms for DS3 level
 - Less than 7 ms for DS2 level
- Redundancy: Controller 1:1, Power 1:1 with second Controller card, low-speed circuits 1:7 for electronics
- Path protection: 1+1 unidirectional linear APS architecture (requires second High-Speed DS3 electrical connection)
- High-Speed inputs: Two primary (BNC TX/RX); Two secondary BNC TX/RX
- External Clock cable:
75 ohm coaxial cable with tinned copper shield. Use type 735A or 1735A or equivalent for cables up to 250 feet, and type 734A or 1734A or equivalent for cables longer than 450 feet

- Management:
 - Command Line Interface (CLI) via CLI/RS-232 craft port
 - CLI/Telnet via Ethernet
 - SNMP via Ethernet
 - TL1 via TCP/IP Ethernet and TL1/RS-232 port
 - TL1 automatic outbound messages via TCP/IP Ethernet and TL1/RS-232 port
- Connectors:
 - Four high-speed BNC (728A coax or equivalent)
 - Two locking Low-Speed 64-pin Champ, one for input and one for output
 - Two locking power inputs for independent -48 volt power feeds
 - One locking 9-pin DCE RS-232 for CLI/modem
 - One locking 25-pin RS-232 for TL1 delivery
 - One IEEE 802.3 10Base-T RJ-45 Ethernet
 - One 4-pin alarm, one pair for Critical and one pair for Major/Minor
- Status LEDs:
 - Full primary and secondary Controller critical alarm, major alarm, minor alarm
 - High-Speed and Low-Speed line condition indicators
 - Low-speed Interface

DS3 (44.736 Mbps) Interface

- Meets ANSI T1.102 requirements for DSX-3 digital crossconnect equipment
- Line Rate: 44.736 Mbps \pm 895bps (20 ppm)
- Line Code: Bipolar with three-zero substitution (B3ZS)
- Line Impedance: 75 ohms \pm 5% resistive, unbalanced
- Framing: M23 or C-bit framing formats
- Receive Sensitivity: 0.24 Vp to 0.95 Vp input
- Transmit Amplitude: 0.36 to 0.85 Vp
- Transmit Pulse: Meets ANSI T1.102 pulse mask
- Transmit Jitter: Meets ANSI T1.102 requirement of < 2.0 UI RMS
- Cable Length: Meets ANSI T1.102 pulse mask for cable lengths up to 450 feet to the crossconnect, using coaxial cable type 735A or 1735A or equivalent up to 250 feet, and type 734A or 1734A or equivalent for cables longer than 250 feet

DS1 (1.544 Mbps) Interface

- Meets ANSI T1.102 requirements for DSX-1 digital crossconnect equipment
- Line Rate: 1.544 Mbps \pm 32 ppm
- Line Impedance: 100 ohms \pm 5% resistive, balanced
- Line Code: AMI or B8ZS selectable for DS1
- Transparent to DS1 framing or lack of framing
- Receive Sensitivity: 0.6 Vp to 3.6 Vp input (–13 dBdsx to 3.3 dBdsx)
- Transmit Amplitude: 2.7 to 3.3 Vp
- Transmit Pulse: Meets ANSI T1.102 and T1.403 pulse mask
- Transmit Jitter: Meets ANSI T1.403, T1.102 and AT&T TR 62411
- Loopback Latency (round trip) 34.5 microseconds
- Cable Length: A maximum of 655 ft. of ABAM cable or equivalent to DSX-1 crossconnect equipment
- Line Build Out (LBO): Individual DS1 transmit adjustments for cable lengths of 0-110 ft., 110-220 ft., 220-330 ft., 330-440 ft., 440-550 ft., and 550-660 ft.

E1 (2.048 Mbps) Interface

- Meets ITU-T/G.703 recommendations
- Line Rate: 2.048 Mbps. \pm 50 ppm
- Line Impedance: 120 ohms (balanced), meets minimum return loss requirements from ITU-T/G.703
- Line Code: HDB3
- Framing: Transparent to E1 framing or lack of framing
- Receive Sensitivity: 0.6 Vp to 3.3 Vp input (–13 dB to 2.7 dB with respect to 3 Vp)
- Transmit Amplitude: 3.0 V (nominal)
- Transmit Pulse: Meets pulse shape requirements of ITU-T/G.703
- Transmit Jitter: Meets ITU-T/G.823 recommendations
- Lightning surge protection and power induction protection per FCC part 68 and GR-1089

Cable Compensation

- DS3 Power Level: For an all-ones transmitted pattern, the power in a 2 kHz band (about 22.368 MHz) is -1.8 to $+5.7$ dBm, and the power in a 2 kHz band (about 44.736 MHz) is at least 20 dB below that in the 2 kHz band (about 22.368 MHz).
- DS3 Output Port: ± 0.85 volts peak, adjustable for DSX-3 line buildout from 0 to 50 ft. or 50 to 450 ft.
- DS1 Output Port: ± 3 volts peak adjustable for DSX-1 line build out from 0 to 660 ft. in increments of 110 ft.

Management

- RS-232 DCE port (DB-9) for command line management
- Ethernet port for SNMP and Telnet sessions, for TL1 transport services over TCP, and for NetworkValet management sessions
- RS-232 port for TL1 transport services

Alarms

External alarm contacts for visible or audible alarms or alarm reporting systems:

- Output Alarm: Relay Contacts
- Output State: Normally Open or Normally Closed
- Two Outputs: Critical Alarm and Major/Minor Alarm
- Maximum Current: 200 mA
- Maximum Voltage: 56 VDC
- Control Input: CPU reset, Alarm Cut Off (ACO) switch on the front control panel, or *aco* CLI command.

DS3 Transmit Clock Source

- Line - recovered from DS3 network receive signal
- Internal - on-board Stratum 4E clock source, 44.736 Mbps ± 20 ppm
- External - external BNC input at 44.736 Mbps
 - Input Impedance: 75 Ohms
 - Amplitude: Minimum 250 mV rms sinusoid; Maximum 1.250 V rms sinusoid

Power

- Two three-terminal (-48, Return, Ground) removable wiring connectors provided for A and B power feeds
- Input Voltage: -42 to -58 VDC
- Input current, worst case (-42 VDC):
Fully-redundant with FFO: 0.9 Amp (A and B inputs combined)
Single Controller with redundant DS1s and FFO: 0.6 Amp
- Inrush current: 15 Amps for 100 microseconds
- Power dissipation:
Fully redundant with FFO: 36 Watts (123 BTU/hour)
Fully redundant, non-FFO: 32 Watts (109 BTU/hour)
Single Controller with redundant DS1s, non-FFO: 22 Watts (75 BTU/hour)
- Redundant power sharing at the +5V logic level
- Internal solid-state (fuseless) over-voltage and over-current protection
- External inline power fuse recommended: One 3 Amp slow-blow for each power feed
- Optional Power Converter/Battery Charger (Carrier Access P/N 730-0116):
115 VAC to -48 VDC
- Optional Battery Unit (Carrier Access P/N 730-0114):
Provides 6 to 8 hours backup power
Two backup systems provide 8 to 12 hours backup power

Environmental

- Altitude: 0 to 15,000 ft. (0 to 4,572 m)
- Humidity: 0 to 98% (noncondensing)
- External Operational Temperature Range (ambient air):
Meets NEBS operating temperature criteria of 23°F to 104°F (-5°C to 40°C) for an indefinite period, and up to 131°F (55°C) for 96 hours (4 days) continuous for a maximum of 15 days per year
- Thermal Protection: Automatic power supply shut-down at 176°F (80°C) ambient

Physical Dimensions

- Height: 1.75 inches (4.45 cm) - mounting brackets fit 1.75-inch and 2-inch hole spacing
- Depth: 10 inches (25.4 cm) - 10.9 inches (27.6 cm) with fan faceplate installed
- Width: 17 inches (43.2 cm) - mounting brackets fit 19-inch and 23-inch racks

- Weight: 10 pounds (4.5 kg) fully equipped
Shipping Weight: 14 pounds (6.4 kg)
- Service Access Aisle: 24 inches (61 cm) front and rear
- Cable Clearance: 3 inches (7.6 cm) behind rear connector panel

Standards Compliance

Safety

- CAN/CSA-C22.2 No. O-M1991
- FCC Regulations, Part 15, Class A (Digital Devices) and Part 68 (Connection of Terminal Equipment to the Telephone Network)
- Industry Canada CS-03 listed
- National Electrical Code 1995 Safety Requirements
- CSA and UL (Bi-National) Standard for Information Technology Equipment, Including Business Equipment, CAN/CSA 22.2, No. 60950-00 / UL 60950, third edition, dated December 1, 2000

Industry

- ANSI T1.403-1996 (T1/EI.2194-003 RI). "Network to Customer Installation - DS1 Metallic Interface." Draft revision to ANSI T1.403-I 989. American National Standards Institute, Sept. 1994.
- ANSI T1.102-1993, "Digital Hierarchy-Electrical Interfaces"
- ANSI T1.404a-1996, "Mask Modification"
- ANSI T1.107a-1995, "Digital Hierarchy - Formats Specification"
- AT&T Technical Reference 62411. "ACCUNET T1.5 Service: Description and Interface Specifications." AT&T, December 1990.
- AT&T Technical Reference 54017. "Automatic Protection Capability, a service function of ACCUNET T1.5 Service."
- CCITT Recommendation V.11. "Electrical Characteristics for Balanced Double-Current Interchange Circuits for General Use with Integrated Circuit Equipment in the Field of Data Communications."
- Telcordia Technical Reference TR-NWT-000499 Issue 4, Revision 1, April 1992, "Transport Systems Generic Requirements (TSGR): Common Requirements."
- Telcordia GR-253-CORE and GR-499-CORE SONET specification
- NEBS Certification: Meets Network Equipment Building Standards (NEBS) Level 3 (earthquake Zone 4), Type 2 and 4 requirements for central office products including electrical safety, emissions, and immunity requirements for intra-building use. Refer to Telcordia GR-63-CORE and GR-1089-CORE for more details.

Technical Specifications

Installation

- Telcordia GR-63-CORE Network Equipment Building System (NEBS) Requirements: Physical Protection
- Telcordia GR-1089-CORE Electromagnetic Compatibility and Electrical Safety - Generic Criteria for Network Telecommunications Equipment

Installation

- Standard EIA & WECO 19-inch or 23-inch rack-mount using universal heavy-duty rack-mounting brackets (part number 710-0153) included with each Wide Bank
- Optional EIA & WECO 19-inch crossbars for mounting up to six units vertically in an 11 rack-unit space (P/N 710-0003)
- Optional EIA & WECO 23-inch crossbars for mounting up to eight units vertically in an 11 rack-unit space (P/N 710-0004)
- Fan Faceplate Option, which provides additional cooling and allows up to 40 Wide Banks to be mounted in a rack

CHAPTER 4

Physical Installation

In this Chapter

- Installation Preparation and Requirements ... 4-2
- Mounting the Wide Bank 28 DS3 ... 4-3
- Mounting the Power Converter/Battery Charger ... 4-11
- Mounting the Battery Unit ... 4-11

Installation Preparation and Requirements

This product is shipped as a complete package, including the Wide Bank 28 DS3 case, equipped (per order) with the number of low-speed cards ordered (from none to as many as eight) and the number of DS3 Controller cards ordered (from none to as many as two). When the shipment arrives, check the contents of the shipping carton against the Packing Materials List in Table 4-1.

- Inspect the unit for signs of damage, report any damage to the shipping company
- Retain all packaging materials if you need to ship or relocate the unit in the future

Table 4-1 Wide Bank 28 DS3 Packing List

Description	Part Number
Items Included With Wide Bank 28 DS3 Purchase	
Wide Bank 28 DS3 Multiplexer equipped according to customer order with low-speed cards and DS3 Controller cards.	
Wide Bank 28 DS3 Controller card (1-2)	740-0029 (740-0187)
Wide Bank Quad DS1 (QDSX) card (1-8)	740-0172
Wide Bank MSO Quad DS1 card (electronics and relay card)	740-0023
Wide Bank MSO Quad DS1 electronics card	740-0025
Wide Bank Three-Channel E1 card (1-8)	740-0052
Wide Bank MSO E1 card (electronics and relay card)	740-0057
Wide Bank MSO E1 electronics card	740-0053
Universal 19-inch or 23-inch Heavy Duty Rack Mounting Brackets (4 pieces) with mounting screws	710-0153
Wide Bank 28 DS3 User Manual	770-0074
Wide Bank 28 DS3 Accessory kit (power connectors, alarm connectors)	790-0002
Wide Bank 28 DS3 Ghost Unit (no cards)	930-0097
Optional Items	
Fan Faceplate Option	790-0003
DSX-1 Cable, 10 ft (3.048 m), for DS1/E1 transmit & receive connections.	005-0025
DSX-1 Cable, 25 ft (7.7 m), for DS1/E1 transmit & receive connections	005-0030
Battery Unit	730-0114
115 VAC/60Hz to -48VDC Power Converter/Battery Charger (DO NOT use the Carrier Access Corporation AB115 Power Converter Cube to power the Wide Bank)	730-0116
19-inch Vertical Mounting Cross Bar (2)	710-0003
23-inch Vertical Mounting Cross Bar (2)	710-0004
Power Cube Tray for mounting up to 3 power converter/chargers	710-0005

Mounting the Wide Bank 28 DS3

- Attaching Mounting Brackets to the Units ... 4-4
- Rack Mounting - Non-FFO Equipped Units ... 4-6
- Rack Mounting - FFO-Equipped Units ... 4-9

DANGER! WHEN INSTALLING THE WIDE BANK, BE SURE TO OBSERVE STANDARD SAFETY PROCEDURES FOR WORKING WITH ELECTRICAL EQUIPMENT.

Rack mounting is the only recommended method for mounting the Wide Bank. The different recommended configurations for rack mounting are:

Standard, non-FFO units:

- Horizontal mounting in a 19-inch or 23-inch rack. This method is limited by specific guidelines described in the mounting procedures that follow.
- Vertical mounting in a 19-inch or 23-inch rack. This method allows up to 24 units to be mounted in a single rack, depending on environmental factors.

FFO-equipped units:

- Horizontal mounting is the only recommended configuration for FFO-equipped units. FFO-equipped units do not require a 1 RU space between units, which results in the highest density installation method.

Before mounting the Wide Bank chassis, ensure that the installation site meets the following criteria:

- Adequate clearance for maintenance access, cable routing, and air flow to cool the unit. Allow approximately 30 inches in front of the removable control panel for maintenance and accessing the slide-in cards. Allow approximately 24 inches in the rear for cable access and bending radius.
- Because the cables on the Power Converter/Battery Charger total 12 feet in length, there should be a properly grounded, 120 VAC power outlet within 11 feet of the Wide Bank power connectors, unless power is supplied by other power conversion equipment that has longer cables.
- A stable environment, clean and free from extremes of temperature, shock, vibration, and EMI, with a relative humidity between 0 and 98%.
- An appropriate ambient air temperature for the mounting method used. The Wide Bank 28 DS3 operates throughout the NEBS operating temperature range unless otherwise specified in the installation descriptions below.

NOTE: If the operating temperature rises above 176° F (80° C), an Over-Temperature alarm is generated. When the temperature is reduced below 176° F (80° C), the Over-Temperature alarm will clear.

- An altitude below 15,000 ft. (4,572 m).

Attaching Mounting Brackets to the Units

The included Universal Heavy-Duty Brackets (Carrier Access part number 710-0153) can be used to mount the Wide Bank in either 19-inch or 23-inch racks, with either 1 3/4-inch or 2-inch vertical hole spacing. These brackets are made up of four individual pieces. The following procedures show how to assemble the brackets and attach them to a Wide Bank.

1. There are two bracket parts with right-angle bends (see Figure 4-1). Mount one of these on each side of the Wide Bank to obtain the desired offset, as shown in Figure 4-2, using the #6 x 3/8-inch mounting screws provided. Use the Wide Bank mounting holes nearest the front of the unit to produce a typical flush mounting. Use the Wide Bank mounting holes nearest the rear of the unit for a 5-inch or center offset to the front.
2. If you are mounting the Wide Bank in a 23-inch rack, fasten the other two bracket pieces to the previously-mounted brackets, as shown in Figure 4-1, using the four 10-32 x 3/4" machine screws provided.
3. Mount the chassis and bracket assembly on the rack, using 10-32 x 3/4" rack-mounting screws in a manner appropriate for the selected mounting arrangement. See *Rack Mounting - Non-FFO Equipped Units* on page 4-6 or *Rack Mounting - FFO-Equipped Units* on page 4-9, as required.




Figure 4-1 Universal Rack-Mounting (19-inch or 23-inch) Brackets (PN 710-0153)




Figure 4-2 Attaching Brackets to 19-inch or 23-inch Racks

Rack Mounting - Non-FFO Equipped Units

- Horizontal Mounting in a Standard EIA or WECO Rack ... 4-6
- Vertical Mounting in a Standard EIA or WECO Rack ... 4-7

NOTE: When mounting Non-FFO Wide Banks horizontally in the same rack, follow the mounting instructions below to meet the NEBS Operating Temperature Criteria and to allow sufficient cooling to prevent thermal shutdown under maximum load conditions.

Horizontal Mounting in a Standard EIA or WECO Rack

Mount Wide Banks, as shown in Figure 4-3, in groups of up to four units, with the units in each group separated by one rack unit (1 3/4 inches). Separate the four-unit groups with four rack units (7 inches) of open space. The Wide Banks can be horizontally mounted in either a standard EIA 19-inch rack or a standard EIA/WECO 23-inch rack using the mounting brackets shipped with the unit.




Figure 4-3 Horizontal Mounting in a Standard Rack

Vertical Mounting in a Standard EIA or WECO Rack

This mounting configuration requires an ambient air temperature below 77° F (25° C), without supplemental cooling. In spaces where ambient temperature can rise above 77°F, install a fan tray (600 CFM or more) below the rows of Wide Banks. The fan tray must direct the air up through the units.

The Wide Banks can be vertically mounted in either a standard EIA/WECO 19-inch rack or a standard EIA/WECO 23-inch rack using the mounting brackets shipped with the unit, and optional Carrier Access Vertical Mount Crossbars (PN 710-0003 for 19-inch racks and PN 710-0004 for 23-inch racks). See Figure 4-4 for an illustration of mounting in both sizes of racks.




Figure 4-4 Vertical Mounting in 19-inch and 23-inch Racks

Physical Installation

Mounting the Wide Bank 28 DS3

If other crossbar structures are used to mount the Wide Banks, align the units vertically, as shown in Figure 4-3, to provide a conduit for convective air flow.

Using a 19-inch rack and crossbars 710-0003, six units can be mounted in each of three horizontal rows, for a total of 18 Wide Banks. Do not mount any other Wide Banks (horizontally) above or below the vertically-mounted units. Fan trays may be mounted below, and fuse panels above but no heat-dissipating equipment or passive structures that impede natural air flow.

Using a 23-inch rack and crossbars 710-0004, eight units can be mounted in each of three horizontal rows, for a total of 24 Wide Banks. Do not mount any other Wide Banks (horizontally) above or below the vertically-mounted units. Fan trays can be mounted below, and fuse panels above but no heat-dissipating equipment or passive structures that impede natural air flow.

Rack Mounting - FFO-Equipped Units

- Fan Faceplate Option ... 4-9
- Rack Mounting (High-Density) ... 4-10

High-density mounting of the Wide Bank requires additional cooling capability provided by the Fan Faceplate Option (FFO). Any Wide Banks mounted with less than one rack unit of space between them must have the FFO option installed.

With FFO the Wide Bank meets NEBS thermal performance criteria for installation of up to 40 units per rack with no space between units (see Figure 4-5 and Figure 4-7).

Fan Faceplate Option



The Fan Faceplate Option provides additional cooling capacity to allow the Wide Banks to be mounted with no space between them. When fan faceplates are installed, the fan power connectors on the faceplates mate with power connectors on the Controller cards (see Figure 4-6). When installing a faceplate, use care to ensure correct alignment of the power connectors before tightening the fastening screws at each end of the faceplate. Also, the fastening screws must be tightened with an adequate tool for compliance with UL 1950. Do not overtighten.

The fans start operating 30 seconds after the FFO is installed.




Figure 4-5 Standard Rack Fully Loaded with FFO-Equipped Units

NOTE: Pre-FFO Wide Banks can be converted to FFO units. The conversion requires new Controller cards that can accommodate a Fan Faceplate and loaded with software release 2.0 or higher.

Physical Installation

Mounting the Wide Bank 28 DS3

NOTE: When removing a fan faceplate in a high-density rack with power on, re-install the fan faceplate within 30 seconds to prevent the Wide Bank from overheating.




Figure 4-6 Fan Faceplate Option

Rack Mounting (High-Density)

Figure 4-7 illustrates the maximum possible density for rack-mounting the Wide Banks in either a standard EIA or WECO 19-inch or a standard EIA or WECO 23-inch rack using the mounting brackets shipped with the unit. This density requires that each Wide Bank have the Fan Faceplate Option installed. Up to 40 FFO-equipped units can be mounted in a single rack.

Vertical mounting is not an approved option for FFO-equipped units.




Figure 4-7 High-Density Mounting with the FFO Option

Mounting the Power Converter/Battery Charger

The Wide Bank can be supplied with power for US operation with the optional 115 VAC to –48 VDC Power Converter/Battery Charger. This converter includes both a six-foot grounded AC power cord and a six-foot three-position DC power cable. The Power Converter/Battery Charger has four mounting holes for attaching the unit to a wall or other flat surface. To mount the Power Converter/Battery Charger on a nearby wall, locate the converter within 5.5 feet of the Wide Bank rear connector panel and use screws or anchors appropriate for the mounting surface.

When using a single power converter, the power connectors shipped with the Wide Bank must be “daisy chained” to supply power to both the A and B power input connectors.

Mounting the Battery Unit

- Wall-Mounting the Battery Unit ... 4-11
- Rack Mounting the Power Converter & Battery Unit ... 4-14

The Wide Bank power supply redundancy can be supplemented by using a Carrier Access Corporation –48V Battery unit. The battery unit is kept charged by the Power Converter/Battery Charger. When AC power fails, the battery unit supplies continuous –48 VDC power for six to eight hours, depending on operational status, the condition of the batteries, and the ambient temperature. A single 6-foot DC power cable connects the battery unit to the Power Converter/Battery Charger.

Wall-Mounting the Battery Unit

To mount the battery unit on a nearby wall, locate the battery unit within 5.5 feet of the Power Converter/Battery Charger and use screws or anchors appropriate to the mounting surface. To mount the battery unit on a 3/4-inch piece of plywood, use four #8 x 3/4-inch pan-head wood screws. See Figure 4-8.

1. Using the template included with the battery unit, clearly mark the locations of the four screws on the plywood. If this template is misplaced, a scaled-down copy of the template, with dimensions, is included in Figure 4-8.

DANGER! DO NOT DRILL THE PILOT HOLES SO LARGE THAT THE SCREW THREADS WILL NOT HOLD. IF THE BATTERY UNIT SHOULD FALL, IT CAN CAUSE SERIOUS INJURY OR DAMAGE. THE CORRECT SIZE DRILL BIT FOR #8 WOOD SCREWS IS 7/64 INCH (1/8 INCH MAXIMUM).

2. Pre-drill pilot holes for all four screws using a drill bit of appropriate size for the screws you are using. This is necessary because the holes are so close to the battery case that it is difficult to drive the screws into the plywood.

Physical Installation


Mounting the Battery Unit

3. Drive the lower two #8 x 3/4-inch pan-head wood screws into the lower pilot holes until the heads are within 1/8 inch of the plywood (see enlargement in Figure 4-8). DO NOT drive the screws until the heads seat on the plywood.
4. Carefully lift the battery unit and hang it on the two screws installed in step 3, using the two keyhole screw slots in the lower corners of the battery unit back plate.

DANGER! DO NOT RELEASE THE BATTERY UNIT UNTIL STEP 5 (BELOW) IS COMPLETED. IF THE BATTERY UNIT SHOULD FALL, IT CAN CAUSE SERIOUS INJURY OR DAMAGE.

5. Fasten the top of the battery unit to the plywood with two #8 x 3/4" pan-head wood screws in the upper pilot holes.

Also see *Rack Mounting the Power Converter & Battery Unit* on [page 4-14](#) for a description of how to rack-mount the Battery Unit.



Screw Hole Locations




Figure 4-8 Mounting the Battery Unit

Rack Mounting the Power Converter & Battery Unit

The Power Converter and Battery unit can be mounted in EIA or WECO racks using heavy-duty mounting brackets and the power supply shelf, as shown in Figure 4-9.




Figure 4-9 Rack-Mounting Battery Units & Power Converters

CHAPTER 5

Electrical Installation and Cabling

In this Chapter

- Cabling and Compliance Requirements ... 5-2
- Static-Sensitive Equipment Handling Procedures ... 5-3
- Connector Panel Interface and Power Connectors ... 5-4
- Cable and Wiring Layout ... 5-5
- Ground Connection ... 5-6
- Low-Speed DS1/E1 Cables ... 5-7
- High-Speed DS3 Cables ... 5-9
- External Clock Cable ... 5-9
- Management Cables ... 5-10
- Power Wiring ... 5-13

Cabling and Compliance Requirements

The Wide Bank 28 DS3 shipping package contains no cables. Refer to following compliance and cable installation procedures for specific cable requirements.

Maintaining NEBS 1089 and FCC Part 15 Compliance

- **Shielding** – All cables connected to the following connectors on the Wide Bank 28 DS3 must be shielded: the Ethernet connector, both low-speed connectors (**LOW SPEED IN** and **LOW SPEED OUT**), and both RS-232 connectors (**RS-232** and **TL1**).
- **RFI Suppressors** – Both low-speed cables and the RS-232 management cable must have ferrite RFI suppressors installed, as described below.
- **Wiring Exposure** – All cables connected to this product must be intrabuilding or non-exposed wiring per GR-1089-CORE.

Static-Sensitive Equipment Handling Procedures

CAUTION! THE WIDE BANK CONTAINS CIRCUIT CARDS AND COMPONENTS THAT ARE SUBJECT TO DAMAGE BY ELECTROSTATIC DISCHARGE (ESD). ALWAYS USE THE FOLLOWING PROCEDURE WHENEVER HANDLING PLUG-IN CIRCUIT CARDS.

NOTE: A grounding wrist strap consists of an electrically conductive elastic wrist band with a grounding wire for connection to the equipment chassis or a common ground point.

Static electricity is always present and is easily picked up from shoes and clothing. Using anti-static procedures will minimize the chances of damaging sensitive semiconductor components.

1. Wear a grounding wrist strap whenever handling, touching, inspecting, installing, or removing plug-in circuit cards.
2. Test the grounding wrist strap before using.
 - Use an ohmmeter to check the resistance of a grounding wrist strap.
 - Connect one meter lead to wrist strap.
 - Connect other meter lead to metal clip or banana plug at end of grounding wire.
 - A resistance of one megohm to ten megohms (megohm = one million ohms) is typical and will provide adequate protection to equipment and user.
 - **DO NOT** use the wrist strap if the resistance is more than 35 megohms because it will not protect the equipment from ESD damage.
 - **DO NOT** use the wrist strap if the resistance is less than 0.75 megohms (750,000 ohms) because it will not protect you from high voltage shock hazards.
3. Before touching a circuit card, momentarily touch the grounded equipment rack or chassis to discharge any static buildup.
4. Before inserting or removing a circuit card from a storage bag, momentarily ground or hold the anti-static plastic storage bag to discharge any static buildup.
5. Do not touch any components or printed wiring on the circuit card. Hold the card by its edges or plastic handles.
6. Always store circuit cards in an anti-static storage bag. Whenever possible, use the same storage bag the card or replacement card came in.
7. If a circuit card is to be returned to the factory, always ship the circuit card inside an anti-static storage bag.

Connector Panel Interface and Power Connectors




Figure 5-1 Wide Bank 28 DS3 Interface and Power Connectors

Cable and Wiring Layout

The figure below shows a typical cable and wiring layout for the Wide Bank 28 DS3. Tie-down loops are provided on the left and right side of the connector panel for tying down cables and wires. Because the low-speed connectors are located in the center of the panel, it is easiest to dress the low-speed cables, Ethernet, ground, and alarm wiring toward the left side of the chassis (as viewed from rear), with the remaining cables and power wires dressed toward the right side, as shown.

NOTE: Ferrite Cube RFI Suppressors are Carrier Access part number 010-0051.




Figure 5-2 Cable and Wiring Layout Example

Ground Connection

When the Wide Bank is connected to a power source other than the Carrier Access Power Converter/ Battery Charger, a separate ground wire must be connected to a Common Bonding Network (CBN). A recommended method to make this connection is shown below.

CAUTION! CHASSIS MUST BE PROPERLY GROUNDED FOR COMPLIANCE WITH NEBS 1089 EMI/EMC AND FCC REQUIREMENT PART 15, FOR POWER GROUNDING AND TO PREVENT RADIO FREQUENCY INTERFERENCE WITH OTHER EQUIPMENT.

1. Measure and cut enough wire to connect from building ground to grounding lug on the connector panel of the Wide Bank. Use #14 to #6 AWG insulated copper wire, as required by grounding practice.
2. Route wire from building ground to Wide Bank connector panel. Bend wire to position it near chassis ground studs, as shown in the figure.
3. Obtain a ground lug with crimp or compression clamp for attaching ground wire. Do not use solder, quick-connect or friction-fit connectors.
4. Strip enough insulation off wire end to fit inside the ground lug, flush with front of wire compression clamp.
5. Apply an anti-oxidant compound to the lug's crimp or pressure connector and to the chassis bonding surface.
6. Insert ground wire into ground lug and clamp wire securely using crimp tool or compression tool.
7. Remove lug nuts and lock washers (included) from chassis ground studs.
8. Position ground lug over chassis ground studs and install a star or lock washer.
9. Attach lug nuts and tighten to 0.8 foot-pound (1.086 Nm).




Figure 5-3 Ground Connections

Low-Speed DS1/E1 Cables

The Wide Bank 28 DS3 uses DSX-1 cables for crossconnecting DS1 or E1 signals to other equipment. If the DSX-1 cables will interface with wire-wrap connections, see *Low-Speed DS1/E1 (DSX-1) Connector Pinouts* on [page A-4](#) for circuit, pin, and wire group information.

Two DSX-1 cables are required, one for transmit and one for receive. See table for cable part numbers and specifications.

Table 5-1 Wide Bank 28 DS3 Low-Speed Cables

Part No.	Cable Length	Application	Connectors
005-0025	10 ft. (3.048 m)	Low-Speed cable for connecting the Wide Bank 28 DS3 to a DS1 or E1 patch panel for standard low-speed applications	Two 64-pin male Amphenol [®] “CHAMP” connectors
005-0030	25 ft. (7.7 m)	Low-Speed cable for connecting the Wide Bank 28 DS3 to a DS1 or E1 patch panel for standard low-speed applications.	Two 64-pin male Amphenol [®] “CHAMP” connectors

CAUTION! CABLE CONNECTORS MUST BE SECURELY LATCHED IN PLACE TO PREVENT SERVICE INTERRUPTIONS. IF THE CABLE CONNECTOR INTERFERES WITH THE LATCH SPRING OR CAN NOT BE SECURELY LATCHED, A DIFFERENT CABLE SHOULD BE USED.

1. Carefully connect the 64-pin connectors of DSX-1 cables to **LOW SPEED IN** and **LOW SPEED DS1 OUT** on the Wide Bank connector panel (see Figure 5-4). Ensure that the spring-loaded connector latches snap over the connectors (see Figure 5-5).
2. Insert and tighten the connector screws on the ends of both connectors (see Figure 5-5).
3. Secure both low-speed cables with cable ties as shown in Figure 5-5.
4. Connect both grounding wires from the low-speed cables to the **Low Speed Drain Wires** connection, as shown in Figure 5-3 and in Figure 5-4.
5. If there are grounding leads on the far end of the low-speed cables, cut them off to prevent them from being connected to other equipment, which may cause an unwanted ground loop.
6. Attach ferrite RF Suppressors on the low-speed cables (two per cable for DS1, three per cable for E1) as shown in Figure 5-2.

Electrical Installation and Cabling

Low-Speed DS1/E1 Cables




Figure 5-4 Connecting the Low-speed Cables




Figure 5-5 Fastening & Tying Down Low-speed Cables

High-Speed DS3 Cables

DS3 connections require 75 ohm coaxial cable with tinned copper shield. Use 735A or 1735A or equivalent cable for lengths up to 250 feet, and 728A or 734A cable for lengths up to 450 feet.

1. Connect the Primary DS3 Input to **Primary IN**.
2. Connect the Primary DS3 Output to **Primary OUT**.
3. Connect the Secondary DS3 Input to **Secondary IN**.
4. Connect the Secondary DS3 Output to **Secondary OUT**.




Figure 5-6 Connecting the DS3 and Clock Cables

External Clock Cable

The Wide Bank 28 DS3 is designed to accept a high-speed 44.736 Mbps external clock source for certain applications. The external clock cable must be a shielded coax terminated with a BNC connector. (See DS3 cable requirements above.) Connect it to **Ext. Clock** on the Wide Bank. For technical specifications, see *DS3 Transmit Clock Source* on [page 3-5](#).

Management Cables

- CLI RS-232 Management Cable ... 5-10
- TL1 RS-232 Port Cable ... 5-11
- Ethernet Management Port ... 5-11
- External Alarm Wiring ... 5-12

CLI RS-232 Management Cable

The RS-232 management port can be connected to an RS-232 terminal or a PC running terminal emulation software such as Hyperterm. Set the port for 9600 baud, 8 data bits, 1 stop bit, no parity, and no flow control.




Figure 5-7 Connecting the Management Cables

The RS-232 CLI management cable must be a shielded RS-232 cable with a male DB9 connector. Connect management cable to RS-232 port on the Wide Bank. For compliance with FCC standards, install a ferrite RF suppressor as shown at right. Note that the cable is looped 360° through the suppressor, then the suppressor is closed and latched.




Figure 5-8 Installing the RS-232 Port Cable and Ferrite RF Suppressor

TL1 RS-232 Port Cable

Connect a shielded DB25 cable between the Wide Bank's TL1 RS-232 asynchronous port and either a terminal multiplexer or an external X.25 pad to provide asynchronous RS-232 to X.25 conversion if preferred. See *TL1 RS-232 Management Port Pinout* on [page A-8](#).

Ethernet Management Port

Connect an Ethernet cable between the Wide Bank's Ethernet port and an IP network for remote management using SNMP, Telnet, TL1 alarms, and Carrier Access' NetworkValet EMS software. The Wide Bank's Ethernet port accepts a standard RJ-45 connector. See *Ethernet RJ-45 (10Base-T) Pinout* on [page A-9](#). The Ethernet cable must be shielded for compliance with NEBS and FCC requirements.

NOTE: For remote management over an IP network, you must know the IP address of the Wide Bank (see *Configuring IP and PPP Addresses* on [page 6-15](#)). For TL1 the default TCP port number is 9999 but this can be changed (see *TL1 Setup and Configuration* on [page 9-9](#)).




Figure 5-9 Connecting to Ethernet Port for Remote Management

External Alarm Wiring

The external alarm contacts can be wired to a remote alarm panel to indicate alarm conditions on the Wide Bank 28 DS3. The figure shows an example of how to wire the contacts. The external alarm contacts can be programmed for either normally open or normally closed operation, using the CLI command `alarmout {no|nc}`. In either case, when the Wide Bank is not powered, the alarm contacts will be open. There is no voltage present on these contacts until they are connected to an external voltage source. See figure for maximum contact ratings.




Figure 5-10 External Alarm Wiring

Power Wiring

- DC Power Connector Input Requirements ... 5-13
- Wiring the Power Plugs ... 5-14
- Connecting to Power Source ... 5-15
- Applying Power ... 5-16

DC Power Connector Input Requirements

CAUTION! BOTH POWER INPUTS MUST BE CONNECTED WHEN THE WIDE BANK IS EQUIPPED WITH TWO CONTROLLER CARDS. IF ONLY ONE CONTROLLER IS POWERED, SERVICE WILL BE INTERRUPTED WHEN THE POWERED CONTROLLER IS REMOVED OR ITS INTERNAL POWER CONVERTER FAILS.

WARNING! THE POWER CONNECTOR INPUT IS FOR **-48 VDC** POWER ONLY. THE POWER AND GROUND WIRES IN THE SUPPLY CABLE MUST BE EITHER **16 AWG** OR **18 AWG** WIRE. THE POWER SUPPLIED TO THE WIDE BANK MUST BE EXTERNALLY PROTECTED BY A THREE-AMP CIRCUIT BREAKER OR SLOW-BLOW FUSE IN THE **-48 VDC** BRANCH CIRCUIT.

WARNING! WARRANTY DOES NOT COVER FAILURES RESULTING FROM LONG-TERM OPERATION WITH POWER APPLIED TO ONLY ONE OF THE REDUNDANT CONTROLLER CARDS.

NOTE: Carrier Access strongly recommends that power always be applied to both power input connectors even if the unit is equipped with only one Controller card. Powering both connectors allows Controller cards to be inserted into either card slot, enables quick installation of a redundant Controller, and also speeds card replacement and software upgrades without losing the current configuration settings.

The Wide Bank has two three-pin DC power connector inputs located on the rear connector panel (see Figure 5-1). Connector A supplies **-48 VDC** to Controller card A, and connector B supplies **-48 VDC** to Controller card B.

If two Controller cards are installed for redundant operation, both power connectors, A and B, must be connected to a **-48 VDC** power source to prevent service interruptions in the event of a power failure or Controller failure. If redundant power sources are not available, both power connectors can be wired to the same source.

The Wide Bank is designed to provide redundant power input protection and redundant power converter protection. For example, if Controller card A loses -48 VDC input power or if its power converter fails, Controller card B will continue to provide power to all circuits in the Wide Bank. Prolonged operation with only one power input will reduce reliability.

To conform with UL 1950 third edition, and CSA-C22.2 No. 950-95 Standard for Safety for Information Technology Equipment, the Wide Bank is equipped with solid-state, automatic-resetting, current-limiting devices to protect the -48 V input and DC return from AC power surges, lightning, or inductive motor spikes. There are no fuses in the Wide Bank.

Wiring the Power Plugs

Two power plugs are shipped with each Wide Bank for wiring to a -42 to -58 VDC power supply as described in the following procedure.

DANGER! ENSURE THAT NO POWER IS PRESENT ON THE THREE WIRES FROM THE POWER SOURCE.

1. Use only 16 AWG or 18 AWG copper wire.
2. Strip the three wires from the power source so that 5/16-inch of bare wire is exposed.

WARNING! BE SURE TO WIRE THE CONNECTOR CORRECTLY, AS DESCRIBED IN THIS PROCEDURE. WIRING -48 V TO THE WRONG TERMINAL CAN SEVERELY DAMAGE THE EQUIPMENT OR POWER SUPPLY.

3. Loosen the set screws and insert the wires in the appropriate square holes as shown below, one at a time, tightening the set screws as you go. When inserting wires, ensure that no bare wire is exposed.




Figure 5-11 Wiring the Power Plugs

Connecting to Power Source

CAUTION! WHEN A CARRIER ACCESS POWER CONVERTER/BATTERY CHARGER IS USED, THE WIDE BANK IS GROUNDED THROUGH THE POWER PLUG (PIN 1). THEREFORE, THE POWER CONVERTER MUST BE PLUGGED INTO A PROPERLY GROUNDED THREE-PRONGED OUTLET WITH A SOLID EARTH GROUND TO PREVENT CIRCUIT PROBLEMS. THE POWER CONVERTER ALSO HAS AN EXTERNAL GROUNDING LUG THAT SHOULD BE CONNECTED TO EARTH GROUND.

IF THE WIDE BANK IS CONNECTED TO A POWER SOURCE OTHER THAN THE CARRIER ACCESS POWER CONVERTER/BATTERY CHARGER, A SEPARATE GROUND WIRE MUST BE CONNECTED TO A COMMON BONDING NETWORK (CBN). SEE *GROUND CONNECTION ON page 5-6*.

NOTE: We recommend that each power input cable be protected by an in-line 3-amp slow-blow use in the -48 Volt line.

Pinout assignments for the power connectors are shown below.




Figure 5-12 Power Connector Pinout

1. Ensure that the power source switch is off (Carrier Access Power Converter/Battery Charger or other power source).
2. Connect the power connectors to the Power A and Power B receptacles on the Wide Bank.

Applying Power

1. Turn on the power switch on the front of the Power Converter, or other local DC power source. There is no power switch on the Wide Bank.
2. Verify that power has been applied to the Wide Bank. The Power LEDs on the front of the Wide Bank should be green for each Controller card installed after initialization.
3. See Chapter 6, *Configuration on page 6-1* for the next step in making the Wide Bank operational.

CHAPTER 6

Configuration

In this Chapter

- Configuration Overview ... 6-2
- Basic Configuration ... 6-2
- Downloading New Software ... 6-23

Configuration Overview

The Wide Bank 28 DS3 Multiplexer is configured at the factory with defaults that are common in the industry. If the default configuration must be changed, or if the setup is lost, perform the following steps to set up a basic configuration.

1. Use the *restore defaults* command to restore the configuration to factory defaults.
2. Change each individual item, as required, to match your specific application.

The basic configuration settings presented in this chapter are examples. It may be necessary to use parameters different from those shown in these procedures to make the Wide Bank work properly in specific installations. See the command descriptions in Chapter 8 for more information about specific commands.

Basic Configuration

- Connecting to the Management Port ... 6-3
- Logging On ... 6-4
- Working Configurations ... 6-4
- Saving a Temporary Copy of Configuration ... 6-5
- Restoring a Temporarily Saved Configuration ... 6-5
- Saving the Configuration to a User File System ... 6-5
- Restoring Saved Configuration from User File System ... 6-5
- Restoring Factory Defaults ... 6-6
- Validating Equipment ... 6-6
- Setting the Time and Date ... 6-7
- Setting System Security, Users, and Login Passwords (Basic Security) ... 6-7
- Setting System Security, Users, and Login Passwords (Security Upgrade Option) ... 6-10
- Configuring IP and PPP Addresses ... 6-15
- Configuring DS3 ... 6-17
- Configuring Low-Speed Ports ... 6-19
- Turning Off Unused or Unterminated Low-Speed Channels ... 6-22
- Logging Off ... 6-22

Connecting to the Management Port

This procedure assumes that a terminal (or PC with terminal-emulation software) is connected to the RS-232 Management Port on the connector panel of the Wide Bank. The Wide Bank's RS-232 port is a DCE port with DB9 Female connector.

Set terminal program for:

- 9600 baud
- 8 data bits
- No stop bits
- 1 parity bit
- No flow control

Note that when you are using the Command Line Interface for the following procedures, the screen will often stop with a final prompt of "more." This means that all the information has not yet been printed to the screen. You can view the rest of the information by:

- Pressing Enter key to display the next line
- Pressing Space Bar to display the next page of information

You can also change the number of lines that are displayed using the `screen [n]` command where *n* is the desired number of lines to display. A `screen 0` command will cause all information to be printed to the screen without stopping.




Figure 6-1 RS-232 Management Connection

Logging On

The Wide Bank is shipped with password protection disabled (*security off*). You can enable password protection to prevent unauthorized access. See *Setting System Security, Users, and Login Passwords (Basic Security)* on page 6-7 or *Setting System Security, Users, and Login Passwords (Security Upgrade Option)* on page 6-10.

To log in with security off, simply press Enter key. If you are logging in via a Telnet session, login is automatic when the connection is made.

System Response to a successful login request:

Table 6-1 CLI Login Displays for Different LS Modes

CLI in DS1 or DS1LS Mode Low-Speed Mode is DS1 ("ds1" commands) or Low-Speed Mode is DS1 ("ls" commands)	CLI in E1LS Mode Low-Speed Mode is E1 ("ls" commands)
<pre>14:08:34 05/26/2001 Automatic Login to Controller Card A Equipment Status ----- -</pre>	<pre>14:08:34 05/26/2001 Automatic Login to Controller Card A Equipment Status ----- -</pre>
<pre>DS3 Controller A Active DS3 Controller B Standby DS1 Card 1 Active DS1 Card 2 Active DS1 Card 3 Active DS1 Card 4 Active DS1 Card 5 Active DS1 Card 6 Active DS1 Card 7 Active DS1 Spare Card Active</pre>	<pre>DS3 Controller A Active DS3 Controller B Standby E1 Card 1 Active E1 Card 2 Active E1 Card 3 Active E1 Card 4 Active E1 Card 5 Active E1 Card 6 Active E1 Card 7 Active E1 Spare Card Active</pre>

Working Configurations

All working configurations are saved in non-volatile memory. Whenever changes are made to the working configuration by issuing any configuration command, the changes are automatically and immediately saved in non-volatile memory. Changes are also copied to the standby Controller's non-volatile memory if Autocopy is on. If Autocopy is off, use the *copy* command to copy the entire configuration to the standby Controller.

There is no command that can undo a configuration change. However, a temporary copy of the current configuration can be saved with the *temp copy* command. This copy of the configuration can be retrieved using the *restore temp copy* command, as long as power has not been cycled.

Another way to preserve the current configuration is to use the *save tftp* command, which saves a snapshot of the configuration in a file system on your network using TFTP. This copy of the configuration will not be destroyed by cycling power. The file can be retrieved using a *restore tftp* command. See the *save* command and the *restore* command in Chapter 9.

Saving a Temporary Copy of Configuration

Use the *temp copy* command to place a temporary copy of the working configuration in volatile storage, to be restored if the working copy becomes corrupted. One use for this command is when you are changing the working configuration and want to easily return to the original configuration if your changes do not work.

To save a copy of the configuration:

```
(A:Active)> temp copy
```

All current settings have been temporarily copied to RAM.

NOTE: This temporary copy, because it is in volatile storage, will be lost whenever power is turned off. This temporary copy, saved by the *temp copy* command, should not be considered a true backup copy. The working configuration and the factory defaults are the only configurations that will survive a power cycle, because they are retained in non-volatile memory.

Restoring a Temporarily Saved Configuration

Use a *restore temp copy* command to replace the current working configuration with the temporary configuration previously saved using a *temp copy* command. If no *temp copy* command was previously issued, or if power was lost, there will be no temporary configuration to load.

Saving the Configuration to a User File System

NOTE: Saving the configuration to a user file system, as well as restoring the configuration requires that a TFTP server be running on the computer identified by the "ipaddr" parameter of the save command.

A more secure copy of the working configuration can be saved to a user file system using TFTP, as mentioned under Working Configuration. The *save tftp ipaddr "filename"* (include quotes) command will save a copy of the working configuration with the specified file name on the computer having the IP address stated in the command.

```
(A:Active)> save tftp ipaddr "filename"
```

Restoring Saved Configuration from User File System

If you have previously saved a copy of the configuration using the *save tftp* command, the file can be retrieved using the *restore tftp ipaddr "filename"* command (see *restore* command in Chapter 9). The IP address and the filename string must match the ones used in the save command. The file you receive is essentially a list of valid CLI commands that will set up the Wide Bank configuration to match the snapshot.

```
(A:Active)> restore tftp ipaddr "filename"
```

Restoring Factory Defaults

The working configuration can be replaced with the original factory defaults by using the *restore defaults* command. Both the working configuration and the factory defaults are stored in non-volatile storage and are retained when power is turned off.

One use for the *restore defaults* command is to re-configure the Wide Bank when the working configuration is lost or corrupted and there is no temporary copy to restore.

To restore the configuration to the factory default settings, enter the following command.

```
(A:Active)> restore defaults
```

Factory default settings are now restored.

Validating Equipment

Validate that all the required interfaces are present. The *equipment* command lists all the low-speed and DS3 cards and shows their status. If the LS mode does not match the card type that is installed, comments in the low-speed status will say “Wrong card for LS mode.”

Table 6-2 CLI Equipment Displays for Different LS Modes

CLI in DS1 or DS1LS Mode Low-Speed Mode is DS1 ("ds1" commands) or Low-Speed Mode is DS1 ("ls" commands)	CLI in E1LS Mode Low-Speed Mode is E1 ("ls" commands)
<pre>(A:Active)> equipment Equipment Status ----- -</pre> <pre>DS3 Controller A Active DS3 Controller B Standby DS1 Card 1 Active DS1 Card 2 Active DS1 Card 3 MSO Active DS1 Card 4 Active DS1 Card 5 Active DS1 Card 6 Active DS1 Card 7 Active DS1 Spare Card Card not present</pre>	<pre>(A:Active)> equipment Equipment Status ----- -</pre> <pre>DS3 Controller A Active DS3 Controller B Standby E1 Card 1 Active E1 Card 2 Active E1 Card 3 MSO Active E1 Card 4 Active E1 Card 5 Active E1 Card 6 Active E1 Card 7 Active E1 Spare Card Card not present</pre>

Setting the Time and Date

Although the working configuration is retained when power is turned off, the system clock time and system date are lost. To set the time and date:

Set System Time

```
(A:Active)> time

The time is 16:01:20 10/01/2001

(A:Active)> time 16:20:00

The time is 16:20:00 10/01/2001
```

Set System Date

```
(A:Active)> date 10/24/2001

The time is 16:21:33 10/24/2001
```

Setting System Security, Users, and Login Passwords (Basic Security)

All configurations of the Wide Bank support a multiple-level user and password security system for the CLI. With this basic security system, each user is assigned an access level and, optionally, a password. The access level limits the user to operate with a specific set of commands. Enhanced security, available as the "Security Upgrade" option, provides additional security features. If your Wide Bank has the Security Upgrade option, see *Setting System Security, Users, and Login Passwords (Security Upgrade Option)* on page 6-10.

See the following sections for information about security tasks:

- Access Levels (Basic Security) ... 6-8
- Password Protection (Basic Security) ... 6-8
- Display Current Security Status (Basic Security) ... 6-9
- Change the Security Status (Basic Security) ... 6-9
- Add a User (Basic Security) ... 6-9
- Assign or Change a User's Password (Basic Security) ... 6-9
- Set a User's Access Level (Basic Security) ... 6-9
- Delete a User (Basic Security) ... 6-9
- Show Current User Settings (Basic Security) ... 6-9

Access Levels (Basic Security)

With basic security, there are three access levels available for CLI users:

- **admin** – The *admin* user has access to all commands and has the sole authority to grant others access to the system by adding and deleting user names and passwords. There can be only one *admin* user (always named "admin") within the system.
- **rw (read/write)** – An *rw* user has access to all commands except those for adding users, deleting users, and setting user levels. The *rw* users are typically responsible for the day-to-day operation of the system.
- **ro (read only)** – An *ro* user is limited to commands that display status and reports. The *ro* access level permits technicians to monitor system operation and performance, but prevents them from altering settings.

Password Protection (Basic Security)

The Wide Bank is shipped with password protection disabled (*security off*). You may choose to enable password protection (*security on*) and set passwords for users to prevent unauthorized system access.

With security off, login is accomplished simply by pressing the Enter key. No password is required, and the user is considered to be at the *admin* level.

If security is on, and passwords have been assigned, login requires that you type a user name and password when prompted. Users are permitted to modify their own passwords, if desired. If passwords have not been assigned for users, a user name is required but no password is requested.

NOTE: With basic security, user names must include from 1 to 10 alphanumeric characters and must not contain spaces. User names are not case-sensitive when defined; however, users must log in using lower-case characters.

Passwords can be from 1 to 10 alphanumeric characters and are case-sensitive. Spaces and special characters are not allowed. Up to 32 characters may be entered but only the first 10 will be used. Passwords can also be blank (not requested at login).

NOTE: When security is on and the user *admin* is logged in, turning security off logs off the user *admin*. Similarly, turning security on automatically logs in the user *admin*.

Security integrity is provided by denying access if a user name or password is entered incorrectly. After three consecutive unsuccessful login attempts, the login prompt will not appear for 10 seconds, and an SNMP trap (cliLoginFailureTrap) is sent to the Network Management System (NMS). After the 10-second delay, the prompt will reappear and another login attempt can be made. This three-attempt rule applies to both RS-232 and Telnet sessions but a Telnet session will be disconnected after three unsuccessful attempts, requiring reconnection after a 10-second delay.

Display Current Security Status (Basic Security)

```
(A:Active)> security
security    off
```

Change the Security Status (Basic Security)

```
(A:Active)> security on
security    on
```

Add a User (Basic Security)

```
(A:Active)> user "bill" add
Successfully added new user "bill"
```

See *USER* on page 8-82 for user name restrictions.

Assign or Change a User's Password (Basic Security)

```
(A:Active)> user "bill" password
New password: ****
Confirm new password: ****
New password accepted
```

See *USER* on page 8-82 for password restrictions.

Set a User's Access Level (Basic Security)

```
(A:Active)> user "bill" level rw
Successfully set "bill"'s access level to rw
```

Delete a User (Basic Security)

NOTE: The *admin* user cannot be deleted.

```
(A:Active)> user "bill" delete
Successfully deleted user "bill"
```

Show Current User Settings (Basic Security)

```
(A:Active)> user

User          Level      Last Login
----          -
admin         admin     11:39:36 06/23/2004 (Active)
bill          rw        11:02:52 06/23/2004
marie         rw        Never logged in
morgan        ro        11:39:14 06/23/2004
```

When security is on, the currently logged-on user is indicated as (Active).

Setting System Security, Users, and Login Passwords (Security Upgrade Option)

If the Wide Bank is configured with the Security Upgrade option, enhanced security features are available, including an additional user access level and the ability to disable user interfaces. As with basic security (described in the previous section), each user can be assigned a user level. Passwords are required for each user.

With the Security Upgrade option, the Wide Bank supports the following enhanced security features:

- Four levels of users – *secu*, *admin*, *rw*, and *ro*
- Restrictions on the number and types of characters allowed in user names and passwords
- The ability to set a time-out value for CLI sessions
- The ability to individually disable the user interface ports: Ethernet port, 9-pin RS-232 CLI port, and 25-pin RS-232 TL1 port
- The ability to disable SNMP management
- The ability to disable TL1 management

See the following sections for information about security tasks:

- Access Levels (Security Upgrade Option) ... 6-11
- Password Protection (Security Upgrade Option) ... 6-11
- User Interface Access (Security Upgrade Option) ... 6-12
- Display Current Security Status (Security Upgrade Option) ... 6-13
- Change the Security Status (Security Upgrade Option) ... 6-13
- Add a User and Assign a Password (Security Upgrade Option) ... 6-13
- Change a User's Password (Security Upgrade Option) ... 6-13
- Set a User's Access Level (Security Upgrade Option) ... 6-13
- Delete a User (Security Upgrade Option) ... 6-13
- Show Current User Settings (Security Upgrade Option) ... 6-14
- Set CLI Time-Out (Security Upgrade Option) ... 6-14
- Disable Ethernet Port (Security Upgrade Option) ... 6-14
- Disable 9-Pin RS-232 CLI Port (Security Upgrade Option) ... 6-14
- Disable 25-Pin RS-232 TL1 Port (Security Upgrade Option) ... 6-14
- Disable SNMP Management (Security Upgrade Option) ... 6-15
- Disable TL1 Management (Security Upgrade Option) ... 6-15

Access Levels (Security Upgrade Option)

With the Security Upgrade option, there are four access levels available for CLI users:

- **secu** – The *secu* user has access to all commands and has the sole authority to grant others access to the system by adding and deleting user names and passwords. The *secu* user also has sole authority to perform such functions as clearing all statistics and logs, configuring IP settings, restoring factory default or previously saved configurations, and configuring the TL1 interface. There can be only one *secu* user (always named "security") within the system.
- **admin** – An *admin* user has access to all commands except those assigned exclusively to the *secu* user. Functions available to the *admin* user that are not available to lower-level users include clearing DS1 and DS3 statistics, copying a configuration from the active to standby Controller, setting the system time and date, programming the flash memory, saving a configuration to a TFTP server file, setting various security functions, configuring SNMP, and copying the current configuration to temporary storage.
- **rw (read/write)** – An *rw* user has access to all commands except those assigned exclusively to the *secu* and *admin* users. The *rw* users are typically responsible for the day-to-day operation of the system.
- **ro (read only)** – An *ro* user is limited to commands that display status and reports. The *ro* access level permits technicians to monitor system operation and performance, but prevents them from altering settings.

Password Protection (Security Upgrade Option)

Wide Banks equipped with the Security Upgrade option are shipped with password protection disabled (*security off*). You may choose to enable password protection (*security on*) and set passwords for users to prevent unauthorized system access.

With security off, login is accomplished simply by pressing the Enter key. No password is required, and the user is considered to be *secu*.

If security is on, login requires that you type a user name and password when prompted. Only the *secu* user may modify passwords.

NOTE: With the Security Upgrade option, user names must include from 8 to 10 alphanumeric characters and must not contain spaces. User names are case-sensitive.

Passwords must be from 8 to 10 characters and are case-sensitive. Passwords must contain at least one each of the following types of characters: upper-case alphabetic, lower-case alphabetic, numeric, and special characters. The permitted special characters are listed with the *user* command (see *USER* on page 8-82).

If you are upgrading firmware in an existing Wide Bank, previously defined user names and passwords that contain fewer than 8 characters will be preserved. Blank passwords are also preserved.

NOTE: When security is on and the user *secu* is logged in, turning security off logs off the user *secu*. Similarly, turning security on automatically logs in the user *secu*.

Security integrity is provided by denying access if a user name or password is entered incorrectly. After three consecutive unsuccessful login attempts, the login prompt will not appear for 10 seconds, and an SNMP trap (*cliLoginFailureTrap*) is sent to the Network Management System (NMS). After the 10-second delay, the prompt will reappear and another login attempt can be made. This three-attempt rule applies to both RS-232 and Telnet sessions but a Telnet session will be disconnected after three unsuccessful attempts, requiring reconnection after a 10-second delay.

NOTE: Whenever a user logs in or out of the CLI interface or the TL1 interface, an event is recorded in the event log. The log entry indicates the name of the user that logged in or out.

User Interface Access (Security Upgrade Option)

With the Wide Bank's Security Upgrade option, you can selectively disable the following user interfaces to prevent unauthorized access:

- **Ethernet port** – Prevents SNMP, TCP/IP TL1, and Telnet sessions over the Ethernet port.
- **9-pin RS-232 CLI port** – Prevents CLI sessions over the RS-232 CLI port.
- **25-pin RS-232 TL1 port** – Prevents TL1 sessions over the RS-232 TL1 port.
- **SNMP management** – Prevents SNMP sessions over the Ethernet port and over the DS3 C-bit PPP data link.
- **TL1 management** – Prevents TL1 sessions over the 25-pin RS-232 TL1 port, over the Ethernet port, and over the DS3 C-bit PPP data link.

The Ethernet port and RS-232 CLI port cannot both be disabled. One of these ports must remain active to provide CLI management access. If you disable the RS-232 port, you must first assign a valid IP address to the Wide Bank for Ethernet access (cannot be null, 0.0.0.0, or 255.255.255.255). For information about setting the IP address, see *Configuring IP and PPP Addresses* on [page 6-15](#).

If you disable SNMP management, SNMP sessions are disabled over the Ethernet port and the DS3 C-bit PPP data link. If you disable TL1 management, TL1 is disabled over the 25-pin RS-232 TL1 port, the Ethernet port, and the DS3 C-bit PPP data link. In a PPP remote management configuration, a local Wide Bank is connected via DS3 to a remote Wide Bank. The local Wide Bank can route messages originating from the Ethernet channel to the remote Wide Bank over the C-bit link. The remote Wide Bank responds over the C-bit link to the local Wide Bank which then routes the responses back over its Ethernet channel. Disabling SNMP or TL1 in the local Wide Bank does not prevent SNMP or TL1 sessions over the C-bit link to the remote Wide Bank. To prevent SNMP or TL1 sessions to the remote Wide Bank via the C-bit link, these interfaces must be disabled for the remote Wide Bank as well.

Display Current Security Status (Security Upgrade Option)

```
(A:Active)> security
security    off
```

Change the Security Status (Security Upgrade Option)

```
(A:Active)> security on
security    on
```

Add a User and Assign a Password (Security Upgrade Option)

```
(A:Active)> user "bill" add
New password: *****
Confirm new password: *****
New password accepted

Successfully added new user "bill"
```

See *USER* on [page 8-82](#) for user name and password restrictions.

Change a User's Password (Security Upgrade Option)

```
(A:Active)> user "bill" password
New password: *****
Confirm new password: *****
New password accepted
```

See *USER* on [page 8-82](#) for password restrictions.

Set a User's Access Level (Security Upgrade Option)

```
(A:Active)> user "bill" level rw
Successfully set "bill"'s access level to rw
```

Delete a User (Security Upgrade Option)

NOTE: The *secu* user cannot be deleted.

```
(A:Active)> user "bill" delete
Successfully deleted user "bill"
```

Show Current User Settings (Security Upgrade Option)

(A:Active)> **user**

User	Level	Last Login
----	-----	-----
security	secu	11:39:36 06/23/2004 (Active)
john	admin	11:39:36 06/23/2004
bill	rw	11:02:52 06/23/2004
marie	rw	Never logged in
jack	ro	Never logged in
morgan	ro	11:39:14 06/23/2004

When security is on, the currently logged-on user is indicated as (Active).

Set CLI Time-Out (Security Upgrade Option)

(A:Active)> **security cli 30**
CLI timeout = 30 minutes

Disable Ethernet Port (Security Upgrade Option)

(A:Active)> **security ethernet disable**
Disabling this port will affect the ability to remotely manage this unit. It will not be possible to remotely manage this unit on IP Address *nnn.nnn.nnn.nnn*

Do you want to disable the Ethernet port now (y/n)?

nnn.nnn.nnn.nnn is the Wide Bank's IP address. Remote management will no longer be possible over this address.

Disable 9-Pin RS-232 CLI Port (Security Upgrade Option)

(A:Active)> **security rs232cli disable**
Disabling this port will disable the ability to locally manage this unit. Remote management will be possible on IP Address *nnn.nnn.nnn.nnn*

Do you want to disable the CLI port now (y/n)?

nnn.nnn.nnn.nnn is the Wide Bank's IP address. Before disabling the CLI port, you must assign a valid IP address. See *Configuring IP and PPP Addresses* on [page 6-15](#).

Disable 25-Pin RS-232 TL1 Port (Security Upgrade Option)

(A:Active)> **security rs232tl1 disable**
TL1 RS-232 port disabled

Disable SNMP Management (Security Upgrade Option)

```
(A:Active)> security snmp disable
SNMP feature disabled
```

Disable TL1 Management (Security Upgrade Option)

```
(A:Active)> security t11 disable
TL1 feature disabled
```

Configuring IP and PPP Addresses

The Wide Bank includes SNMP and Telnet support. Before they can be used, the following network settings must be configured. These settings are not necessary if you do not want to use SNMP or Telnet.

The following example represents a response while in C-bit framing mode. If the Wide Bank is not in C-bit framing mode, the *ip ppp* and *ip route ppp|ethernet* items are not available.

```
(A:Active)> ip
ip      address 192.168.2.40
ip      mask   255.255.255.0
ip      gateway 192.168.2.202
ip      nms1   192.168.0.4
ip      nms2   206.168.118.70
ip      nms3
ip      ppp    192.168.5.10
ip      route  ethernet
```

```
(A:Active)> ip address 192.168.0.5
Modifying IP address will affect ability to remotely manage this unit.
The IP address for remote management will be 192.168.0.5
Do you want to update the IP address now (y/n)?
```

(First IP Address of the active controller)

```
(A:Active)> ip mask 255.255.255.0
(Subnet mask for LAN)
```

```
(A:Active)> ip gateway 192.168.0.1
(IP Address for the LAN gateway)
```

```
(A:Active)> ip nms1 192.168.0.3
(IP Address for SNMP Trap notification)
```

```
(A:Active)> ip nms2 192.168.0.4
(Second IP Address for SNMP Trap notification)
```

```
(A:Active)> ip nms3 192.168.0.5
  (Third IP Address for SNMP Trap notification)

(A:Active)> ip ppp 192.168.0.6
  (IP Address for far end of the PPP link - DS3 C-bit framing
  only)

(A:Active)> ip route ethernet
  (Set route for outbound IP traffic: ppp or ethernet. Ethernet
  is the default. DS3 C-bit framing is only for ppp route.)
```

Verify Network Settings

```
(A:Active)> ip

ip      address 192.168.0.5
ip      mask   255.255.255.0
ip      gateway 192.168.0.1
ip      nms1   192.168.0.3
ip      nms2   192.168.0.4
ip      nms3   192.168.0.5
ip      ppp    192.168.0.6
ip      route  ethernet
```




Figure 6-2 IP Routing with Point-to-Point Protocol

IP Routing With Point-to-Point Protocol (PPP)

PPP routing provides an IP connection over the DS3 C-bit data link that can be used for management instead of the Ethernet port. For example, a local (near end) Wide Bank configured with an IP PPP setting will route any IP packets destined for the PPP address along the C-bit PPP data link to the remote (far end) Wide Bank 28 DS3. The near-end Wide Bank will also handle routing of upstream IP traffic from the far-end Wide Bank 28 DS3.

IP over PPP Applications

These IP applications will function over the PPP link:

- TFTP
- SNMP
- TELNET
- PING
- TL1

Configuring DS3

The following command (the ds3 command without parameters) displays the DS3 configuration settings. For details and parameters for the ds3 command, see Chapter 8. The following examples show the difference between M23 framing and C-bit framing.

CAUTION! IT IS STRONGLY RECOMMENDED THAT THE DS3 CLOCK SOURCE BE SET TO "INTERNAL" TIMING. THE WIDE BANK 28 DS3 IS AN ASYNCHRONOUS MULTIPLEXER. ASYNCHRONOUS COMMUNICATIONS DO NOT REQUIRE A COMMON CLOCK BETWEEN THE COMMUNICATING DEVICES. CHANGING THE CLOCK SOURCE TO "LINE" CAN DISRUPT SERVICE AND CAUSE DS1 TIMING SLIPS.

The following example shows the response when configured for M23 framing.

```
(A:Active)> ds3

- DS3
  ds3      circuitid "steve"
  ds3      clock int
  ds3      clockrevert on
  ds3      equipment off
  ds3      framing m23
  ds3      length short
  ds3      line off
  ds3      loopdetect off
  ds3      payload off
  ds3      send off
  ds3      threshold off
```

```
ds3 pm lcv thresholds
  min15      0
  hour       0
  day        1
```

The following example shows the response when configured for C-bit framing.

```
(A:Active)> ds3
```

```
- DS3
  ds3   circuitid "DS3"
  ds3   clock int
  ds3   clockrevert on
  ds3   equipmentid "DS3 Equip."
  ds3   equipment off
  ds3   facilityid "DS3 Path"
  ds3   frameid "Frame"
  ds3   framing cbit
  ds3   gennumber "DS3 Test Generator"
  ds3   length short
  ds3   line off
  ds3   locationid "DS3 Loc."
  ds3   loopdetect off
  ds3   payload off
  ds3   portnumber "DS3 Idle Port"
  ds3   send off
  ds3   threshold off
  ds3   unit "000000"
Performance Thresholds:      15 min.      1 hour      1 day
-----
coding violations - line:      0          0          0
errored seconds - line:      0          0          0
coding viols-path p-bit:     0          0          0
err seconds - path p-bit:    0          0          0
loss of signal secs - line:  0          0          0
sev err seconds - line:     0          0          0
sev err sec - path cp-bit:   0          0          0
```

Configuring Low-Speed Ports

There are two forms of DS1 line coding supported on the Wide Bank: B8ZS and AMI. You can configure to either form, as shown below using AMI as an example.

NOTE: There is only one line-coding for E1: HDB3. When E1 cards are installed in the Wide Bank 28 DS3 and the CLI is set for E1LS mode (see the *lsmode* command), the following DS1 references are changed to E1.

```
(A:Active)> ds1 5
The DS1 channel # is: 5
```

Table 6-3 CLI Low-Speed Displays for Different LS Modes

CLI in DS1 or DS1LS Mode Low-Speed Mode is DS1 ("ds1" commands) or Low-Speed Mode is DS1 ("ls" commands)	CLI in E1LS Mode Low-Speed Mode is E1 ("ls" commands)
<pre>- DS1 5 ds1 5 circuitid "DS1 5" ds1 5 enable ds1 5 equipment off ds1 5 length dsx0 ds1 5 line off ds1 5 linecode ami ds3 5 loopdetect off ds1 5 metallic off ds1 5 send off</pre>	<pre>- LS Circuit 5 e1 13 circuitid "E1 5" e1 13 enable e1 13 equipment off e1 13 line off e1 13 loopdetect off e1 13 metallic off e1 13 send off</pre>

For example, to configure DS1 interface 5 to AMI line coding:

```
(A:Active)> ds1 5 linecode ami
The DS1 channel # is: 5
ds1 5      linecode ami
```

Saving the Configuration

There is no need to manually save the configuration. The Wide Bank retains the working configuration settings in non-volatile storage. If power is lost and regained, the working configuration is always retained.

NOTE: An additional backup of the configuration can be sent to a user file using a *save tftp* command.

NOTE: When E1 cards are installed in the Wide Bank and the CLI is set for E1LS mode, the following DS1 references are changed to E1.

Verify All System Parameters

```
(A:Active)> config

- CONTROLLER

    ds1      protect on
    ds3      protect off
    autocopy      on
    revertive ds3  off
    revertive ds1  off
    arm                on

    ffo      present off

    security      off

    screen 24

    ip      address 192.168.26.44
    ip      mask 255.255.255.0
    ip      gateway 192.168.26.202
    ip      nms1 192.168.41.46
    ip      nms2 192.168.25.212
    ip      nms3
    ip      ppp
    ip      route ethernet

    snmp name      "Name"
    snmp location  "Location"
    snmp contact   "Contact"
    snmp getcomm   "public"
    snmp setcomm   "public"
    snmp trapcomm  "public"

- DS3

    ds3      circuitid "DS3"
    ds3      clock int
    ds3      clockrevert on
    ds3      equipmentid "DS3 Equip."
    ds3      equipment off
    ds3      facilityid "DS3 Path"
    ds3      frameid "Frame"
    ds3      framing cbit
    ds3      gennumber "DS3 Test Generator"
    ds3      length short
    ds3      line off
    ds3      locationid "DS3 Loc."
    ds3      loopdetect off
    ds3      payload off
    ds3      portnumber "DS3 Idle Port"
```

```

ds3          send off
ds3    threshold off
ds3          unit "000000"
Performance Thresholds:    15 min.    1 hour    1 day
-----
coding violations - line:    387      1161     3865
errored seconds - line:    25       75      250
coding viols-path p-bit:    382     1146     3820
err seconds - path p-bit:    25       75      250
loss of signal secs - line:  4        12      40
sev err seconds - line:    4        12      40
sev err sec - path cp-bit:  4        12      40

- 1
  ds1 1  circuitid "DS1#1"
  ds1 1  enable
  ds1 1  equipment off
  ds1 1  length dsx0
  ds1 1  line off
  ds1 1  linecode b8zs
  ds1 1  loopdetect off
  ds1 1  metallic off
  ds1 1  send off
Performance Thresholds:    15 min.    1 hour    1 day
-----
coding violations - line:    13340   40020   133400
errored seconds - line:    65      195     648

  •
  • (Circuits 2 through 27)
  •

- 28
  ds1 28 circuitid "DS1#28"
  ds1 28 enable
  ds1 28 equipment off
  ds1 28 length dsx0
  ds1 28 line off
  ds1 28 linecode b8zs
  ds1 28 loopdetect off
  ds1 28 metallic off
  ds1 28 send off
Performance Thresholds:    15 min.    1 hour    1 day
-----
coding violations - line:    13340   40020   133400
errored seconds - line:    65      195     648

```

Verifying Autocopy to Secondary Controller

With a secondary Controller card installed, and the autocopy feature on (default), the secondary Controller will automatically reflect the same configuration as the primary Controller. The only way to verify that autocopy worked is to switch Controllers and check configurations. If autocopy is off (*autocopy off*), or if you choose to manually copy the configuration, the configuration can be copied to the secondary Controller with a *copy* command. There may be some cases (in protected DS3 installations) when the primary and secondary Controller/DS3 interfaces will not have the same configuration. In these cases, *autocopy* should be turned off (use the command *autocopy off*).

NOTE: The security configuration (user names, access levels, passwords) is always autocopied between Controllers.

Turning Off Unused or Unterminated Low-Speed Channels

For continued FCC Part 15A and NEBS compliance, unused and unterminated low-speed channels must be turned off by issuing the CLI *ds1* or *ls* command:

```
(A:Active)> ds1 [n|range|all] disable
```

or

```
(A:Active)> ls [n|range|all] disable
```

Logging Off

When you have finished configuring the Wide Bank, you can log off with the *exit* command.

```
(A:Active)> exit
```

Logging out

Downloading New Software

- Configurations for Downloading Firmware ... 6-23
- Management Connections for Downloading Firmware ... 6-23
- Protocol Options for Downloading Firmware ... 6-24
- Downloading to a Redundant Wide Bank 28 DS3 ... 6-26
- Downloading to a Non-Redundant Wide Bank 28 DS3 ... 6-32

If your Wide Bank 28 DS3 Controller cards are equipped with FLASH memory, you can download a new level of firmware to your Wide Bank. Usually, units with a serial number of 01898491000 or higher have FLASH capability. The firmware can reside on any TFTP server to which you can connect through the Ethernet, or it can reside on the PC you are using to manage the download. You must know the file name of the new firmware, and if you are downloading through the Ethernet you must know the IP address of the TFTP server on which the firmware resides.

Configurations for Downloading Firmware

A Wide Bank can be physically configured either with one Controller card (non-redundant), or with two Controller cards (redundant). How your Wide Bank is configured will affect the downloading process, as well as the continuous processing of traffic.

Downloading Firmware to a non-redundant Wide Bank will cause a short interruption of service (up to 90 seconds) when the system resets after FLASH is re-programmed. Downloading firmware to a redundant Wide Bank, when successful, will cause no interruption of service.

The effects to the downloading process are explained in the following procedures.

Management Connections for Downloading Firmware

The options for managing the download are:

- Figure 6-3A: A PC, running terminal emulation (HyperTerminal, for example), connected to the RS-232 port on the Wide Bank. The settings are 9600, 8 bits, no parity, 1 stop bit.
- Figure 6-3B: A VT100 terminal connected to the RS-232 port on the Wide Bank to control a download over an Ethernet connection, and the Ethernet port on the Wide Bank connected to the Ethernet. With this connection, the new firmware must reside on a TFTP server connected to the Ethernet.
- Figure 6-3C: A Telnet session, connected to the Ethernet, and the Ethernet port on the Wide Bank connected to an IP network. The TFTP server on which the new level of firmware resides must be reachable through an IP network as well, and you must know the IP addresses for both the Wide Bank and the server.

Configuration

Downloading New Software

- Figure 6-3C: A NetworkValet management session connected to the Ethernet, and the Ethernet port on the unit connected to an IP network. The TFTP server on which the new level of firmware resides must be reachable through an IP network as well, and you must know the IP addresses for both the Wide Bank and the server.
- An SNMP session connected to the Ethernet, and the Ethernet port on the Wide Bank connected to an IP network. A TFTP download is initiated via SNMP using the enterprise MIB.
- An SNMP or Telnet session operating via the DS3 PPP link. The PPP link must be active and the device on the other end of the PPP link must be connected to an IP network.

Protocol Options for Downloading Firmware

The protocol options for downloading software are:

- Xmodem protocol: This protocol can be used when the management PC is connected to the RS-232 port of the unit (Figure 6-3A) and the new control code resides on the same (management) PC.
- Trivial File Transfer Protocol (TFTP): This protocol can be used when the management PC is connected to either the RS-232 port in which file transfer occurs over the Ethernet port (Figure 6-3B) or is connected with a Telnet session through the Ethernet port (Figure 6-3C). There must be a TFTP server that can store and transfer the new control code. The TFTP protocol is usually faster than the Xmodem protocol.





Figure 6-3 Downloading Software to the Wide Bank 28 DS3

Downloading to a Redundant Wide Bank 28 DS3

This procedure applies when you are using TFTP to download, invoked either through the RS-232 port or by Telnet session through the Ethernet port. Connect a PC or terminal as described in *Connecting to the Management Port on page 6-3*.

Figure 6-4 shows the state of the Wide Bank before any action is taken to initiate a TFTP download. Controller A is in control and is handling all traffic.

NOTE: Make sure there are no existing error or alarm conditions on the unit before you proceed. Ensure that revertive is turned off (*revertive ds3 off*) before initiating any downloads. A revertive switch while downloading a file will abort a download.



Before the load command is invoked, Controller A has control and is carrying all traffic.


Figure 6-4 Normal Operation of Wide Bank

1. Log in to the Wide Bank.
2. At the prompt, enter the `load` command, as follows (Be sure to include the quotes in the filename, and give the complete path):

```
(A:Active)> load tftp [TFTP server IP address] "[filename]"
```

```
Initializing memory buffer...  
Downloading Image using TFTP. Please wait...  
TFTP Download Finished Verifying. Please wait...  
Verification Successful
```

Load Command causes new code to be downloaded to Controller A memory



Controller A maintains control and still handles all traffic

Figure 6-5 Downloading Code to Controller A RAM

```
Do you want to Program the FLASH now (y/n)?
```

3. Enter **Y**.

```
Please wait until this controller comes alive (approximately  
1 minute).  
Switching control to Standby Controller
```




Figure 6-6 Re-Programming the FLASH on Controller A

NOTE: If you are using a Telnet session, it will be closed here. Re-establish the Telnet session on Controller B to continue.

The Wide Bank initiates a switch of Controllers, then executes the commands necessary to cause the firmware just downloaded to RAM to be programmed into the FLASH on the board that used to be active (Controller card A) (see Figure 6-6). During this programming, the traffic is carried by the secondary Controller card (B), which is now active. After the download is complete (approximately one minute), press Enter key to initiate a log-in to Controller card B.

NOTE: When the CLI is in E1LS mode, the following low-speed circuit references are changed to E1 instead of DS1.

4. Press Enter key (now talking to Controller card B).

```
01:00:29 01/01/1997
```

```
Automatic Login to Controller Card B
```


```
Equipment          Status
-----
DS3 Controller A   Standby
DS3 Controller B   Active
DS1 Card 1         Active
DS1 Card 2         Active
DS1 Card 3         Active
DS1 Card 4         Active
DS1 Card 5         Active
DS1 Card 6         Active
DS1 Card 7         Active
DS1 Spare Card     Card not present
```

```
(B:Active)>
```

5. Type the *load* command again and enter the following command (Be sure to include the quotes in the filename, and give the complete path):

```
(B:Active)> load tftp [TFTP server IP address] "[filename]"
```

```
Initializing memory buffer.Downloading Image using TFTP.
Please wait...
TFTP Download Finished
Verifying. Please wait...
Verification Successful
```



Controller B maintains control and still handles all traffic.


Figure 6-7 Downloading Code to Controller B RAM

Do you want to Program the FLASH now (Y/N)?

6. Enter **Y**.

Please wait until this card comes alive (approximately 1 minute).
Switching control to Standby Controller and closing Telnet session
Please re-establish Telnet session

The Wide Bank again initiates a switch of Controllers, drops the Telnet connection, then executes the commands necessary to cause the firmware just downloaded to RAM to be programmed into the FLASH on the board that used to be active (Controller card B). During this programming, the traffic is carried by the primary Controller card (A), which is now active and running the new code. After the download is completed, log in to Controller card A.



Entering YES (y) causes control and traffic to be switched to Controller card A **(1)**, then the new code is burned into FLASH on Controller card B **(2)**.

Figure 6-8 Reprogramming FLASH on Controller B

7. Press Enter key to log in to Controller A and continue.

```
01:00:29  01/01/1997
```

```
Automatic Login to Controller Card A
```

Equipment	Status
-----	-----
DS3 Controller A	Active
DS3 Controller B	Standby
DS1 Card 1	Active
DS1 Card 2	Active
DS1 Card 3	Active
DS1 Card 4	Active
DS1 Card 5	Active
DS1 Card 6	Active
DS1 Card 7	Active
DS1 Spare Card	Card not present

Downloading to a Non-Redundant Wide Bank 28 DS3

Connect a PC or terminal as described in *Management Connections for Downloading Firmware on page 6-23*

- Xmodem Download Initiated Via RS-232 ... 6-32
- TFTP Download Initiated Via RS-232 or Ethernet ... 6-35

NOTE: Make sure there are no existing error or alarm conditions on the unit before you proceed.

Xmodem Download Initiated Via RS-232

The following procedure assumes you are using MS HyperTerminal to perform the download.

NOTE: When the CLI is in E1LS mode, the following low-speed circuit references are changed to E1 instead of DS1.

1. Log in as usual:

```
16:51:49 01/01/1997
```

```
Automatic Login to Controller Card A
```


Equipment	Status
-----	-----
DS3 Controller A	Active
DS3 Controller B	Card not present
DS1 Card 1	Active
DS1 Card 2	Active
DS1 Card 3	Active
DS1 Card 4	Active
DS1 Card 5	Active
DS1 Card 6	Active
DS1 Card 7	Active
DS1 Spare Card	Active

```
(A:Active)>
```


2. Type the command "load xmodem", as follows:

```
(A:Active)> load xmodem  
  
Initializing memory buffer...  
Please Start Xmodem Download...
```

3. From the "Transfer" menu in HyperTerminal, select the option "Send File". The following displays will appear.




4. Type the path and filename you want to download and select Xmodem as the protocol.



Configuration

Downloading New Software

5. Click the "Send" button. The Xmodem transfer will start. The following status displays will appear:



6. When the Xmodem download is completed, the system verifies the validity of the downloaded file and a message is displayed indicating whether the download was successful.
7. A prompt asks if you want to program the FLASH now. If you say no, you will have to do it later, using the *program flash* command. Until you program the FLASH, your Wide Bank will continue to run using the old firmware.

8. Do you want to Program the FLASH now (Y/N)?
9. Enter **Y**.

NOTE: Because there is no secondary (backup) Controller, the following message appears. It warns that an interruption of traffic (up to 90 seconds) will occur.

```
WARNING: Secondary Controller is not present
Programming the FLASH will cause interruption of traffic.
```

```
Do you want to Program the FLASH now (y/n)?
```

10. Enter **Y**.

```
Please wait until this controller comes alive (Approximately 1
min.)
Firmware upgrade in process...
Erasing Flash. Please wait...
Programming Flash. Please wait...
Programming Successful.
```

The system will now reset, during which the DS3 traffic is interrupted for up to 90 seconds.

TFTP Download Initiated Via RS-232 or Ethernet

This procedure applies when you are using TFTP to download, invoked either through the RS-232 port or by Telnet session through the Ethernet port. Connect a PC or terminal as described in *Management Connections for Downloading Firmware on page 6-23*

NOTE: Make sure there are no existing error or alarm conditions on the unit before you proceed.

1. Log in to the Wide Bank.
2. At the prompt, enter the **load** command, as follows (Be sure to include the quotes in the filename, and give the complete path):

```
(A:Active)> load tftp [TFTP server IP address] "[filename]"
```

```
Initializing memory buffer...
Downloading Image using TFTP. Please wait...
TFTP Download Finished
Verifying. Please wait...
Verification Successful
```

Configuration

Downloading New Software

NOTE: A prompt asks if you want to program the FLASH now. If you say no, you will have to do it later, using a *program flash* command. Until you program FLASH your Wide Bank is still running the old firmware.

```
Do you want to Program the FLASH now (Y/N)?
```

3. Enter **Y**.

NOTE: Because there is no secondary (backup) Controller, the following message appears. It warns that an interruption of traffic (up to 90 seconds) will occur.

```
WARNING: Secondary Controller is not present
Programming the FLASH will cause interruption of traffic.
```

```
Do you want to Program the FLASH now (Y/N) ?
```

4. Enter **Y**.

```
Please wait until this controller comes alive (Approximately 1
min.)
```

```
Firmware upgrade in process...
```

```
Erasing Flash. Please wait...
```

```
Programming Flash. Please wait...
```

```
Programming Successful.
```

The system now resets, during which the DS3 traffic is interrupted for up to 90 seconds.

NOTE: If you are using a Telnet session for this download, you will have to re-establish the Telnet session after the reset.

CHAPTER 7

Diagnostics & Troubleshooting


In this Chapter

- LED Test and Status Indicators ... 7-2
- Determining Performance and Status ... 7-7
- General Troubleshooting ... 7-9
- Thermal Shut-Down ... 7-10
- Self-Tests ... 7-11
- Looptests Using Built-in PRBS BERT ... 7-15
- Testing Low-Speed Interface Operation ... 7-18
- Testing DS3 Interfaces ... 7-32
- Testing DS3 Redundancy ... 7-39

LED Test and Status Indicators

- Power LED ... 7-3
- Alarm Cutoff (ACO) LED and Pushbutton ... 7-3
- Critical (CR) Alarms ... 7-4
- Major/Minor (MJ/MN) Alarms ... 7-4
- Controller Status (CS) LED ... 7-5
- High Speed (HS) Line Condition LED ... 7-5
- Low-Speed DS1/E1 Line Status LEDs (one per span) ... 7-6
- Ethernet Status LED ... 7-6

Status LED indicators on the Wide Bank 28 DS3 control panel provide a visual means of identifying system status, high-speed DS3 line condition, and low-speed DS1/E1 line status.



Power LED

There is one Power LED for each of the two Controller cards. Each indicates the status of the power supply on its respective Controller card.



State	Meaning
OFF	-48V failed
GREEN	Power Supply is functional
RED	On-board power supply (5V) failed

Alarm Cutoff (ACO) LED and Pushbutton

There is one alarm cutoff LED and pushbutton switch for each Controller card. Each alarm severity (critical, major, and minor) has its own ACO function, though major and minor alarms share the same relay contacts. When an alarm condition occurs, the active Controller energizes the alarm relays for that alarm severity, providing open or closed contacts on the alarm output connector on the rear connector panel, depending on the alarmout command setting. The connectors can be wired to the facility alarm system to provide audible and visual alarm indications for each alarm severity. See *Alarm Contacts* on [page A-3](#).

You can silence or suppress the current alarm outputs by pressing the ACO pushbutton on the active Controller (the Controller with lit alarm LEDs). This deactivates the currently active alarm relay contacts and lights the ACO LED. However, if a new alarm condition occurs, the ACO function for that alarm severity will be reset and that alarm output will resume. ACO operation is also reset when the alarm condition is cleared.



Color	Description
OFF	Alarms active
YELLOW	Alarms suppressed

Critical (CR) Alarms

A critical alarm means that a traffic-affecting fault exists. Use the state of the Controller Status LED or DS3 Line Condition LED for more information to identify the fault. The faults can be:

- DS3 Loss of Signal
- DS3 Loss of Frame
- DS3 Receive AIS
- DS3 Receive RAI
- Active Card Failure (only in a single card system)

For a detailed description of critical alarms and how they are reported, see *Alarm Reporting on page 12-1*.



State	Meaning
OFF	No Critical Alarms
RED	Traffic-affecting fault exists

Major/Minor (MJ/MN) Alarms

A major/minor alarm means that a fault exists that has a potential to affect traffic, or a redundancy switch occurred. Use the state of the Controller Status LED, DS3 Line Condition LED, Low-Speed Status LED, or the Power LED for more information to identify the fault. For a detailed description of major and minor alarms and how they are reported, see *Alarm Reporting on page 12-1*.



State	Meaning
OFF	No Alarms
YELLOW	Minor Alarms exist
RED	Major Alarms exist

Controller Status (CS) LED

There is a status LED for each Controller. In a protected redundant system with two Controllers, the active (working) Controller status LED is green and the standby (protection) Controller status LED is off.



State	Meaning
GREEN	Normal Operation
RED	Alarm Condition
RED FLASHING	Self-Test Fail
YELLOW	Network Loopback
OFF	Standby

High Speed (HS) Line Condition LED


This LED shows the condition of the high speed DS3 line interface.



State	Meaning
GREEN	Normal Operation
RED	Loss of Signal (LOS)
RED FLASHING	LOF and/or AIS received
YELLOW	RAI Alarm
YELLOW FLASHING	Line Code Violation or Frame Bit Errors

Low-Speed DS1/E1 Line Status LEDs (one per span)

All DS1 and E1 low-speed circuit cards have four LEDs, though E1 cards use only the first three and the fourth remains off. Primary low-speed circuits are numbered 1 through 28, and spares are numbered 1 through 4. When a primary circuit switches to a spare, the primary status LED turns off and the spare LED lights.



State	Meaning
OFF	Off-line
GREEN	Normal Operation
RED	Loss of Signal (LOS) or Metallic Loopback
RED FLASHING	Self Test Fail
YELLOW	Equipment or Line Loopback
YELLOW FLASHING	Line Code Violations

Ethernet Status LED

This LED is located on the rear connector panel.



State	Meaning
OFF	No Link (no power)
GREEN	Link OK (connected)

Determining Performance and Status

- DS3 Far-End Statistics ... 7-7
- DS3 Path Maintenance Data Link ... 7-7
- Point-to-Point Protocol Status ... 7-8

DS3 Far-End Statistics

DS3 far-end statistics are available only when the Wide Bank 28 DS3 is configured for C-bit framing.

The commands that display DS3 far-end statistics, in conformance with RFC 1407 DS3 MIB:

- ***hour ds3far*** – Provides hour statistics for the far-end DS3. Statistics are calculated for Unavailable Seconds, Severely Errored Seconds, Errored Seconds, and Parity Error Count.
- ***day ds3far*** – Provides day statistics for the far-end DS3. Statistics are calculated for Unavailable Seconds, Severely Errored Seconds, Errored Seconds, and Parity Error Count.
- ***status ds3far*** – Provides status information for the far-end DS3, including alarm conditions and characteristic DS3 ID strings. The alarm code can be one of the 11 codes specified in ANSI T1.107.

DS3 Path Maintenance Data Link

DS3 Path Maintenance Data Link is available only when the Wide Bank 28 DS3 is configured for C-bit framing.

The Path Maintenance Data Link is a 28.2-kbps terminal-to-terminal data link embedded in the C-bits. The signal format on this data link comprises messages using a link access procedure on the D-channel (LAPD). The LAPD messages carry DS3 Path Identification, DS3 Idle Signal Identification, and DS3 Test Signal Identification. The specific message formats are as defined in ANSI T1.107. The DS3 Path Identification is the most common message and is sent when the DS3 is carrying traffic, the DS3 Idle Signal Identification is sent when an IDLE signal is sent, and the DS3 Test Signal Identification is sent when a PRBS test signal is sent. The appropriate LAPD message is sent at least once per second. Because these messages consume minimal bandwidth, the unused bandwidth is available for proprietary messaging.

Functional Description of DS3 Path Maintenance Data Link

The three identification messages all contain the following information, which can be set using the *ds3* command:

- Equipment Identification Code – Describes a specific piece of equipment
- Location Identification Code – Describes a specific location

Diagnostics & Troubleshooting

Determining Performance and Status

- Frame Identification Code – Identifies where the equipment is located within a building at a given location
- Unit Code – Identifies the equipment location within a bay
- DS3 Path Identification Facility Identification Code – Identifies a specific DS3 path
- Idle Signal Identification Port Number – Designates the equipment port that initiates the idle signal
- Test Signal Identification Generator Number – Designates the signal generator that initiates the test signal

Point-to-Point Protocol Status

Use the *status ppp* command to retrieve status information for the PPP link. (See the *status* command in Chapter 8.) The following information is available.

- Operational Status
- Connection Speed
- Transmit Status
- Receive Status

General Troubleshooting

Use the functional block diagram below for general troubleshooting. The following sections provide tests to aid in fault isolation.




Figure 7-1 General Troubleshooting Diagram

Thermal Shut-Down

The Wide Bank is designed for continuous operation at ambient temperatures up to 104 °F (40 °C) and for short-term operation at ambient temperatures up to 131 °F (55 °C).

At higher ambient temperatures, the Wide Bank uses internal thermal protectors to automatically shut down operation before any damage occurs. Prior to shutdown, the Wide Bank will issue an over temperature alarm to notify the network of an impending thermal shutdown. The Wide Bank will remain shutdown until the temperature inside the unit falls below 158 °F (70 °C), then it will automatically reset and resume normal operation.

If thermal shutdown occurs, do the following:

- Ensure that –48 VDC power is supplied to both the A and B power inputs when redundant Controller cards are installed. (With only one input, the powered Controller must deliver twice as much power, making its power converter operate at a higher temperature.)
- Verify that the Wide Bank is properly ventilated to allow for heat dissipation. (Non-FFO equipped units require free air space between units for ventilation.)
- Reduce the ambient temperature if necessary.

Self-Tests

- Low-Speed Circuit Self-Test ... 7-11
- Low-Speed Card Self-Test ... 7-12
- DS3 Card Self-Test ... 7-12
- FFO Test and Monitoring ... 7-13
- Complete Self-Test (Power-Up Test) ... 7-14

Low-Speed Circuit Self-Test

NOTE: When the selected CLI mode is either DS1LS or E1LS, the *test ds1* command becomes the *test ls* command. The operation of the *test ls* command is identical to the *test ds1* command, except the references to the circuits are changed to either LS, DS1, or E1.

Use this test for each low-speed circuit, including the four spares. See Figure 7-2.

```
(A:Active)> test ds1 7
This will interrupt traffic. Continue (Y/N)? Y
Testing DS1 7 ...
ds1 7          Self Test: pass
```

Alternatively, you can test all the circuits on the seven low-speed cards and the spare card:

```
(A:Active)> test ds1 all

WARNING: This command affects service. Continue? [y|n]? y
Testing DS1 1-28 and Spare 1-4...

DS1 1          Self Test: Pass
DS1 2          Self Test: Pass
DS1 3          Self Test: Pass
.
.
.
DS1 28         Self Test: Pass
Spare 1        Self Test: Pass
Spare 2        Self Test: Pass
Spare 3        Self Test: Pass
Spare 4        Self Test: Pass
```

The DS1/E1 Test

1. Sends AIS toward DS1/E1.
2. Performs internal self-test on low-speed DS1/E1 circuits.
3. Loops unframed PRBS test signal through ASIC on high-speed card.




Figure 7-2 Low-Speed Circuit Self-Test

Low-Speed Card Self-Test

This performs the preceding low-speed circuit self-test on all four DS1 (or three E1) circuits on a low-speed card.

```
(A:Active)> test ds1card 5
This will interrupt traffic. Continue (y/n)? Y
Testing DS1 card 5 ...
```

DS3 Card Self-Test

```
(A:Active)> test ds3
This will interrupt traffic. Continue (Y/N)? Y
Testing DS3 ...
DS3 Self Test: pass
```

The DS3 Test

1. Sends AIS toward DS3 and DS1/E1.
2. Performs internal self-test on M13 Framer.




Figure 7-3 DS3 Card Self-Test

FFO Test and Monitoring

Fan Faceplate Option (FFO) operation is automatically tested 30 seconds after installation. Also, the FFO can be manually tested with the `test fan [a|b|all]` command. The FFO test applies power to the fans for 30 seconds (there is a five-second delay after power is applied to the first fan until power is applied to the second fan). During the 30-second test the rotation speed of each fan is monitored. If either fan does not rotate at the correct speed, an error is logged, a Fan A and/or Fan B failure alarm is enabled, and the Controller Status LED blinks red. Once a fan failure is detected, the malfunctioning fan remains disabled until a new faceplate is installed.

If the speed of the fans is sufficient to cool the Wide Bank, they pass the self-test and they remain enabled. Each Controller continually monitors the speed of its fan. If either fan is too slow for 30 consecutive seconds, the malfunctioning fan is disabled and a major alarm (Fan A, Fan B, or all Failure) is generated. The alarm remains active until the malfunctioning FFO faceplate is removed. If the configuration for `ffo present` is `on` when the faceplate is removed, and power is on, another major alarm (Fan Faceplate Not Installed) becomes active. Alarms will clear when the faceplate is re-installed.

To prevent the Fan Faceplate Not Installed alarm, issue the `ffo present off` command in the command line interface before removing the faceplate.

NOTE: The `test all` command includes the fan test for both fans, only if the Controller is a version that supports the Fan Faceplate Option and only if the FFO is installed. If the Controller is an older version, or if the fans are not present, the fan tests are omitted.

Complete Self-Test (Power-Up Test)

Use the complete self-test to test the entire Wide Bank with one command. This test runs automatically when power is turned on.

```
(A:Active)> test all
```

```
WARNING: This command affects service. Continue? [y|n]? y
Testing all interfaces...
```

```
DS1 Card 1           Self Test: Pass
DS1 Card 2           Self Test: Pass
DS1 Card 3           Self Test: Pass
DS1 Card 4           Self Test: Pass
DS1 Card 5           Self Test: Pass
DS1 Card 6           Self Test: Pass
DS1 Card 7           Self Test: Pass
DS1 Spare Card       Self Test: Pass

DS3                  Self Test: Pass

Fan A                Self Test: Fan not present
Fan B                Self Test: Fan not present
```

The Complete Self-Test

1. Performs DS1/E1 tests.
2. Performs DS3 tests.
3. Performs FFO tests.




Figure 7-4 Complete Self-Test

Looptests Using Built-in PRBS BERT

- Low-Speed CSU Loopup Drop with PRBS BERT ... 7-15
- Low-Speed NIU Loopup Network with PRBS BERT ... 7-16
- DS3 Loopup Network with PRBS BERT ... 7-17

Low-Speed CSU Loopup Drop with PRBS BERT

This test sends a CSU loopup code and unframed PRBS test pattern toward a CSU device on the low-speed drop. The returned signal is analyzed by the built-in Bit Error Rate Tester (BERT) and the PRBS error rate is displayed in the hour statistics.

1. Configure for CSU loopback and PRBS test. (This example uses DS1 #1.)

```
(A:Active)> ds1 1 send csu loopup drop  
(A:Active)> ds1 1 send prbs drop
```

2. Display PRBS error rate.

```
(A:Active)> hour ds1 1
```

3. When finished, disable loopback and PRBS.

```
(A:Active)> ds1 1 send off  
(A:Active)> ds1 1 send csu loopdown drop
```




Figure 7-5 Low-Speed CSU Looptest with PRBS BERT

Low-Speed NIU Loopup Network with PRBS BERT

This test sends a low-speed NIU loopup code and unframed PRBS test pattern toward the far-end, which can be another Wide Bank or other NIU device. The far-end device loops back the low-speed signal to the near-end Wide Bank. The returned signal is analyzed by the built-in Bit Error Rate Tester (BERT) and the PRBS error rate is displayed in the *hour* statistics.

1. Configure for NIU network loopback and PRBS test. (This example uses DS1 #1.)

```
(A:Active)> ds1 1 send niu loopup  
(A:Active)> ds1 1 send prbs network
```

2. Display PRBS error rate.

```
(A:Active)> hour ds1 1
```

3. When finished, disable loopback and PRBS.

```
(A:Active)> ds1 1 send off  
(A:Active)> ds1 1 send niu loopdown
```




Figure 7-6 Low-Speed Network Looptest with PRBS BERT

DS3 Loopup Network with PRBS BERT

This test sends a high-speed NIU loop code and unframed PRBS test pattern toward the far-end, which can be another Wide Bank or other NIU device. The far-end device loops back the high-speed signal to the near-end Wide Bank. The returned high-speed signal is analyzed by the built-in Bit Error Rate Tester (BERT) and the PRBS error rate is displayed in the *hour* statistics.

NOTE: When *ds3 protect* is turned on, the *ds3 send* command will transmit codes over both primary and secondary DS3s.

1. Configure for DS3 network loopback and PRBS test.

```
(A:Active)> ds3 send loopup
```

```
(A:Active)> ds3 send prbs
```

2. Verify that PRBS SYNC SEC is incrementing.

```
(A:Active)> hour ds3
```

3. When finished, disable loopback and PRBS test.

```
(A:Active)> ds3 send off (A:Active)> ds3 send loopdown
```




Figure 7-7 DS3 Network Looptest with PRBS BERT

Testing Low-Speed Interface Operation

- Testing Low-Speed Near-End with Loop Tests ... 7-19
- Testing the Low-Speed Far-End with Loop Tests ... 7-27
- Running Maintenance Tests on a Low-Speed Circuit ... 7-29

Use the test configuration below when perform the following tests.




Figure 7-8 Test Setup

Testing Low-Speed Near-End with Loop Tests

- DS1 Line Loopback ... 7-20
- DS1 Equipment Loopback ... 7-20
- DS1 Metallic Loopback ... 7-21
- DS1 NIU Loopback ... 7-22
- DS1 NIU Loopback Using Two Wide Banks ... 7-23
- DS1 Send CSU Loopback Toward Drop ... 7-24
- DS1 Send NIU Loopup Code Toward Drop ... 7-25
- DS1 Send NIU Loopup Code Toward Network ... 7-26

NOTE: When the low-speed mode (*lsmode*) is set to either *ds1ls* or *e1ls*, the *ds1* command becomes the *ls* command. The operation of the *ls* command is identical to the *ds1* command, except the references to the circuits are changed to either LS, DS1, or E1. See Chapter 8 for *lsmode* description.

The command **ds1 [n | range | all] setting** allows you to select one or more DS1 or E1 circuits for use with most loopback tests. The *n* can be a range (**ds1 1-6**), an individual circuit (**ds1 1**), a group of individual circuits (**ds1 1-4, 7, 12, 15**), or a combination of ranges and individual circuits (**ds1 1-4, 5, 7, 13-16**). One exception is the metallic loopback, which is limited to four circuits.

A test set should be used on the low-speed side to send patterns and perform loopback tests on each of the available low-speed circuits, as indicated in the following procedure.

DS1 Line Loopback

1. Configure for line loopback.

```
(A:Active)> ds1 1 line on
```




Figure 7-9 Low-Speed Line Loopback

2. Send a pattern from the test set on the low-speed circuit, and verify that the test set synchronizes on the pattern without errors.
3. When finished, disable line loopback.

```
(A:Active)> ds1 1 line off
```

DS1 Equipment Loopback

1. Configure the low-speed circuits for equipment loopback.

```
(A:Active)> ds1 1 equipment on
```




Figure 7-10 Low-Speed Equipment Loopback

2. Test from the DS3 side and verify that there are no errors.
3. When the test is complete, disable equipment loopback.

```
(A:Active)> ds1 1 equipment off
```

DS1 Metallic Loopback

1. Configure the low-speed circuits for metallic loopback. A metallic loopback is shown in Figure 7-11.

```
(A:Active)> ds1 1 metallic on
```

NOTE: Special rules exist for metallic loopback because there is only one spare quad card (four DS1 circuits or three E1 circuits).

- No more than four DS1 or three E1 circuits can be issued a metallic loopback at one time (the commands `ds1 all metallic` and `ls all metallic` are not valid).
- Circuits selected for metallic loopback must all be from different protection groups. For example, the range 1-5 is not valid because 1 and 5 are in the same group. See Figure 7-1 for information on circuit groups.




Figure 7-11 Low-Speed Metallic Loopback

2. Send a pattern from the test set on the low-speed circuits, and verify that the test set synchronizes on the pattern without errors.
3. When the test is complete, disable metallic loopback.

```
(A:Active)> ds1 1 metallic off
```

DS1 NIU Loopback

The Wide Bank provides NIU loopback capability toward the DS3 network. To test its functionality, use a test set on the DS3 interface to inject NIU loop codes toward the low-speed interfaces.

NOTE: This test can also be performed with two Wide Banks as shown on the next page.




Figure 7-12 Low-Speed NIU Loopback

1. Enable loop code detection.

```
(A:Active)> ds1 1 loopdetect on
```
2. Use test set on DS3 side to inject an NIU Loop Up code to low-speed circuit #1. (Loop Up code is 11000).
3. Inject a test pattern of your choice (QRSS, PRBS, and so on).
4. Verify that the loop experiences no bit errors.
5. Verify that the test set connected to the low-speed circuit #1 is receiving AIS.
6. Inject an NIU Loop Down code toward the low-speed circuit #1 from the test set (Loop Down code is 11100).
7. Verify that low-speed circuit #1 returns to normal operation.
8. Disable loop code detection.

```
(A:Active)> ds1 1 loopdetect off
```
9. Repeat steps 1 to 8 for the remaining low-speed circuit interfaces.

DS1 NIU Loopback Using Two Wide Banks

This test is similar to the DS1 NIU Loopback on the previous page but uses two Wide Banks connected back-to-back. The local Wide Bank allows the test set on low-speed side to send an NIU loopup across the DS3 connection to test the far end Wide Bank's DS1 NIU loopup response.

1. On local (near-end) Wide Bank, disable loop detection.

```
(A:Active)> ds1 1 loopdetect off
```

2. On far-end Wide Bank, enable loop detection.

```
(A:Active)> ds1 1 loopdetect on
```

3. Using the test set on the low-speed side, send an NIU loop code toward the remote Wide Bank over the DS3.
4. Verify that the test set receives a loopup response.
5. If desired, repeat steps 1 to 4 for the remaining low-speed circuit interfaces.




Figure 7-13 Low-Speed NIU Loopback Using Two Wide Banks

DS1 Send CSU Loopback Toward Drop

1. Send CSU loopup toward the test set connected to the low-speed interface.

```
(A:Active)> ds1 1 send csu loopup drop
```

2. Verify that test set responds to loopup code.

3. Send loopdown toward the test set connected to the low-speed interface.

```
(A:Active)> ds1 1 send csu loopdown drop
```

4. Verify that test set responds to the loopdown code.




Figure 7-14 Send Low-Speed CSU Loopup Code Toward Drop

5. Repeat tests for interface configured with a line code of AMI.

```
(A:Active)> ds1 1 linecode ami
```

NOTE: The linecode parameter is used only with DS1s. The E1s are always configured for HDB3.

DS1 Send NIU Loopup Code Toward Drop

1. Send NIU loopup toward the test set connected to the low-speed interface.

```
(A:Active)> ds1 1 send niu loopup drop
```

2. Verify that test set responds to loopup code.
3. Send loopdown toward the test set connected to the low-speed interface.

```
(A:Active)> ds1 1 send niu loopdown drop
```

4. Verify that test set responds to the loopdown code.




Figure 7-15 Send Low-Speed NIU Loopup Code Toward Drop

DS1 Send NIU Loopup Code Toward Network

1. Send NIU loopup toward the test set connected to the DS3 interface.

```
(A:Active)> ds1 1 send niu loopup network
```

2. Verify that test set responds to loopup code.

3. Send loopdown toward the test set connected to the DS3 interface.

```
(A:Active)> ds1 1 send niu loopdown network
```

4. Verify that test set responds to the loopdown code.




Figure 7-16 Send Low-Speed NIU Loopup Code Toward Network

Testing the Low-Speed Far-End with Loop Tests

- [Activating Far-End Loopbacks in M23 Framing Mode ... 7-27](#)
- [Activating Far-End Loopbacks in C-Bit Framing Mode ... 7-27](#)
- [Testing the Network to the Far-End Through a Low-Speed Drop ... 7-28](#)

When one of the following Activate Loopback commands is received by the far-end, the corresponding low-speed circuit is set to Equipment loopback mode. The loopback status can be observed by the *dsl* and *status dsl (ls and status ls)* commands. Also, the Low-Speed Status LED is set to YELLOW.

Activating Far-End Loopbacks in M23 Framing Mode

When the Wide Bank is configured for M23 framing, the following low-speed far-end loopup and loopdown commands are available:

```
dsl [n|range|list|all] send [niu|csu]  
[loopup|loopdown] [network|drop]
```

Sends a loop up or loop down code to the specified far-end for loop mode control.

Activating Far-End Loopbacks in C-Bit Framing Mode

When the Wide Bank is configured for C-bit framing, the following low-speed far-end loopup and loopdown control is available.

The commands that control the far-end low-speed loop mode:

```
dsl [n|range|all] send [niu|csu|cbit]  
[loopup|loopdown] [network|drop]
```

Sends a loop up or loop down code to the specified far-end for loop mode control.

Testing the Network to the Far-End Through a Low-Speed Drop

This test uses a Wide Bank at one end of the network to provide an NIU loopup of a low-speed drop at the far end. In the example below, a Wide Bank is used at both ends of the DS3 network, providing a simple illustration of how the far-end loopup works.

NOTE: This test works with *range* and *all* parameters of the *ds1 (ls)* command but usually is just as effective using only the *n* parameter (testing only one ls circuit), which leaves all the other low-speed circuits operational. This test's best purpose is to test the DS3 network, beginning at a near-end low-speed drop and ending at a far-end low-speed drop.

Once an equipment loopback is established to the far-end with the *ds1 [n|range|all] send loopup* or *ds1 [n|range|all] send cbit loopup* command, a *ds1 [n|range|all] send prbs network* command will send a prbs pattern over the selected low-speed tributaries within the DS3 network. This pattern will be looped back from the far-end. Note that the unselected low-speed circuits will maintain normal traffic during this test.

To stop the test, issue a *ds1 [n|range|all] send off* command, then issue the appropriate loopdown command to disconnect the equipment loopback at the far end.

To read the results of the test, issue an *hour ds1 n* command.




Figure 7-17 Testing the Network with a Send PRBS Network Command

Running Maintenance Tests on a Low-Speed Circuit

NOTE: When the *lsmode* mode is set to either *ds1ls* or *e1ls*, the *ds1* command becomes the *ls* command. The operation of the *ls* command is identical to the *ds1* command, except the references to the circuits are changed to either LS, DS1, or E1. See Chapter 8 for description

This test is used to test the low-speed circuits using the redundant low-speed circuits.

1. Move low-speed circuit #5 to the spare group and display protection

```
(A:Active)> ds1 5 move spare
```

```
(A:Active)> status ds1 all
```

Interface	Receive	Transmit	Loop	Protection
-----	-----	-----	----	-----
DS1 1	Traffic	Traffic	None	1 used by DS1 5
DS1 2	Traffic	Traffic	None	by Spare 2
DS1 3	Traffic	Traffic	None	by Spare 3
DS1 4	Traffic	Traffic	None	by Spare 4
DS1 5	Traffic	Traffic	None	1 used by DS1 5
DS1 6	Traffic	Traffic	None	by Spare 2
DS1 7	Traffic	Traffic	None	by Spare 3
DS1 8	Traffic	Traffic	None	by Spare 4
DS1 9	Traffic	Traffic	None	1 used by DS1 5
DS1 10	Traffic	Traffic	None	by Spare 2
DS1 11	Traffic	Traffic	None	by Spare 3
DS1 12	Traffic	Traffic	None	by Spare 4
DS1 13	Traffic	Traffic	None	1 used by DS1 5
DS1 14	Traffic	Traffic	None	by Spare 2
DS1 15	Traffic	Traffic	None	by Spare 3
DS1 16	Traffic	Traffic	None	by Spare 4
DS1 17	Traffic	Traffic	None	1 used by DS1 5
DS1 18	Traffic	Traffic	None	by Spare 2
DS1 19	Traffic	Traffic	None	by Spare 3
DS1 20	Traffic	Traffic	None	by Spare 4
DS1 21	Traffic	Traffic	None	1 used by DS1 5
DS1 22	Traffic	Traffic	None	by Spare 2
DS1 23	Traffic	Traffic	None	by Spare 3
DS1 24	Traffic	Traffic	None	by Spare 4
DS1 25	Traffic	Traffic	None	1 used by DS1 5
DS1 26	Traffic	Traffic	None	by Spare 2
DS1 27	Traffic	Traffic	None	by Spare 3
DS1 28	Traffic	Traffic	None	by Spare 4
Spare 1	Available			
Spare 2	Available			
Spare 3	Available			
Spare 4	Available			

2. Run test on low-speed circuit #5

```
(A:Active)> test ds1 5
```

```
Testing      DS1 5
-----      ----
DS1 5        Selftest: Pass
```

Show low-speed circuit #5 parameters.

```
(A:Active)> ds1 5
```

```
- 5
  ds1 5  circuitid "DS1 5"
  ds1 5   enable
  ds1 5   equipment off
  ds1 5   length dsx0
  ds1 5   line off
  ds1 5   linecode b8zs
  ds1 5   loopdetect off
  ds1 5   metallic off
  ds1 5   send off
Performance Thresholds:      15 min.      1 hour      1 day
-----
coding violations - line:      0          0          0
errored seconds - line:      0          0          0
```

3. Restore Spare A group protection

```
(A:Active)> ds1 5 move home
```

```
DS1 5 moved to home
```

```
(A:Active)> status ds1 all
```

Interface	Receive	Transmit	Loop	Protection
-----	-----	-----	----	-----
DS1 1	Traffic	Traffic	None	by Spare 1
DS1 2	Traffic	Traffic	None	by Spare 2
DS1 3	Traffic	Traffic	None	by Spare 3
DS1 4	Traffic	Traffic	None	by Spare 4
DS1 5	Traffic	Traffic	None	by Spare 1
DS1 6	Traffic	Traffic	None	by Spare 2
DS1 7	Traffic	Traffic	None	by Spare 3
DS1 8	Traffic	Traffic	None	by Spare 4
DS1 9	Traffic	Traffic	None	by Spare 1

DS1 10	Traffic	Traffic	None	by Spare 2
DS1 11	Traffic	Traffic	None	by Spare 3
DS1 12	Traffic	Traffic	None	by Spare 4
DS1 13	Traffic	Traffic	None	by Spare 1
DS1 14	Traffic	Traffic	None	by Spare 2
DS1 15	Traffic	Traffic	None	by Spare 3
DS1 16	Traffic	Traffic	None	by Spare 4
DS1 17	Traffic	Traffic	None	by Spare 1
DS1 18	Traffic	Traffic	None	by Spare 2
DS1 19	Traffic	Traffic	None	by Spare 3
DS1 20	Traffic	Traffic	None	by Spare 4
DS1 21	Traffic	Traffic	None	by Spare 1
DS1 22	Traffic	Traffic	None	by Spare 2
DS1 23	Traffic	Traffic	None	by Spare 3
DS1 24	Traffic	Traffic	None	by Spare 4
DS1 25	Traffic	Traffic	None	by Spare 1
DS1 26	Traffic	Traffic	None	by Spare 2
DS1 27	Traffic	Traffic	None	by Spare 3
DS1 28	Traffic	Traffic	None	by Spare 4
Spare 1	Available			
Spare 2	Available			
Spare 3	Available			
Spare 4	Available			

4. Send Line loopback toward test equipment

```
(A:Active)> ds1 5 line on  
(A:Active)> status ds1 5
```

Interface	Receive	Transmit	Loop	Protection
-----	-----	-----	----	-----
DS1 5	Traffic	Traffic	Line	by Spare 1

5. Repeat for a low-speed circuit in each of the protection groups.

Testing DS3 Interfaces

- Testing DS3 Framing and Loop Timing ... 7-32
- Testing the DS3 Near-End with Loopback Tests ... 7-35
- Testing the DS3 Far-End with Loopback Tests ... 7-37

Testing DS3 Framing and Loop Timing

This test is conducted in non-redundant mode. There should be only one Controller card and one DS3 line available.




Figure 7-18 Non-Redundant Mode

DS3 Non-Redundant Test Setup

1. Configure as:

```
(A:Active)> arm off  
(A:Active)> ds3 protect off
```

2. Configure the DS3 interface parameters

```
(A:Active)> ds3 circuitid "CAC2345"  
(A:Active)> ds3 equipmentid "Wide Bank"  
(A:Active)> ds3 facilityid "primary"  
(A:Active)> ds3 frameid "videodata"  
(A:Active)> ds3 gennumber 1  
(A:Active)> ds3 locationid "Boulder"  
(A:Active)> ds3 portnumber 2  
(A:Active)> ds3 unit "aaaa05"  
(A:Active)> ds3 clock int
```

DS3 Test with M23 Framing

1. Configure the DS3 for M23 framing.

```
(A:Active)> ds3 framing m23
```

```
ds3 framing m23
```

```
(A:Active)> ds3
```

```
- DS3
  ds3   circuitid "DS3A"
  ds3       clock int
  ds3 clockrevert on
  ds3   equipment off
  ds3       framing m23
  ds3       length short
  ds3       line off
  ds3 loopdetect off
  ds3   payload off
  ds3       send off
  ds3   threshold off
  ds3 pm lcv thresholds
        min15          0
        hour            0
        day             1
```

2. Configure the test set for M23 framing, and verify that the test set frames up.

DS3 Test with C-bit Framing

1. Configure the DS3 for C-bit Parity framing.

```
(A:Active)> ds3 framing cbit
```

```
ds3 framing cbit
```

```
(A:Active)> ds3
```

```
- DS3
  ds3   circuitid "DS3"
  ds3       clock int
  ds3 clockrevert on
  ds3 equipmentid "DS3 Equip."
  ds3   equipment off
```

Diagnostics & Troubleshooting

Testing DS3 Interfaces

```
ds3 facilityid "DS3 Path"
ds3 frameid "Frame"
ds3 framing cbit
ds3 gennumber "DS3 Test Generator"
ds3 length short
ds3 line off
ds3 locationid "DS3 Loc."
ds3 loopdetect off
ds3 payload off
ds3 portnumber "DS3 Idle Port"
ds3 send off
ds3 threshold off
ds3 unit "000000"
Performance Thresholds:          15 min.          1 hour          1 day
-----
coding violations - line:         0             0             0
errored seconds - line:          0             0             0
coding viols-path p-bit:         0             0             0
err seconds - path p-bit:        0             0             0
loss of signal secs - line:      0             0             0
sev err seconds - line:          0             0             0
sev err sec - path cp-bit:       0             0             0
```

2. Configure the test set for C-bit Parity framing, and verify that the test set frames up.

DS3 Tests with Line Timing

1. Configure the clock source to use line timing (provided by the test set).

```
(A:Active)> ds3 clock line
```

2. Repeat preceding *DS3 Test with M23 Framing* and *DS3 Test with C-bit Framing* for line clock source.
3. Configure clock source to internal for the following tests.

```
(A:Active)> ds3 clock int
```

Testing the DS3 Near-End with Loopback Tests

- DS3 Equipment Loopback ... 7-35
- DS3 Line Loopback with M23 Framing ... 7-35
- DS3 Line Loopback with C-bit Framing ... 7-36
- DS3 Payload Loopback with M23 Framing ... 7-36
- DS3 Payload Loopback with C-bit Framing ... 7-36

DS3 Equipment Loopback

1. Configure the DS3 for equipment loopback.

```
(A:Active)> ds3 equipment on
```

2. Apply PRBS from the test set on the low-speed circuit, and verify that the test set synchronizes on the pattern without errors.
3. When complete, disable equipment loopback.

```
(A:Active)> ds3 equipment off
```

DS3 Line Loopback with M23 Framing

1. With a test set on the DS3, configure for M23 framing and apply a line loopback.

```
(A:Active)> ds3 framing M23
```

```
(A:Active)> ds3 clock line
```

```
(A:Active)> ds3 line on
```

2. At the test set apply a PRBS pattern, and verify that the test set synchronizes on the pattern without errors.
3. When complete, disable line loopback.

```
(A:Active)> ds3 line off
```

DS3 Line Loopback with C-bit Framing

1. Repeat test using C-bit Parity framing.

```
(A:Active)> ds3 framing cbit
```

```
(A:Active)> ds3 line on
```

2. When complete, disable line loopback.

```
(A:Active)> ds3 line off
```

DS3 Payload Loopback with M23 Framing

1. With a test set on the DS3, configure for M23 framing and apply a payload loopback.

```
(A:Active)> ds3 framing M23
```

```
(A:Active)> ds3 payload on
```

2. At the test set apply a PRBS pattern to a low-speed line, and verify that the test set synchronizes on the pattern without errors.

3. When complete, disable payload loopback.

```
(A:Active)> ds3 payload off
```

DS3 Payload Loopback with C-bit Framing

1. Repeat test using C-bit Parity framing.

```
(A:Active)> ds3 framing cbit
```

```
(A:Active)> ds3 payload on
```

2. When complete, disable payload loopback and set clock to internal.

```
(A:Active)> ds3 payload off
```

```
ds3      payload off
```

```
(A:Active)> ds3 clock int
```

```
ds3      clock int
```

Testing the DS3 Far-End with Loopback Tests

When the Wide Bank is configured for C-bit framing, the following DS3 far-end loopup and loopdown control is available.

The command that controls the far-end DS3 loop mode sends either a loop up code or a loop down code:

```
ds3 send [loopup|loopdown]
```

When a DS3 Activate Loopback command is received, the DS3 is set to a LINE loopback mode. The loopback status can be observed by the *ds3* and *status ds3* commands. Also, the Controller Status LED is set to YELLOW.

Far-End Loop Codes

When a far-end loop command is issued at the near-end, the selected Line Loopback Activate or Deactivate code word is transmitted ten times to the far-end, followed immediately by the selected low-speed or DS3 Line code word (also transmitted 10 times). See Table 2-1. The total message to the far-end is 40 octets long (each code word is two octets).

NOTE: The labels for the loopback code words are determined by ANSI T1.107, so the following chart refers to DS1 exclusively. However, the same loopback functions and code words apply to E1 as well, with the exception that every fourth low-speed circuit is not used with E1.

The DS1 code words use bits 3 - 7 to indicate which line is to be looped back.

Table 2-1 Far-End Loopback Code Words

Loopback Function	Loopback Code Word
Activate Line Loopback	00001110 11111111
Deactivate Line Loopback	00111000 11111111
Select DS3 Line	00110110 11111111
Select DS1 Line 1	01000010 11111111
Select DS1 Line 2	01000100 11111111
Select DS1 Line 3	01000110 11111111
Select DS1 Line 4 (not E1)	01001000 11111111
Select DS1 Line 5	01001010 11111111
Select DS1 Line 6	01001100 11111111

Table 2-1 Far-End Loopback Code Words (Continued)

Loopback Function	Loopback Code Word
Select DS1 Line 7	01001110 11111111
Select DS1 Line 8 (not E1)	01010000 11111111
Select DS1 Line 9	01010010 11111111
Select DS1 Line 10	01010100 11111111
Select DS1 Line 11	01010110 11111111
Select DS1 Line 12 (not E1)	01011000 11111111
Select DS1 Line 13	01011010 11111111
Select DS1 Line 14	01111100 11111111
Select DS1 Line 15	01011110 11111111
Select DS1 Line 16 (not E1)	01100000 11111111
Select DS1 Line 17	01100010 11111111
Select DS1 Line 18	01100100 11111111
Select DS1 Line 19	01100110 11111111
Select DS1 Line 20 (not E1)	01101000 11111111
Select DS1 Line 21	01101010 11111111
Select DS1 Line 22	01101100 11111111
Select DS1 Line 23	01101110 11111111
Select DS1 Line 24 (not E1)	01110000 11111111
Select DS1 Line 25	01110010 11111111
Select DS1 Line 26	01110100 11111111
Select DS1 Line 27	01110110 11111111
Select DS1 Line 28 (not E1)	01111000 11111111
Select DS1 Line All	00100110 11111111

Testing DS3 Redundancy

- Testing Electronics Protection ... 7-39
- Testing Electronics and Network Protection ... 7-42

Testing Electronics Protection

- DS3 Test Setup ... 7-39
- DS3 Manual Switch Test ... 7-40
- DS3 Automatic Protection Test ... 7-40
- DS3 Revertive Switching Test ... 7-41

This test requires two Controller cards that are capable of operating correctly.

NOTE: If you are testing with a Telnet session, each time you switch Controllers (*switch* command), you will have to reconnect your Telnet session to the Wide Bank IP address.

DS3 Test Setup

1. Configure all of the DS1s for B8ZS line coding (E1 circuits must be configured for HDB3), and both DS3s for M23 framing and DS3 electronic redundancy. Configuring for DS3 electronic redundancy means having two Controller cards that operate correctly, arm turned on (*arm on*), and ds3 network protection turned off (*ds3 protect off*).

Configure all DS1s for B8ZS line coding (E1 for HDB3):

```
(A:Active)> ds1 all linecode B8ZS
```

Configure both DS3s for M23 framing:

```
(A:Active)> ds3 framing m23
```

Configure for DS3 electronic redundancy only:

```
(A:Active)> ds3 protect off
```

2. Loop the DS3 back on itself (transmit to receive with 75 ohm BNC cable).
3. Send PRBS pattern across the low-speed circuit using the test set.
4. Verify that the test set synchronizes on its own pattern on the low-speed link.

DS3 Manual Switch Test

1. Verify that a manual switch-over to the secondary Controller can be achieved.

```
(A:Active)> switch  
Switching control to Standby DS3 Controller  
(B:Active)>
```

2. Verify that the test set is still synchronized to the PRBS pattern with a low received-error rate. Errors here are the direct result of the manual switch-over.

3. Switch-over to the primary DS3 link.

```
(B:Active)> switch  
Switching control to Standby DS3 Controller  
(A:Active)>
```

DS3 Automatic Protection Test

1. Ensure that DS3 protection is on.

```
(A:Active)> ds3 protect on  
  
ds3 protect on
```

2. Ensure that revertive switching is off.

```
(A:Active)> revertive off  
  
revertive off
```

3. Physically remove the primary Controller card (Controller card A).

4. Verify that a switch-over has occurred to the standby Controller. Prompt should read:

```
Switching control to Standby DS3 Controller  
(B:Active)>
```

DS3 Revertive Switching Test

1. Re-insert the primary Controller card.
2. Verify that no revertive switch-over occurs. There should be no prompt telling you of a switch to the standby Controller, and Controller B should still be shown active.
3. Manually switch back to the primary Controller.

```
(B:Active)> switch
```

```
Switching control to Standby DS3 Controller
```

```
(A:Active)>
```

4. Remove the secondary Controller card (Controller card B).
5. Verify that the Wide Bank recognizes that the protection Controller card has been removed.
6. Verify that NO errors are encountered by the test set.

Testing Electronics and Network Protection

- DS3 Test Setup ... 7-42
- DS3 Network Protection Test ... 7-42
- DS3 Electronics Protection Test ... 7-43

DS3 Test Setup

The following steps will configure the DS1s for B8ZS line coding (E1 circuits must be configured for HDB3), DS3s for M23 formatting, and DS3 electronic and Network redundancy.

1. Configure all DS1s for B8ZS line coding (DS1 circuits only; E1 is always HDB3):

```
(A:Active)> ds1 all linecode B8ZS
```

2. Configure both DS3s for M23 framing.

```
(A:Active)> ds3 framing m23
```

3. Configure for DS3 electronic redundancy and network redundancy.

```
(A:Active)> ds3 protect on
```

```
ds3 protect on
```

```
(A:Active)> arm on
```

```
arm on
```

4. Ensure that revertive switching is off.

```
(A:Active)> revertive off
```

```
revertive off
```

DS3 Network Protection Test

1. Using 75-ohm BNC coaxial cable, loop Primary DS3 receive and transmit signals together, and loop Secondary DS3 receive and transmit signals together.
2. Send PRBS pattern across the low-speed circuit using the test set.
3. Verify that a manual switch-over to the secondary Controller can be achieved.

```
(A:Active)> switch
```

```
Switching control to Standby DS3 Controller
```

```
(B:Active)>
```

4. Verify that the test set is still synchronized to the PRBS pattern.

5. Switch back to the primary DS3 Controller.

```
(B:Active)> switch  
Switching control to Standby DS3 Controller  
(A:Active)>
```

6. Repeat test, except this time pull the Primary DS3 Link cable instead of executing a manual switch in step 5.

7. Verify that a switch-over has occurred to the secondary link. Note that although there were errors received during the manual switch over, the error count should be less than those encountered in the Electronics Protection test. For a description of “hitless” switching, see Telcordia TR-TSY-752, chapter 8.

8. Reconnect the primary DS3 network link, and switch operation back to the primary DS3.

```
(A:Active)> switch  
Switching control to Standby DS3 Controller
```

DS3 Electronics Protection Test

Verify that the test set encounters no errors when performing the following steps.

1. Pull out the primary Controller card.
2. Verify that a switch-over has occurred to the standby Controller.
3. Re-insert the primary Controller card.
4. Verify that no switch-over occurs.
5. Switch back to the primary Controller.

```
(B:Active)> switch  
Switching control to Standby DS3 Controller
```

6. Pull out the secondary Controller card.
7. Re-insert the secondary Controller card.

Diagnostics & Troubleshooting

Testing DS3 Redundancy

CHAPTER 8

CLI Commands and Messages

In this Chapter

- Management Overview ... 8-2
- Command Line Interface ... 8-6
- CLI Command List ... 8-9

Management Overview

- Management Interfaces ... 8-2
- Redundant DS3 Network Interfaces ... 8-3
- Telnet Interface ... 8-3
- Security Levels ... 8-4
- SNMP Traps ... 8-5

Management Interfaces

The Wide Bank 28 DS3 has four management interfaces (see Figure 8-1):

- **Command Line Interface (CLI).** An ASCII language, communicated over an RS-232 data port or via Ethernet through a Telnet session. The Command Line Interface is a scrolling interface. It is operated only from a dumb terminal (VT100) or a terminal emulation program such as ProComm or HyperTerminal.
- **SNMP Agent.** Simple Network Management Protocol (SNMP), an industry standard management interface, communicated through IP over a 10Base-T Ethernet data port. The Wide Bank's embedded SNMP Agent attaches to an Ethernet connection. It is operated by an SNMP Manager application such as SunConnect SunNet Manager, HP OpenView, or Castle Rock SNMPc, and the Carrier Access NetworkValet.
- **Transaction Language One (TL1).** TL1 compliant automatic outbound alarming through either a 25-pin RS-232 port or over TCP/IP. The Wide Bank also supports TL1 commands over these same interfaces (see Chapter 9).
- **PPP over DS3.** Point-to-Point Protocol (PPP) can be used to support TFTP, SNMP, Telnet, Ping, and TL1 over the DS3 link between two Wide Banks using C-bit framing. Management commands are sent through the Ethernet port of the local Wide Bank for routing over the DS3 C-bit data link to a remote Wide Bank. To use this mode, the local Wide Bank must be configured with the IP PPP Address of the remote Wide Bank and the IP Route is set to Ethernet. The remote Wide Bank's IP Route is set to PPP.

Management interfaces access the same configuration and data structures for low-speed DS1 and E1 and high-speed DS3 interfaces. CLI has more maintenance and monitoring features than the SNMP Agent. In other words, CLI manages a superset of the SNMP Agent. However, SNMP can monitor status (traps), which CLI cannot.

Redundant DS3 Network Interfaces

The Wide Bank can have two Controller cards. To provide electronic and/or network redundancy, each Controller card has a DS3 network interface. The secondary card (B) provides electronics and route protection against faults that occur on the primary Controller card (A) and its interface.




Figure 8-1 Management Port Connections

Telnet Interface

You can use Telnet to remotely access the Wide Bank after setting up the IP address of the Ethernet port (see *IP* on page 8-48). The Telnet interface is identical to the VT100 interface except that it uses the TCP/IP protocol for data transport and is accessed through the 10Base-T Ethernet connection.

You can open a Telnet session using the IP address. After pressing the Enter key to initiate the connection, you can then log in as usual. When finished, log out using the *exit* command before disconnecting the Telnet session.

If you do not exit the session, it will continue for 16 minutes, and any attempt to login through Telnet or the RS-232 port will fail. If this occurs, type Ctrl k on the terminal connected to the Wide Bank RS-232 port to end the one-sided Telnet session. If the Telnet session is idle for five minutes, you will be automatically logged out.

Security Levels

To prevent unauthorized access to the network, users can be assigned security levels. The levels available depend on whether you use the Wide Bank's basic security feature or whether the Wide Bank is equipped with the Security Upgrade option. See *Security on page 1-5* for an overview of basic security and the Security Upgrade option.

Basic Security

With basic security, there are three security levels:

- **admin** – The *admin* user has access to all commands and has the sole authority to grant others access to the system by adding and deleting user names and passwords. There can be only one *admin* user (always named “admin”) within the system.
- **rw (read/write)** – An *rw* user has access to all commands except those for adding users, deleting users, and setting user levels. The *rw* users are typically responsible for the day-to-day operation of the system.
- **ro (read only)** – An *ro* user is limited to commands that display status and reports. The *ro* access level permits technicians to monitor system operation and performance, but prevents them from altering settings.

Security Upgrade Option

With the Security Upgrade option, there are four security levels:

- **secu** – The *secu* user has access to all commands and has the sole authority to grant others access to the system by adding and deleting user names and passwords. The *secu* user also has sole authority to perform such functions as clearing all statistics and logs, configuring IP settings, restoring factory default or previously saved configurations, and configuring the TL1 interface. There can be only one *secu* user (always named “security”) within the system.
- **admin** – An *admin* user has access to all commands except those assigned exclusively to the *secu* user. Functions available to the *admin* user that are not available to lower-level users include clearing DS1 and DS3 statistics, copying a configuration from the active to standby Controller, setting the system time and date, programming the flash memory, saving a configuration to a TFTP server file, setting various security functions, configuring SNMP, and copying the current configuration to temporary storage.
- **rw (read/write)** – An *rw* user has access to all commands except those assigned exclusively to the *secu* and *admin* users. The *rw* users are typically responsible for the day-to-day operation of the system.
- **ro (read only)** – An *ro* user is limited to commands that display status and reports. The *ro* access level permits technicians to monitor system operation and performance, but prevents them from altering settings.

Security Integrity

The Wide Bank will deny access if a user name or password is entered incorrectly. After three consecutive unsuccessful login attempts, the login prompt does not appear for 10 seconds, and an SNMP trap (cliLoginFailureTrap) is sent. After the 10 second delay, the prompt reappears and another login attempt can be made. The three-attempt rule is effective for both RS-232 and Telnet sessions; however, a Telnet session is disconnected after three unsuccessful attempts, requiring reconnection after a 10 second delay.

SNMP Traps

All supported SNMP MIB traps are turned on by default. The first three traps are supported by the Wide Bank 28 DS3 with RFC 1213 MIB II. The remaining are equipment status traps provided by the Carrier Access enterprise MIB (ds3am.mib). For detailed descriptions, see *SNMP Traps Supported by Wide Bank 28 DS3 on page 11-6*.

- warmStartTrap – occurs when the Wide Bank is powered off and on, or when all Controller cards are removed and replaced
- linkDownTrap – occurs when a communication facility fails or is removed
- linkUpTrap – occurs when a communication facility is removed, then restored
- cliLoginFailureTrap – occurs after three failed CLI login attempts
- ds3ControllerStateTrap – occurs when a DS3 Controller experiences an alarm state change
- ds1CardStateTrap – occurs when a DS1 card experiences an alarm state change
- ext48VPowerStatusTrap – occurs when an external 48V power source fails or when the failure is cleared
- ds1ProtectSwitchTrapTrap – occurs when a DS1 facility is moved to the spare card
- ds1MoveHomeTrap – occurs when a DS1 facility is moved from the spare card to its home card
- ds1InternalHardwareFailureTrap – occurs when a DS1 facility experiences an internal hardware failure
- ds1InternalHdwFailureClearTrap – occurs when a DS1 facility experienced an internal hardware failure and it is now clearing
- ds1InternalHdwFailureSpareTrap – occurs when a DS1 facility experienced an internal hardware failure while on the spare
- ds1InternalHdwFailureSpareClearTrap – occurs when a DS1 facility experienced an internal hardware failure and it is now clearing

Command Line Interface

- Using the Command Line Interface ... 8-6
- Context Sensitive Help ... 8-7
- CLI Command List ... 8-9
- CLI Shortcuts (Recall and Edit) ... 8-10

The command line interface provides a method to fully control and monitor the operation of the Wide Bank using any terminal or PC running terminal emulation software.

Using the Command Line Interface

1. Configure the terminal interface to 9600 baud, 8 data bits, 1 stop bit, no parity, no flow control.
2. Connect the serial port of a terminal or a PC running terminal emulation software to the RS-232 port of the Wide Bank (female DB9 connector).

This gives you access to the command line interface. After pressing the Enter key, you should see the following display:

```
13:30:14 06/19/1999

Automatic Login to Controller Card A
Equipment          Status
-----
DS3 Controller A   Active
DS3 Controller B   Standby
DS1 Card 1         Active
DS1 Card 2         Active
DS1 Card 3         Active
DS1 Card 4         Active
DS1 Card 5         Active
DS1 Card 6         Active
DS1 Card 7         Active
DS1 Spare Card     Active
```

NOTE: While using the CLI, remember that an inactive period of 15 minutes causes an automatic termination of the session.

Context Sensitive Help

The Command Line interface has a context-sensitive help feature that tells you what the command options are. If you type a question mark (?) at the prompt by itself, the entire list of commands is displayed. If you type a question mark after the name of a command, the first-level options for that specific command are displayed. Some commands have more options under the first level, which can be displayed only by typing **help** after the name of the specific command.

For example, note that the first command (`ds1 ?`) below shows the first level of options, and the second command (`ds1 help`) below shows **all** option for the `ds1` command.

Example: Show First level of options for the `ds1` command.

```
(A:Active)> ds1 ?  
  
ds1 [n|range|all] ..... Set/Display DS1 n=1..28, range=x-y or all  
circuitid "id" ..... DS1 Circuit ID  
enable/disable ..... Activate/Deactivate DS1 Interface  
equipment ..... Apply DS1 Equipment Loopback  
length ..... Set DS1 line length  
line ..... Apply Line Loopback to DS1  
linecode ..... Coding Type  
loopdetect ..... Set Detection of Loop Codes  
metallic ..... Apply DS1 Metallic Loopback  
move ..... Move Control of DS1 n to Spare DS1  
pm threshold ..... Show/Set DS1 PM Threshold Values  
send ..... Send a Code on DS1 Toward Drop or Network
```

Example: Show all levels of options for the `ds1` command.

```
(A:Active)> ds1 help  
  
ds1 [n|range|all] ..... Set/Display DS1 n=1..28, range=x-y or all  
circuitid "id" ..... DS1 Circuit ID  
enable/disable ..... Activate/Deactivate DS1 Interface  
equipment ..... Apply DS1 Equipment Loopback  
    off ..... Disable DS1 equipment loopback towards DS3  
    on ..... Enable DS1 equipment loopback towards DS3  
length ..... Set DS1 line length  
    dsx0 ..... DSX (0'-110')  
    dsx110 ..... DSX (110'-220')  
    dsx220 ..... DSX (220'-330')  
    dsx330 ..... DSX (330'-440')  
    dsx440 ..... DSX (440'-550')  
    dsx550 ..... DSX (550'-660')  
line ..... Apply Line Loopback to DS1  
    off ..... Disable DS1 Line Loopback towards DS1  
    on ..... Enable DS1 Line Loopback towards DS1
```

CLI Commands and Messages

Command Line Interface

linecode Coding Type
 ami AMI Line Coding
 b8zs B8ZS Line Coding
loopdetect Set Detection of Loop Codes
 off Disable All Loop Code Detections
 on Enable All Loop Code Detections
 niu Enable NIU Loop Code Detections only
 cbit Enable C-bit Loop Code Detections only
metallic Apply DS1 Metallic Loopback
 off Disable Metallic Loopback
 on Enable Metallic Loopback
move Move Control of DS1 n to Spare DS1
 home Switches Control from Spare to Home DS1
 spare Switches Control from Home to Spare DS1
pm threshold Show/Set DS1 PM Threshold Values
 Command Syntax:
 ds1 <n-n> pm threshold <int> <err> <val>
 Example: ds1 1-4 pm threshold hour cvl 300
 int = min15, hour, day
 err = cvl, esl
 val = value for new threshold
send Send a Code on DS1 Toward Drop or Network
 off Disable Code Send
 ais Send AIS to the DS1 Drop
 cbit loopup Send C-bit Loop Up Request to DS3
 cbit loopdown Send C-bit Loop Down Request to DS3
 csu loopup drop Send CSU Loop Up Code to DS1 Drop
 csu loopup network Send CSU Loop Up Code to DS3 side
 csu loopdown drop Send CSU Loop Down Code to DS1 Drop
 csu loopdown network ... Send CSU Loop Down Code to DS3 side
 niu loopup Send NIU Loop Up Code to DS3 side
 niu loopdown Send NIU Loop Down Code to DS3 side
 prbs drop Send PRBS Code to DS1 Drop
 prbs test drop Perform Automated PRBS Test of DS1 Drop
 prbs network Send PRBS Code to DS1 Network

CLI Command List

- ACO ... 8-11
- ALARMS ... 8-11
- ALARMS STANDBY ... 8-11
- ALARMOUT ... 8-13
- ARM ... 8-13
- AUTOCOPY ... 8-14
- CLEAR ... 8-14
- CONFIG ... 8-15
- CONTROLLER ... 8-17
- COPY ... 8-18
- DATE ... 8-18
- DAY ... 8-19
- DS1 ... 8-21
- DS1 AINS ... 8-22
- DS1 CIRCUITID ... 8-23
- DS1 ENABLE/DISABLE ... 8-23
- DS1 EQUIPMENT ... 8-24
- DS1 LENGTH ... 8-25
- DS1 LINE ... 8-25
- DS1 LINECODE ... 8-26
- DS1 LOOPDETECT ... 8-27
- DS1 METALLIC ... 8-27
- DS1 MOVE ... 8-28
- DS1 PM THRESHOLD ... 8-29
- DS1 PROTECT ... 8-30
- DS1 SEND ... 8-30
- DS3 ... 8-32
- DS3 CIRCUITID ... 8-33
- DS3 CLOCK ... 8-33
- DS3 CLOCKREVERT ... 8-34
- DS3 EQUIPMENT ... 8-34
- DS3 EQUIPMENTID ... 8-35
- DS3 FACILITYID ... 8-35
- DS3 FRAMEID ... 8-35
- DS3 FRAMING ... 8-36
- DS3 GENNUMBER ... 8-36
- DS3 LENGTH ... 8-37
- DS3 LINE ... 8-37
- DS3 LOCATIONID ... 8-37
- DS3 LOOPDETECT ... 8-38
- DS3 PAYLOAD ... 8-38
- DS3 PM THRESHOLD ... 8-39
- DS3 PORTNUMBER ... 8-41
- DS3 PROTECT ... 8-41
- DS3 SEND ... 8-42
- DS3 THRESHOLD ... 8-42
- DS3 UNIT ... 8-43
- EQUIPMENT ... 8-43
- EXIT ... 8-45
- FFO PRESENT ... 8-45
- HELP, ? ... 8-46
- HOUR ... 8-47
- IP ... 8-48
- LOAD ... 8-49
- LOG ... 8-50
- LS ... 8-50
- LS AINS ... 8-51
- LS CIRCUITID ... 8-53
- LS ENABLE/DISABLE ... 8-53
- LS EQUIPMENT ... 8-54
- LS LENGTH ... 8-55
- LS LINE ... 8-56
- LS LINECODE ... 8-56
- LS LOOPDETECT ... 8-57
- LS METALLIC ... 8-57
- LSMODE ... 8-58
- LS MOVE ... 8-59
- LS PROTECT ... 8-61
- LS SEND ... 8-61
- PING ... 8-63
- PROGRAM FLASH ... 8-63
- RESTORE ... 8-63
- RESULTS ... 8-66
- REVERTIVE ... 8-67
- SAVE ... 8-68
- SCREEN ... 8-69
- SECURITY ... 8-69
- SECURITY CLI ... 8-70
- SECURITY ETHERNET ... 8-71
- SECURITY RS232CLI ... 8-71
- SECURITY RS232TL1 ... 8-72
- SECURITY SNMP ... 8-73
- SECURITY TL1 ... 8-73
- SNMP ... 8-74
- STATUS ... 8-75
- SWITCH ... 8-78
- TEMP COPY ... 8-79
- TEST ... 8-79
- TIME ... 8-80
- TL1 ... 8-81
- USER ... 8-82
- VERSION ... 8-85

CLI Command Syntax

The command syntax uses the following conventions:

- *Courier Font* is used for command words
- *Italic Font* indicates a variable for which you must substitute a value or word
- Curly Brackets { } enclose required parameters
- Square Brackets [] enclose optional items
- Vertical Rules ||| separate items in a list for which you must select only one item

NOTE: The Wide Bank ships with all configuration parameters set to factory default values unless otherwise specified. Default values appear in bold type in the tables following the CLI command syntax. The Wide Bank can be restored to these default values at any time *RESTORE* on [page 8-63](#).

CLI Shortcuts (Recall and Edit)

To simplify entering repetitive commands, CLI allows you to “recall” the previous three commands entered by typing Ctrl+R (hold the Ctrl key down and press the R key). To go “forward,” type Ctrl+F.

CLI also allows you to edit commands by using the Backspace key to delete mistakes and retyping characters. This also allows you to easily recall and edit a previous command to change characters, and then press the Enter key to enter the modified command.

ACO

Name: Alarm Cut Off

Purpose: Activates the Alarm Cut Off, which deactivates the alarm relay contacts to suppress the alarm.

Security: *rw* and above

Syntax: `aco`

ALARMS

Name: Alarms

Purpose: Display the currently active alarms.

Security: *ro* and above

Syntax: `alarms`

Example: `alarms`

```
Sev   Active Alarm
---   -
CR    DS3 A Loss Of Signal
```

Syntax: `aco`

ALARMS STANDBY

Name: Alarms Standby

Purpose: Set the severity of failure conditions for the standby DS3 Controller when logging and reporting alarms (REPT ALM) and events (REPT EVT). The severity of many other failure conditions can be set by the TL1 command *SET-ATTR-<AIDType> on page 9-75*.

The “standby self-test” is only run when the standby Controller is initialized. Other CLI commands (*test all, test ds3*) and TL1 commands (*dgn-t3-all, dgn-all*) only run a self-test on the active Controller card.

The “other controller bad” condition occurs if the active Controller loses communications with the standby Controller. Both conditions cause a CONTEQPT, “Control Equipment Failure”, STANDBY.

Note: The Wide Bank restricts standby Controller condition severities to values that are equal to or less than the corresponding active Controller settings. You can still set a standby condition severity to a greater value but the actual reported value will be restricted by the active Controller setting, as shown in the following examples.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `alarms standby {ds3_selftest|othercontrollerbad}`
`{critical|major|minor|na|nr}`

Field	Description
<code>ds3_selftest</code>	Standby DS3 Controller failed Self-Test
<code>othercontrollerbad</code>	Active DS3 Controller lost communications with the standby Controller
<code>critical</code>	Set alarm condition level to Critical
<code>major</code>	Set alarm condition level to Major
<code>minor</code>	Set alarm condition level to Minor
<code>na</code>	Not Alarmed. Condition is logged and reported as an event (REPT EVT) instead of an alarm (REPT ALM).
<code>nr</code>	Not Reported. Condition is logged but not reported.

Example: `alarms standby ds3_selftest`
Set to Not Reported

Indicates that standby Controller self-test failure alarm severity is currently set to Not Reported (nr).

Example: `alarms standby ds3_selftest minor`
Set to Minor

Sets standby Controller self-test failure alarm severity to Minor.

Example: `alarms standby ds3_selftest major`
Notice: Limited to Minor by Active Setting
Set to Major

Sets standby Controller self-test failure alarm severity to Major. However, the accompanying “Notice” indicates that this alarm severity will be limited to Minor because the active Controller alarm severity is currently set to Minor. The standby Controller alarm severity can be no higher than the active Controller setting.

ALARMOUT

Name: Alarm Relay Output Contacts

Purpose: Sets the alarm output contacts to normally open (NO) or normally closed (NC). This command affects both the Critical and Major/Minor alarm relay contacts.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `alarmout {nc|no}`

Field	Description
nc	Normally Closed (NC). Contacts will open when alarm is active. Note: The contacts will be open when the Wide Bank is not powered.
no	Normally Open (NO). Contacts will close when alarm is active.

Example: `alarmout`
`alarm contacts normally open`

Example: `alarmout nc`
`alarm contacts normally closed`

ARM

Name: Automatic Redundancy Mode

Purpose: Set or show the current protection switching operation. Arm is turned on automatically when revertive DS3 is turned on (see *REVERTIVE* on page 8-67) because network protection is normally revertive.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `arm {on|off}`

Field	Description
on	The default setting is ON. When a fault occurs in the active Controller, the Wide Bank switches control to the standby Controller. If DS3 network protection is also enabled (see <i>DS3 PROTECT</i> on page 8-41), the Wide Bank switches Controllers when a DS3 line defect occurs.
off	Disables protection switching

AUTOCOPY

Name: Automatic Copy Mode

Purpose: When turned on, allows the active Controller to automatically copy configuration changes to the standby Controller. This command has no effect when only one Controller is installed. Multi-user information is always copied between Controllers.

Security: Set - *rw* and above
 Show - *ro* and above

Syntax: `autocopy [on|off]`

Setting	Description
<code>autocopy</code>	Use the command by itself to show the current setting
<code>on</code>	Enables the active Controller to automatically copy configuration changes to the standby Controller card
<code>off</code>	Disables the autocopy mode

Example: `autocopy on`
 Enables the autocopy mode.

CLEAR

Name: Clear Data

Purpose: Clears recorded statistics and logs.

NOTE: If you clear the event log, timestamps for any existing alarms or conditions are also cleared.

Security: *rw* and above with basic security; *admin* and above for CLEAR ds1 and CLEAR ds3 with Security Upgrade; *secu* for CLEAR all, CLEAR log, CLEAR log standby, and CLEAR wtr with Security Upgrade

See *Security on page 1-5* for an overview of basic security and the Security Upgrade option.

Syntax: `clear {all|ds1 [number|range|all]|ds3|log [standby]|wtr}`

Field	Description
<code>all</code>	All interface statistics and log data
<code>ds1 number</code>	Clear a low-speed interface number, 1 to 28
<code>ds1 range</code>	Clear a range of low-speed interfaces separated by a hyphen as in 5-8

Field	Description
ds1 all	Clear all low-speed interface statistics and log data
ds3	Clear DS3 statistics
log	Clear event log
log standby	Clear standby Controller event log
wtr	Clear 5-minute wait-to-restore period

Example: `clear ds1 5`

Clear counts for DS1 #5 interface.

CONFIG

Name: Configuration Settings

Purpose: Display configuration settings of all cards and interfaces.

Security: *ro* and above

Syntax: `config`

Message:

```
- CONTROLLER

ds1      protect on
ds3      protect off
autocopy          on
revertive ds3    off
revertive ds1    off
arm                on

ffo      present off

security          off

screen 24

ip      address 192.168.26.44
ip      mask    255.255.255.0
ip      gateway 192.168.26.202
ip      nms1    192.168.41.46
ip      nms2    192.168.25.212
ip      nms3
ip      ppp
ip      route  ethernet
```

CLI Commands and Messages

CLI Command List

```
snmp name      "Name"
snmp location  "Location"
snmp contact   "Contact"
snmp getcomm   "public"
snmp setcomm   "public"
snmp trapcomm  "public"

- DS3
ds3  circuitid "DS3"
ds3  clock int
ds3  clockrevert on
ds3  equipmentid "DS3 Equip."
ds3  equipment off
ds3  facilityid "DS3 Path"
ds3  frameid "Frame"
ds3  framing cbit
ds3  gennumber "DS3 Test Generator"
ds3  length short
ds3  line off
ds3  locationid "DS3 Loc."
ds3  loopdetect off
ds3  payload off
ds3  portnumber "DS3 Idle Port"
ds3  send off
ds3  threshold off
ds3  unit "000000"
Performance Thresholds:  15 min.    1 hour    1 day
-----
coding violations - line:    387      1161     3865
errored seconds - line:     25       75      250
coding viols-path p-bit:    382     1146     3820
err seconds - path p-bit:   25       75      250
loss of signal secs - line:  4        12       40
sev err seconds - line:     4        12       40
sev err sec - path cp-bit:  4        12       40

- 1
ds1 1  circuitid "DS1#1"
ds1 1  enable
ds1 1  equipment off
ds1 1  length dsx0
ds1 1  line off
ds1 1  linecode b8zs
ds1 1  loopdetect off
ds1 1  metallic off
ds1 1  send off
Performance Thresholds:  15 min.    1 hour    1 day
-----
coding violations - line:   13340    40020   133400
errored seconds - line:     65      195     648
```

```
•
• (Circuits 2 through 27)
•
- 28
  ds1 28  circuitid "DS1#28"
  ds1 28      enable
  ds1 28  equipment off
  ds1 28      length dsx0
  ds1 28      line off
  ds1 28  linecode b8zs
  ds1 28  loopdetect off
  ds1 28  metallic off
  ds1 28      send off
  Performance Thresholds:    15 min.    1 hour    1 day
                             -----
coding violations - line:    13340    40020    133400
errored seconds - line:     65      195     648
```

CONTROLLER

Name: Controller Settings

Purpose: Display all Controller settings.

Security: ro and above

Syntax: controller

Message:

```
DS3 (A:Active)> controller
- CONTROLLER

  ds1      protect on
  ds3      protect off
  autcopy          on
  revertive ds3    off
  revertive ds1    off
  arm           on

  ffo      present on

  security          off

  screen 24

  ip      address 192.168.26.49
  ip      mask 255.255.255.0
  ip      gateway 192.168.26.202
  ip      nms1
```

```
ip          nms2
ip          nms3
snmp name   "Name"
snmp location "Location"
snmp contact "Contact"
snmp getcomm "public"
snmp setcomm "public"
snmp trapcomm "public"
```

COPY

Name: Copy Configuration

Purpose: Copy current configuration settings from the active Controller to the standby Controller. This command is not required when autocopy is enabled (see *AUTOCOPY* on page 8-14).

Security: *rw* and above with basic security; *admin* and above with Security Upgrade

See *Security* on page 1-5 for an overview of basic security and the Security Upgrade option.

Syntax: copy

DATE

Name: Date

Purpose: Set or show the date of the Wide Bank system clock.

Security: Set - *rw* and above with basic security; *admin* and above with Security Upgrade
Show - *ro* and above

See *Security* on page 1-5 for an overview of basic security and the Security Upgrade option.

Syntax: date [*mm/dd/yyyy*]

Setting	Description
date	Use the command by itself to show the current setting
<i>mm</i>	Month = 1 to 12
<i>dd</i>	Day = 1 to 31
<i>yyyy</i>	Year = 1997 and up

Example: date

```
The time is 14:03:53 09/05/2002
```

Example: `date 9/5/2002`

Sets the date (month, day, and year) to September 5, 2002.

DAY

Name: Day Performance

Purpose: Show the 24-hour performance statistics for an interface. Display conforms to RFC 1406 and 1407 requirements for reporting SNMP MIB statistics.

For current hour statistics, see *HOUR* on page 8-47.

Security: *ro* and above

Syntax: `day {ds3|ds3far|ds1 number}`

Field	Description
day	Show 24-hour statistics
ds1 number	Display 24-hour performance statistics for selected DS1 interface number, 1 to 28
ds3	Display 24-hour performance statistics for the DS3 interface
ds3far	Display 24-hour performance statistics for the far-end DS3 interface. (Valid only with C-bit framing.)

Example: `day ds3`

15-Minute Interval Statistics for Near-end DS3 at 09:58:54 05/09/2001

STATISTIC \ INTERVAL	Current	1	2	3	4	Day
Unavailable Sec	0	0	0	0	0	0
Loss of Signal Sec	0	0	0	0	0	0
P-Bit Sev Err Sec	0	0	0	0	0	0
P-Bit Errored Sec	0	0	0	0	0	0
Sev Err Framing Sec	0	0	0	0	0	0
Line Errored Sec	0	0	0	0	0	0
Line Sev Errored Sec	0	0	0	0	0	0
Protected Sec	0	0	0	0	0	0
Loopback Sec	0	0	0	0	0	0
PRBS Sync Sec	0	0	0	0	0	0
Protected Cnt	0	0	0	0	0	0
P-Parity Error Cnt	0	0	0	0	0	0
LCV Error Cnt	0	0	0	0	0	0
Elapsed Sec	834	LCV Error Rate				0
Valid Intervals	96	P-Parity Error Rate				0
FE Elapsed Sec	N/A	C-Parity Error Rate				N/A
FE Valid Intervals	N/A	FE C-Parity Err Rate				N/A

... FOLLOWED BY INTERVALS 5 THROUGH 96.

CLI Commands and Messages

CLI Command List

Example: day ds3far

15-Minute Interval Statistics for Far-end DS3 at 09:58:58 05/09/2001

STATISTIC \ INTERVAL	Current	1	2	3	4	Day
FE Unavailable Sec	0	0	0	0	0	0
FE C-bit Sev Err Sec	0	0	0	0	0	0
FE C-bit Errored Sec	0	0	0	0	0	0
FE C-Parity Err Cnt	0	0	0	0	0	0
Elapsed Sec	N/A	LCV Error Rate			N/A	
Valid Intervals	N/A	P-Parity Error Rate			N/A	
FE Elapsed Sec	577	C-Parity Error Rate			N/A	
FE Valid Intervals	96	FE C-Parity Err Rate			0	

... FOLLOWED BY INTERVALS 5 THROUGH 96.

Example: day ds1 5

15-Minute Interval Statistics for DS1 5 at 09:58:23 05/09/2001

STATISTIC \ INTERVAL	Current	1	2	3	4	Day
Unavailable Sec	0	0	0	0	0	0
Sev Errored Sec	0	0	0	0	0	0
Errored Sec	0	0	0	0	0	0
Loss of Signal Sec	0	0	0	0	0	0
Line Errored Sec	0	0	0	0	0	0
Controlled Slip Sec	0	0	0	0	0	0
Degraded Min	0	0	0	0	0	0
Protected Sec	0	0	0	0	0	0
Loopback Sec	0	0	0	0	0	0
PRBS Sync Sec	0	0	0	0	0	0
Protected Cnt	0	0	0	0	0	0
LCV Error Cnt	0	0	0	0	0	0
PRBS Error Cnt	0	0	0	0	0	0
Elapsed Sec	383	LCV Error Rate			0	
Valid Intervals	96	PRBS Error Rate			No Sync.	

... FOLLOWED BY INTERVALS 5 THROUGH 96.

DS1

Name: DS1 Configuration Settings

Purpose: Show the DS1 or E1 low-speed interface configuration. The command followed by the interface number displays the current configuration. (See following *ds1* commands with settings used to set the interface configuration.)

Note: When the LSMODE is set to DS1, you must use the *DS1* commands. When the LSMODE is set to either DS1LS or E1LS, you must use the *LS* commands. The *LS* command operates just like the *DS1* command, except that the responses are specific to the DS1 or E1 interface type. In the DS1LS mode, the low-speed references in command responses are the same as for the DS1 mode. In E1LS mode, the low-speed references in command responses are for E1 (each E1 card has only three active circuits; the fourth, unused, circuit on an E1 card is called CIR). See *LSMODE* on page 8-58 and *LS* on page 8-50.

Security: *ro* and above

Syntax: `ds1 {number|range|list|all}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces

Example: `ds1 5`

```

- 5
  ds1 5  circuitid "DS1 5"
  ds1 5   enable
  ds1 5   equipment off
  ds1 5   length dsx0
  ds1 5   line off
  ds1 5   linecode b8zs
  ds1 5   loopdetect off
  ds1 5   metallic off
  ds1 5   send off
Performance Thresholds:      15 min.      1 hour      1 day
-----
coding violations - line:      0          0          0
errored seconds - line:      0          0          0
  
```

Example: `ds1 all`

Display configuration settings for all low-speed interfaces.

DS1 AINS

Name: DS1 Automatic In-Service Detection

Purpose: Set low-speed alarm mode for automatic detection of new service connections. This command allows service providers to configure low-speed drops before connections or facilities are available. When automatic in-service detection is enabled, a disabled low-speed channel can be enabled (set in service) while a Loss of Signal (LOS) condition is present, and the Wide Bank will inhibit LOS alarm reporting for that channel until a new service connection has been established for the specified delay time.

Note: Following a DC power interruption, the LOS inhibit will be disabled on all channels, causing an LOS alarm on any DS1 that is enabled but not in service.

Note: A channel's LOS inhibit will also be disabled immediately if any of the following events occur:

- the channel is disabled (set out of service)
- a hardware failure occurs on the channel
- a metallic loopback is run on the channel
- the channel is manually moved to a spare
- the channel's card is removed

However, if a channel is disabled and then re-enabled while an LOS condition is present, the automatic in-service detection will again inhibit the LOS alarm.

Auto in-service detection is applied on a channel-by-channel basis. If service is discontinued on a channel, automatic in-service detection can be reapplied to that channel by simply placing it out of service and then back in service (see *DS1 ENABLE/DISABLE on page 8-23*).

To quickly provision automatic in-service detection when turning up a new Wide Bank, first turn on automatic in-service detection and then place all DS1s or E1s out of service and then back in service.

Security: Set - *rw* and above
 Show - *ro* and above

Syntax: `ds1 ains [on|off|delay time]`

Setting	Description
<code>ds1 ains</code>	Use the command by itself to show the current setting
<code>on</code>	Enables automatic detection of new low-speed service on channels that are subsequently enabled and inhibits LOS alarms until a new service has been connected for the specified delay time.
<code>off</code>	Disables automatic in-service detection and allows LOS alarms on all low-speed channels
<code>delay time</code>	Set automatic in-service detection delay in hours, 1 to 168 (1 week). The default time is 2 hours.

Example: `ds1 ains on`

Enable automatic in-service detection of all low-speed channels that are subsequently enabled.

Example: `ds1 ains delay 12`

Set automatic in-service delay to 12 hours.

DS1 CIRCUITID

Name: DS1 Circuit Identification

Purpose: Set the low-speed circuit identification string (transmission vendor's identification), which is used for SNMP display only.

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} circuitid {"string"}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
circuitid	Set low-speed circuit identification string
<i>"string"</i>	Alphanumeric string enclosed in quotes, as per RFC 1406 requirement for SNMP MIBs

Example: `ds1 1 circuitid "DS1 1"`

Set DS1 #1 circuit identifier.

DS1 ENABLE/DISABLE

CAUTION! DISABLING AN INTERFACE WILL DISRUPT SERVICE.

Name: DS1/E1 Interface Enable/Disable

Purpose: Activate or deactivate a low-speed interface (normally used for SNMP managed systems).

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} {enable|disable}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
enable	Activate low-speed interface
disable	Deactivate low-speed interface

Example: `ds1 8 disable`

Disable DS1 #8.

DS1 EQUIPMENT

Name: DS1/E1 Equipment Loopback

Purpose: Set equipment loopback toward low-speed side (see chapter 7).

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} equipment {on|off}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
equipment	Send equipment loopback toward low-speed side
on	Apply equipment loopback
off	Remove equipment loopback

Example: `ds1 2 equipment on`

Apply DS1 #2 equipment loopback.

DS1 LENGTH

Name: DS1 Length for Line Buildout

Purpose: Adjust the DS1 line buildout (LBO) based on line length required for making cable connections to DSX-1 crossconnect equipment. Not available for E1 circuits.

Security: *rw* and above

Syntax: **ds1** {*number*|*range*|*list*|**all**} **length**
{**dsx0**|**dsx110**|**dsx220**|**dsx330**|**dsx440**|**dsx550**}

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
length	Line buildout length (see settings below)
dsx0	Set for 0 to 110 feet
dsx110	Set for 110 to 220 feet
dsx220	Set for 220 to 330 feet
dsx330	Set for 330 to 440 feet
dsx440	Set for 440 to 550 feet
dsx550	Set for 550 to 660 feet

Example: **ds1 5-8 length dsx220**

Set DS1 #5 through #8 for line buildout of 330 to 440 feet.

DS1 LINE

Name: DS1 Line Loopback

Purpose: Configure line loopback toward low-speed side (see chapter 7).

Security: *rw* and above

Syntax: **ds1** {*number*|*range*|*list*|**all**} **line** {**on**|**off**}

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
line	Send line loopback toward low-speed side
on	Apply line loopback
off	Remove line loopback

Example: `ds1 9 line on`

Apply DS1 #9 line loopback.

DS1 LINECODE

Name: DS1 Line Coding

Purpose: Configure line coding for low-speed circuits. DS1 circuits use AMI or B8ZS. E1 circuits are fixed at HDB3.

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} linecode {ami|b8zs}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
linecode	Configure DS1 line coding. E1 circuits are fixed at hdb3 (High Density Bipolar 3).
ami	Alternate Mark Inversion
b8zs	Binary 8-Zero Substitution

Example: `ds1 10 linecode b8zs`

Set DS1 #10 for B8ZS line coding.

DS1 LOOPDETECT

Name: DS1 Loopcode Detection

Purpose: Configure low-speed channel for detection of bit pattern loopcodes.

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} loopdetect {on|off|niu|cbit}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
loopdetect	Configure loopcode detection
on	Enable loopcode detection
off	Disable loopcode detection
niu	Enable NIU loopcode detection only – turns off C-bit detection
cbit	Enable C-bit loopcode detection only – turns off NIU detection

Example: `ds1 11 loopdetect on`

Set DS1 #11 to detect loopcodes.

DS1 METALLIC

Name: DS1 Metallic Loopback

Purpose: Configure metallic loopback toward low-speed side (see chapter 7). Metallic loopbacks can only be applied to a maximum of four DS1 channels, one per protection group.

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} metallic {on|off}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
metallic	Send metallic loopback toward low-speed side
on	Apply metallic loopback
off	Disable metallic loopback

Example: `ds1 11 metallic on`

Apply DS1 #11 metallic loopback.

DS1 MOVE

Name: DS1 Move Channel

Purpose: Move low-speed channel to home card or spare card. Moving a circuit home does not reset the revertive state (*REVERTIVE* on page 8-67).

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} move {home|spare}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
move	Move low-speed channel
home	Move channel to home card
spare	Move channel to spare card

Example: `ds1 13 move spare`

Move DS1 #13 from home card to spare card.

DS1 PM THRESHOLD

Name: DS1 Performance Monitor Threshold

Purpose: Set or show the threshold value for PM statistics. When the threshold is exceeded, the Wide Bank will log a CLI event and send an automatic TL1 message. The performance threshold function complies with Telcordia GR-820-CORE.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ds1 {number|range|list} pm threshold [interval error value]`

Field	Description
pm threshold	Use the command by itself to show the current setting
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
<i>interval</i>	Specify measurement time interval (see Interval table below)
<i>error</i>	Specify error type (see Error table below)
<i>value</i>	An integer value specifying the threshold error count for the measurement interval. Set to zero to disable threshold crossing alerts.

Interval	Description
min15	15 minutes
hour	One hour
day	One day

Error	Description
cvl	Code Violations - Line. The total number of line code violations that have been detected during the measurement interval. A CVL is the occurrence of a Bipolar Violation (BPV).
esl	Errored Seconds - Line. The number of one-second intervals containing one or more CVLs or one or more Loss of Signal (LOS) defects.

Example: `ds1 5 pm threshold`

The following message shows the default values defined in GR-820-CORE.

```

- DS1 5
  Performance Thresholds:      15 min.      1 hour      1 day
                             -----      -
coding violations - line:      13340      40020      133400
errored seconds - line:       65        195        648
    
```

Example: `ds1 1-4 pm threshold min15 cvl 32`

Set DS1 circuits 1 to 4 for PM threshold CVLs to 32 for each 15-minute report interval.

DS1 PROTECT

Name: DS1 Protection

Purpose: Configure automatic low-speed electronics protection. The default is on.

Security: *rw* and above

Syntax: `ds1 protect [on|off]`

Field	Description
<code>protect</code>	Use the command by itself to show the current setting
<code>on</code>	Enable low-speed electronics protection. This is the default.
<code>off</code>	Disable low-speed electronics protection.

Example: `ds1 protect on`

Enable DS1 Electronics Protection.

DS1 SEND

Name: DS1 Send Code

Purpose: Configure low-speed circuit to send a code. This command permits a variety of bit pattern codes to be sent toward the low-speed or network side. Each low-speed channel includes a $2^{15}-1$ pseudo-random bit sequence (PRBS) code generator and detector (see chapter 7).

Note: Because the codes are unframed, external test equipment may indicate a loss of framing.

Security: *rw* and above

Syntax: `ds1 {number|range|list|all} send setting`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
send	Send a code pattern (see settings below)

Setting	Description
off	Send no code or stop sending code
ais	Send alarm indication signal (AIS) toward the low-speed side
cbit loopdown	Send C-bit loopdown request toward the far-end low-speed circuits on the DS3 network side using DS3 C-bit FEAC code words. DS3 C-bit parity framing mode only
cbit loopup	Send C-bit loopup request toward the far-end low-speed circuits on the DS3 network side using DS3 C-bit FEAC code words. DS3 C-bit parity framing mode only.
csu loopdown drop	Send CSU loopdown code (100) toward the low-speed side and wait for acknowledge
csu loopdown network	Send a CSU loopdown code (100) over DS3 toward the far-end low-speed circuit
csu loopup drop	Send CSU loopup code (10000) toward the low-speed side and wait for acknowledge
csu loopup network	Send CSU loopup code (10000) over DS3 toward the far-end low-speed circuit
niu loopdown drop	Send NIU loopdown code request toward DS1 drop side
niu loopdown network	Send NIU loopdown code request over DS3 toward DS1 NIU at remote end
niu loopup drop	Send NIU loopup code request toward DS1 drop side
niu loopup network	Send NIU loopup code request over DS3 toward DS1 NIU at remote end
prbs drop	Send unframed PRBS code toward the low-speed side. The manager monitors the low-speed receive to detect PRBS errors and will display the error count, error rate, and synchronization state (sync/no sync).
prbs network	Send unframed PRBS code toward the network side.
prbs test drop	Perform Automated PRBS Test of DS1 drop side. The Wide Bank will send an unframed PRBS code for 10 seconds and then display the test result.

Example: ds1 5 send csu loopup drop

Send DS1 #5 CSU loopup code toward low-speed drop side.

DS3

Name: DS3 Interface

Purpose: Show the DS3 interface settings.

Security: ro and above

Syntax: ds3

Example: ds3

```

- DS3
  ds3   circuitid "DS3"
  ds3   clock int
  ds3   clockrevert on
  ds3   equipmentid "DS3 Equip."
  ds3   equipment off
  ds3   facilityid "DS3 Path"
  ds3   frameid "Frame"
  ds3   framing cbit
  ds3   gennumber "DS3 Test Generator"
  ds3   length short
  ds3   line off
  ds3   locationid "DS3 Loc."
  ds3   loopdetect off
  ds3   payload off
  ds3   portnumber "DS3 Idle Port"
  ds3   send off
  ds3   threshold off
  ds3   unit "000000"
Performance Thresholds:
                                15 min.      1 hour      1 day
                                -----      -
coding violations - line:        0            0            0
errored seconds - line:         0            0            0
coding viols-path p-bit:        0            0            0
err seconds - path p-bit:       0            0            0
loss of signal secs - line:     0            0            0
sev err seconds - line:         0            0            0
sev err sec - path cp-bit:      0            0            0

```

DS3 CIRCUITID

Name: DS3 Circuit Identification

Purpose: Set the DS3 circuit identification string, which is used for SNMP display only.

Security: *rw* and above

Syntax: `ds3 circuitid {"string"}`

Field	Description
<code>circuitid</code>	DS3 circuit ID
<code>"string"</code>	Alphanumeric string providing transmission vendor's identification

Example: `ds3 circuitid "MULTIPLEXER-1"`

DS3 CLOCK

Name: DS3 Clock Source

Purpose: Set or show the DS3 transmit primary clock source.

CAUTION! IT IS STRONGLY RECOMMENDED THAT THE DS3 CLOCK SOURCE BE SET TO "INTERNAL" TIMING. THE WIDE BANK 28 DS3 IS AN ASYNCHRONOUS MULTIPLEXER. ASYNCHRONOUS COMMUNICATIONS DO NOT REQUIRE A COMMON CLOCK BETWEEN THE COMMUNICATING DEVICES. CHANGING THE CLOCK SOURCE TO "LINE" CAN DISRUPT SERVICE AND CAUSE DS1 TIMING SLIPS.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ds3 clock [clear|ext|int|line]`

Field	Description
<code>ds3 clock</code>	Show DS3 transmit clock source
<code>clock</code>	DS3 transmit clock source
<code>clear</code>	Clear a forced reference switch
<code>ext</code>	Use external BNC input (44.736 Mbps)
<code>int</code>	Use internal Stratum 4E clock oscillator
<code>line</code>	Recover clock from DS3 receive signal

Example: `ds3 clock int`

Set DS3 transmit clock source to use internal oscillator.

DS3 CLOCKREVERT

Name: DS3 Clock Revertive Switching

Purpose: Set or show the DS3 clock revertive switch setting. When turned on, the transmit clock will revert to the original clock source when it is considered to be healthy again.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ds3 clockrevert [off|on]`

Field	Description
<code>ds3 clockrevert</code>	Show DS3 clock revert setting
<code>clockrevert</code>	DS3 clock revert setting
<code>off</code>	Turn off revertive clock switching
<code>on</code>	Turn on revertive clock switching

Example: `ds3 clockrevert on`

DS3 EQUIPMENT

Name: DS3 Equipment Loopback

Purpose: Set the DS3 equipment loopback (see chapter 7).

Security: *rw* and above

Syntax: `ds3 equipment {off|on}`

Field	Description
<code>on</code>	Send DS3 equipment loopback toward the low-speed side
<code>off</code>	Disable DS3 equipment loopback

Example: `ds3 equipment on`

DS3 EQUIPMENTID

Name: DS3 Equipment Identification

Purpose: Set the DS3 Equipment Identification code to be sent on the C-bit parity link to the far end.

Security: *rw* and above

Syntax: `ds3 equipmentid {"string"}`

Field	Description
<code>equipmentid</code>	DS3 equipment ID
<code>"string"</code>	Alphanumeric string providing Equipment ID code

Example: `ds3 equipmentid "MUX3A"`

DS3 FACILITYID

Name: DS3 Facility Identification

Purpose: Set the DS3 Facility Identification code to be sent on the C-bit parity link to the far end.

Security: *rw* and above

Syntax: `ds3 facilityid {"string"}`

Field	Description
<code>facilityid</code>	DS3 facility ID
<code>"string"</code>	Alphanumeric string providing Facility ID code

Example: `ds3 equipmentid "MUX3A"`

DS3 FRAMEID

Name: DS3 Frame Identification

Purpose: Set the DS3 Frame Identification code to be sent on the C-bit parity link to the far end.

Security: *rw* and above

Syntax: `ds3 frameid {"string"}`

Field	Description
frameid	DS3 frame ID
"string"	Alphanumeric string providing Frame ID code

Example: `ds3 frameid "MUX3A"`

DS3 FRAMING

Name: DS3 Framing

Purpose: Set the DS3 interface framing.

Security: *rw* and above

Syntax: `ds3 framing {m23|cbit}`

Field	Description
framing	DS3 framing
m23	Set to M23 framing
cbit	Set to C-bit parity framing

Example: `ds3 framing cbit`

DS3 GENNUMBER

Name: DS3 Generator Number

Purpose: Set the DS3 Test Generator Number or Name to be sent on the C-bit parity link to the far end.

Security: *rw* and above

Syntax: `ds3 gennumber {"string"}`

Field	Description
gennumber	DS3 test generator number or name
"string"	Alphanumeric string providing Test Generator Number or Name

Example: `ds3 gennumber "MUX3A"`

DS3 LENGTH

Name: DS3 Length for Line Buildout

Purpose: Set the DS3 line buildout (LBO).

Security: *rw* and above

Syntax: `ds3 length {long|short}`

Field	Description
<code>length</code>	DS3 line buildout
<code>long</code>	50 feet or more
<code>short</code>	Less than 50 feet (default)

Example: `ds3 length long`

DS3 LINE

Name: DS3 Line Loopback

Purpose: Set the DS3 line loopback toward the DS3 interface (see chapter 7).

Security: *rw* and above

Syntax: `ds3 line {on|off}`

Field	Description
<code>line</code>	DS3 line loopback
<code>on</code>	Apply line loopback toward DS3 interface
<code>off</code>	Disable line loopback

Example: `ds3 line on`

DS3 LOCATIONID

Name: DS3 Location Identification

Purpose: Set the DS3 Location Identification code to be sent on the C-bit parity link to the far end.

Security: *rw* and above

Syntax: `ds3 locationid {"string"}`

Field	Description
locationid	DS3 location ID
"string"	Alphanumeric string providing DS3 Location ID

Example: `ds3 locationid "Denver"`

DS3 LOOPDETECT

Name: DS3 Loopcode Detection

Purpose: Set the DS3 interface setting for detection of loopcodes.

Security: *rw* and above

Syntax: `ds3 loopdetect {on|off}`

Field	Description
loopdetect	DS3 loopcode detection
on	Enable loopcode detection
off	Disable loopcode detection (default)

Example: `ds3 loopdetect on`

DS3 PAYLOAD

Name: DS3 Payload Loopback

Purpose: Set the DS3 interface setting for payload loopback toward the DS3 interface.

Security: *rw* and above

Syntax: `ds3 payload {on|off}`

Field	Description
payload	DS3 payload loopback
on	Enable payload loopback toward DS3 interface
off	Disable payload loopback (default)

Example: `ds3 payload on`

DS3 PM THRESHOLD

Name: DS3 Performance Monitor Threshold

Purpose: Set or show the threshold value for PM statistics. When the threshold is exceeded, the Wide Bank will log a CLI event and send an automatic TL1 message. The performance threshold function complies with Telcordia GR-820-CORE.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ds3 pm threshold [interval error value]`

Field	Description
<code>ds3 pm threshold</code>	Use the command by itself to show the current setting
<i>interval</i>	Specify measurement time interval (see intervals below)
<i>error</i>	Specify error type (see errors below)
<i>value</i>	An integer value specifying the threshold error count for the measurement interval. Set to zero to disable threshold crossing alerts. Maximum values for error-seconds are: 900 per 15-minute interval 3,600 per hour interval 86,400 per day interval Maximum values (register size) for cvl and cvp_p errors are: 2,147,483,647

Interval	Description
<code>min15</code>	15 minutes
<code>hour</code>	One hour
<code>day</code>	One day

Error	Description
<code>cvl</code>	Code Violations - Line. The total number of line code violations that have been detected during the measurement interval. A CVL is the occurrence of a Bipolar Violation (BPV) OR Excessive Zeros (EXZ). BPVs that are part of the zero substitution code are excluded.
<code>esl</code>	Errored Seconds - Line. The number of one-second intervals containing one or more CVLs OR one or more Loss of Signal (LOS) defects detected during the measurement interval. An ESL is the occurrence of one or more Bipolar Violations (BPVs), one or more Excessive Zeros (EXZs), or one or more Loss of Signal (LOS) defects.

Error	Description
cvp_p	Code Violations - Path P-bit. The definition of CVP-P depends on the particular DS3 application: <ul style="list-style-type: none"> • For M23 applications, CVP-P is the number of P-bit parity check Code Violations (CVs). The receipt of non-identical P-bits corresponding to the same DS3 M-Frame also constitutes a parity check CV. • For C-bit applications, both CP-bit parity Code Violations (CVCP-P) counts and CVP-P counts are defined and may be supported because they can convey different information.
esp_p	Errored Seconds - Path P-bit. The definition of CVP-P depends on the particular DS3 application: <ul style="list-style-type: none"> • For M23 applications, ESP-P is the number of one-second intervals containing one or more P-bit parity errors, one or more Severely Errored Frames (SEFs), or one or more AIS defects. • For C-bit Parity applications, SSP-P is the number of one-second intervals containing one or more ESP-P errors or ESCP-P errors. ESCP-P is the number of seconds containing one or more CP-bit parity violations, one or more Severely Errored Frames (ESFs), or one or more AIS defects.
loss_l	Loss of Signal Seconds - Line. The number of one-second intervals containing one or more Loss of Signal (LOS) defects.
sesl	Severely Errored Seconds - Line. The number of one-second intervals in which Bipolar Violations (BPVs) plus Excessive Zeros (EXZs), or one or more Loss of Signal (LOS) defects occur.
sescp_p	Severely Errored Seconds - Path CP-bit. The number of one-second intervals containing 44 or more C-bit Coding Violations (CCVs) OR one or more Out of Frame defects OR a detected incoming AIS. This count is only for the SYNTRAN and C-bit Parity DS3 applications.

Example: `ds3 pm threshold`

The following message shows the default values defined in GR-820-CORE.

```

Performance Thresholds:      15 min.      1 hour      1 day
                             -----      -----      -----
coding violations - line:    387        1161        3865
errored seconds - line:     25         75         250
coding viols-path p-bit:    382       1146       3820
err seconds - path p-bit:   25         75         250
loss of signal secs - line:  4          12         40
sev err seconds - line:     4          12         40
sev err sec - path cp-bit:  4          12         40
    
```

Example: `ds3 pm threshold min15 cvl 32`

Set PM threshold for CVLs to 32 for each 15-minute report interval.

DS3 PORTNUMBER

Name: DS3 Port Number

Purpose: Set the DS3 Port Number to be sent on the C-bit parity link to the far end.

Security: *rw* and above

Syntax: `ds3 portnumber {"string"}`

Field	Description
<code>portnumber</code>	DS3 port number
<code>"string"</code>	Alphanumeric string providing DS3 port number

Example: `ds3 portnumber "25"`

DS3 PROTECT

Name: DS3 Network Protection

Purpose: Configure DS3 network protection when using two DS3 lines. When DS3 protection is enabled, the Wide Bank will switch to the standby Controller if the DS3 interface on the active Controller has an alarm condition. The Wide Bank will not revert back to the active Controller unless revertive switching is enabled (see *REVERTIVE on page 8-67*).

Security: *rw* and above

Syntax: `ds3 protect [off|on]`

Field	Description
<code>protect</code>	DS3 network protection
<code>off</code>	Disable network protection (default). This setting will provide electronics-only protection if there are two Controllers and only one DS3 line.
<code>on</code>	Enable network protection when there are two DS3 lines

Example: `ds3 protect on`

DS3 SEND

Name: DS3 Send Code

Purpose: Configure DS3 interface to send a code toward the network. This command permits a variety of bit pattern codes to be sent toward the low-speed or network side. Each low-speed channel includes a pseudo-random bit sequence (PRBS) code generator and detector (see chapter 7).

Note: Because the codes are unframed, external test equipment may indicate a loss of framing.

Note: When *ds3 protect* is turned on, this command will transmit codes over both primary and secondary DS3s.

Security: *rw* and above

Syntax: `ds3 send {off|ais|idle|loopup|loopdown|prbs}`

Field	Description
<code>send</code>	DS3 send code setting
<code>off</code>	Send no code or stop sending code
<code>ais</code>	Send alarm indication signal (AIS) toward the DS3 network
<code>idle</code>	Send IDLE code to far-end DS3
<code>loopup</code>	Send the code to loop up the far end DS3 (C-bit framing only)
<code>loopdown</code>	Send the code to loop down the far end DS3 (C-bit framing only)
<code>prbs</code>	Send unframed PRBS code toward the DS3 network

Example: `ds3 send idle`

DS3 THRESHOLD

Name: DS3 Threshold

Purpose: Specify the bit error rate that, when exceeded, triggers a protection switch to the standby DS3 Controller card. The bit error rate (BER) is specified as a power of 10, as in 10^{-n} where $n=4, 5, 6, 7, \text{ or } 8$.

Security: *rw* and above

Syntax: `ds3 threshold {4|5|6|7|8}`

Field	Description
threshold	DS3 Bit Error Rate threshold
4	BER > 1×10^{-4} . Maximum detection time = 100 ms
5	BER > 1×10^{-5} . Maximum detection time = 1 second
6	BER > 1×10^{-6} . Maximum detection time = 10 seconds
7	BER > 1×10^{-7} . Maximum detection time = 100 seconds
8	BER > 1×10^{-8} . Maximum detection time = 1000 seconds

Example: `ds3 threshold 5`

DS3 UNIT

Name: DS3 Unit Code

Purpose: Set the DS3 Unit code to be sent on the C-bit parity link to the far end.

Security: *rw* and above

Syntax: `ds3 unit {"string"}`

Field	Description
unit	DS3 unit code
"string"	Alphanumeric string providing DS3 Unit code

Example: `ds3 unit "27"`

EQUIPMENT

Name: Equipment Configuration

Purpose: Display list showing what hardware and software is present and what redundant electronics exist.

Security: *ro* and above

Syntax: `equipment`

Message:

```

Equipment          Status
-----
DS3 Controller A   Active
DS3 Controller B   Card not present
DS1 Card 1         Active
DS1 Card 2         Active
DS1 Card 3         Active
DS1 Card 4         Active
DS1 Card 5         Active
DS1 Card 6         Active
DS1 Card 7         Active
DS1 Spare Card     Active
    
```

Equipment	Status	Description
DS3 Controller A/B	Active	Controller card is installed and in active mode (DS3 circuit is active)
	Standby	Controller is installed and in standby mode
	Not Present	Controller is not installed
	Not Ready	Controller is present but is not communicating with the active card for unknown reasons
	Fail	Controller hardware failure
DS1/E1 Card	Active	DS1/E1 card is installed and active but individual DS1/E1 circuits may have failed and be on Spare card
	Not Present	DS1/E1 card is not installed
	MSO Active	DS1/E1 MSO card (relay and electronics) is installed and active but individual DS1/E1 circuits may have failed and be on Spare card
	MSO Relay Only Active on Spare	DS1/E1 MSO relay card is installed but electronics card is missing. Circuits have been switched to Spare card.
	MSO Relay Only Not Active	DS1/E1 MSO relay card is installed but electronics card is missing. Circuits have been switched to Spare card.
	MSO Relay Only Conflict On Spare	DS1/E1 MSO relay card is installed but electronics card is missing. Multiple MSO card removals prevent switching circuits to Spare.
	MSO Relay Only Spare Not Present	DS1/E1 MSO relay card is installed but electronics card is missing. Circuits cannot be switched because Spare card is not installed.
	Wrong Card for Mode	System mode is set to DS1 when E1 card is installed, or vice versa. Status applies to both MSO and non-MSO card types.

Equipment	Status	Description
DS1/E1 Card Spare	Active	DS1/E1 card is installed and active, but individual DS1/E1 circuits may have failed
	Not Present	DS1/E1 card is not installed
	MSO Active	DS1/E1 MSO card (relay and electronics) is installed and active but individual DS1/E1 circuits may have failed
	MSO Relay Only Spare Not Present	DS1/E1 MSO relay card is installed but electronics card is missing. Circuits cannot be switched without spare electronics.
	Conflict	Multiple MSO card removals prevent switching circuits to Spare
	Wrong Card for Mode	System mode is set to DS1 when E1 card is installed, or vice versa. Status applies to both MSO and non-MSO card types.

EXIT

Name: Exit Session

Purpose: End the current session. The current user is logged out of the CLI. If security is on, a user name (and password, if applicable) is required to log in again.

Security: *ro* and above

Syntax: `exit`

Example: `exit`

End the current session and log off from CLI.

FFO PRESENT

Name: Fan Faceplate Option Present

Purpose: Specify whether an alarm will be generated if the fan faceplate is not present or is removed. The default is off.

Note: When an FFO-capable Controller is powered up or a fan faceplate is removed and then reinstalled, the Controller will detect the fan faceplate and set ffo present on.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ffo present [on|off]`

Field	Description
ffo present	Use the command by itself to show the current setting
present	Configure FFO alarm response
on	Enable FFO alarm if fan faceplate is not present or is removed
off	Disable FFO alarm (default)

Example: `ffo present on`

HELP, ?

Name: **Help**

Purpose: Use this command to display a list of available commands. There are two levels of help provided by typing **?** or **help**. The information displayed depends on the user security level.

Security: *ro* and above

Syntax: `[command name] {?|help}`

Field	Description
command name	Type the command name for which you want to obtain help
?	Displays the command and a list of its first level of parameters
help	Displays the command and all its parameters if there is more than one level of options

Example: `help`

```
? ..... For partial command help, type ? after
           entering any partial command in question
help ..... For full command help, type "help" after
           entering any partial command in question
```

Example: `ip help`

```
ip ..... Set/Display IP Addresses xxx.xxx.xxx.xxx
  address ipaddr ..... Set IP Address
  mask    ipaddr ..... Set Subnet Mask
  gateway ipaddr ..... Set IP Address of Gateway
  nms1    ipaddr ..... Set IP Address of NMS1 (trap)
  nms2    ipaddr ..... Set IP Address of NMS2 (trap)
  nms3    ipaddr ..... Set IP Address of NMS3 (trap)
  ppp     ipaddr ..... Set IP Address of Other End of PPP Link
  route  ..... Set Route for Outbound IP Traffic
           ethernet ..... Ethernet
           ppp ..... PPP over DS3 Path Maintenance Data Link
```

HOURL

Name: Hour Performance Report

Purpose: Show the one-hour performance report for an interface. The performance statistics displayed conform to SNMP MIBs 1406 and 1407 reporting requirements.

For 24-hour statistics, see *DAY* on page 8-19.

Security: ro and above

Syntax: hour {ds1 number|ds3|ds3far}

Field	Description
ds1 number	Display performance for a DS1, where number = 1 to 28
ds3	Display performance for the DS3 interface
ds3far	Display performance for far-end DS3 (valid only with C-bit framing)

Example: hour ds1 5

15-Minute Interval Statistics for DS1 1 at 06:08:23 05/09/2001

STATISTIC \ INTERVAL	Current	1	2	3	4	Hour
Unavailable Sec	0	0	-	-	-	0
Sev Errored Sec	0	0	-	-	-	0
Errored Sec	0	3	-	-	-	3
Loss of Signal Sec	0	0	-	-	-	0
Line Errored Sec	0	3	-	-	-	3
Controlled Slip Sec	0	0	-	-	-	0
Degraded Min	0	0	-	-	-	0
Protected Sec	0	0	-	-	-	0
Loopback Sec	0	0	-	-	-	0
PRBS Sync Sec	0	2	-	-	-	2
Protected Cnt	0	0	-	-	-	0
LCV Error Cnt	0	371	-	-	-	371
PRBS Error Cnt	0	66	-	-	-	66
Elapsed Sec	175	LCV Error Rate				0
Valid Intervals	1	PRBS Error Rate				No Sync.

Example: hour ds3far

15-Minute Interval Statistics for Far-end DS3 at 06:09:47 05/09/2001

STATISTIC \ INTERVAL	Current	1	2	3	4	Hour
FE Unavailable Sec	0	0	0	0	0	0
FE C-bit Sev Err Sec	0	0	0	0	0	0
FE C-bit Errored Sec	0	0	0	0	0	0
FE C-Parity Err Cnt	0	0	0	0	0	0

CLI Commands and Messages

CLI Command List

Elapsed Sec	N/A	LCV Error Rate	N/A
Valid Intervals	N/A	P-Parity Error Rate	N/A
FE Elapsed Sec	587	C-Parity Error Rate	N/A
FE Valid Intervals	96	FE C-Parity Err Rate	0

IP

Name: IP Configuration

Purpose: Configure the IP address, gateway, mask, and trap receiver addresses.

Security: Set - *rw* and above with basic security; *secu* with Security Upgrade
Show - *ro* and above

See *Security on page 1-5* for an overview of basic security and the Security Upgrade option.

Syntax: `ip [address|mask|gateway|nms1|nms2|nms3|
ppp ipaddr|route {ethernet|ppp addr}]`

Field	Description
ip	Use the command by itself to see current settings
address	Set Wide Bank primary Controller address
mask	Set subnet mask for LAN
gateway	Set IP address for the LAN gateway
nms1	Set Network Management System (NMS) #1 to receive SNMP Trap notifications
nms2	Set NMS #2 to receive SNMP Trap notifications
nms3	Set NMS #3 to receive SNMP Trap notifications
ppp	Set IP address or route to other end of PPP link
<i>ipaddr</i>	IP address in the form xxx.xxx.xxx.xxx, where xxx is a number from 0 to 255
route	Configure route for outbound IP traffic via Ethernet or PPP
ethernet	Send outbound packets to the Ethernet port, except those destined for the PPP link (based on value of "ip ppp ipaddress")
ppp	Send outbound packets to the C-bit PPP link using DS3 Path Maintenance Data Link
<i>addr</i>	PPP address in the form xxx.xxx.xxx.xxx, where xxx is a number from 0 to 255

Example: ip

```
ip address 192.168.3.161
ip mask 255.255.255.0
ip gateway 192.168.3.202
ip nms1 192.168.3.233
ip nms2
ip nms3
```

Example: ip address 192.168.90.2

Modifying IP address will affect ability to remotely manage this unit.
The IP address for remote management will be 192.168.90.2
Do you want to update the IP address now (y/n)?

Set IP address of Wide Bank primary Controller.

Example: ip mask 255.255.255.0

Set subnet mask.

Example: ip nms1 192.168.95.17

Set NMS2 IP address for reporting traps.

Example: ip route ppp 192.168.90.40

Set route for outbound packets over C-bit PPP link.

LOAD

Name: Load Software

Purpose: Initiate a download of Wide Bank software from a management PC or a network TFTP server to the Wide Bank. See *Downloading New Software on page 6-23* for the downloading procedure.

Security: rw and above

Syntax: load {xmodem|tftp} ipaddress "filename"

Field	Description
xmodem	Download software via XModem
tftp	Download software via TFTP
ipaddress	Host IP address of TFTP server, in the form xxx.xxx.xxx.xxx, where xxx is a number from 0 to 255.
"filename"	Set Network Management System (NMS) #1 to receive SNMP Trap notifications

Example: `load xmodem`

Initiates a download from a terminal emulation program using Xmodem protocol. The file name is entered in the terminal emulation program.

Example: `load tftp 192.168.2.90 "c:\directory\filename"`

Initiates a download from a TFTP server on the LAN. The path and file name must be enclosed in quotes.

LOG

Name: `Log`

Purpose: Show event history.

Security: *ro* and above

Syntax: `log`

Index	Time	Date	Alarm
----	----	----	-----
9	01:00:30	01/01/97	Self Test Pass
8	01:00:02	01/01/97	DS3 Test Pass
7	01:00:00	01/01/97	Power on
6	01:01:45	01/01/97	Log out
5	01:00:35	01/01/97	Log in
4	01:00:29	01/01/97	Self Test Pass
3	01:00:03	01/01/97	DS3 Test Pass
2	01:00:00	01/01/97	Default Configuration Installed
1	01:00:00	01/01/97	Power on

LS

Name: `LS Configuration Settings`

Purpose: Show the DS1 or E1 low-speed interface settings. The command followed by the interface number displays the current configuration. The command, with a move option, gives control of a low-speed interface to a spare circuit for maintenance or when a low-speed card is to be removed.

Note: When the LSMODE is set to DS1, you must use the *DSI* commands. When the LSMODE is set to either DS1LS or E1LS, you must use the *LS* commands. The *LS* command operates just like the *DSI* command, except that the responses are specific to the DS1 or E1 interface type. In the DS1LS mode, the low-speed references in command responses are the same as for the DS1 mode. In E1LS mode, the low-speed references in command responses are for E1 (each E1 card has only three active circuits; the fourth, unused, circuit on an E1 card is called CIR). See *LSMODE on page 8-58* and *DSI on page 8-21*.

Security: *ro* and above

Syntax: `ls {number|range|list|all}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces

Example: `ls 5`

```

- LS Circuit 5
  ds1 5   circuitid "DS1 5"
  ds1 5   enable
  ds1 5   equipment off
  ds1 5   length dsx0
  ds1 5   line off
  ds1 5   linecode b8zs
  ds1 5   loopdetect off
  ds1 5   metallic off
  ds1 5   send off
Performance Thresholds:
-----
coding violations - line:      0      0      0
errored seconds - line:       0      0      0
  
```

Example: `ls all`

Display configuration settings for all low-speed interfaces.

LS AINS

Name: **LS Automatic In-Service Detection**

Purpose: Set low-speed alarm mode for automatic detection of new service connections. This command allows service providers to configure low-speed drops before connections or facilities are available. When automatic in-service detection is enabled, a disabled low-speed channel can be enabled (set in service) while a Loss of Signal (LOS) condition is present, and the Wide Bank will inhibit LOS alarm reporting for that channel until a new service connection has been established for the specified delay time.

Note: Following a DC power interruption, the LOS inhibit will be disabled on all channels, causing an LOS alarm on any DS1 or E1 that is enabled but not in service.

Note: A channel's LOS inhibit will also be disabled immediately if any of the following events occur:

- the channel is disabled (set out of service)
- a hardware failure occurs on the channel
- a metallic loopback is run on the channel
- the channel is manually moved to a spare
- the channel's card is removed.

However, if a channel is disabled and then re-enabled while an LOS condition is present, the automatic in-service detection will again inhibit the LOS alarm.

Auto in-service detection is applied on a channel-by-channel basis. If service is discontinued on a channel, automatic in-service detection can be reapplied to that channel by placing it out of service and then back in service (see *LS ENABLE/DISABLE on page 8-53*).

To quickly provision automatic in-service detection when turning up a new Wide Bank, first turn on automatic in-service detection and then place all DS1s or E1s out of service and then back in service.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ls ains [on|off|delay time]`

Setting	Description
<code>ls auto/in service</code>	Use the command by itself to show the current setting
<code>on</code>	Enables automatic detection of new low-speed service on channels that are subsequently enabled, and inhibits LOS alarms until a new service has been connected for at least 2 minutes
<code>off</code>	Disables automatic in-service detection and allows LOS alarms on all low-speed channels

Example: `ls ains on`

Enable automatic in-service detection of all low-speed channels that are subsequently enabled.

Example: `ls ains delay 12`

Set automatic in-service delay to 12 hours.

LS CIRCUITID

Name: LS Circuit Identifier

Purpose: Set the low-speed circuit identification string (transmission vendor's identification), which is used for SNMP display only.

Security: *rw* and above

Syntax: `ls {number|range|list|all} circuitid {"string"}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
circuitid	Set low-speed circuit identification string
<i>"string"</i>	Alphanumeric string enclosed in quotes, as per RFC 1406 requirement for SNMP MIBs

Example: `ls 1 circuitid "MUX2-1"`

Set LS #1 circuit identifier.

LS ENABLE/DISABLE

CAUTION! DISABLING AN INTERFACE WILL DISRUPT SERVICE.

Name: LS Interface Enable/Disable

Purpose: Activate or deactivate a low-speed interface (normally used for SNMP managed systems).

Security: *rw* and above

Syntax: `ls {number|range|list|all} {enable|disable}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
enable	Activate low-speed interface
disable	Deactivate low-speed interface

Example: `ls 8 disable`

Disable DS1 #8.

LS EQUIPMENT

Name: LS Equipment Loopback

Purpose: Set equipment loopback toward low-speed side (see chapter 7).

Security: *rw* and above

Syntax: `ls {number|range|list|all} equipment {on|off}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
equipment	Send equipment loopback toward low-speed side
on	Apply equipment loopback
off	Remove equipment loopback

Example: `ls 2 equipment on`

Apply LS #2 equipment loopback.

LS LENGTH

Name: LS Length for Line Buildout

Purpose: Set the DS1 line buildout (LBO) based on line length required for making cable connections to DSX-1 crossconnect equipment. Not available for E1 circuits.

Security: *rw* and above

Syntax: `ls {number|range|list|all} length
{dsx0|dsx110|dsx220|dsx330|dsx440|dsx550}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
length	equipment loopback toward low-speed side
dsx0	Set for 0 to 110 feet
dsx110	Set for 110 to 220 feet
dsx220	Set for 220 to 330 feet
dsx330	Set for 330 to 440 feet
dsx440	Set for 440 to 550 feet
dsx550	Set for 550 to 660 feet

Example: `ls 5-8 length dsx220`

Set LS #5 through #8 for line buildout of 330 to 440 feet.

LS LINE

Name: LS Line Loopback

Purpose: Configure line loopback toward low-speed side (see chapter 7).

Security: *rw* and above

Syntax: `ls {number|range|list|all} line {on|off}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
line	Send line loopback toward low-speed side
on	Apply line loopback
off	Remove line loopback

Example: `ls 9 line on`

Apply LS #9 line loopback.

LS LINECODE

Name: LS Line Coding

Purpose: Set line coding for low-speed circuits. DS1 circuits use AMI or B8ZS. E1 circuits are fixed at HDB3.

Security: *rw* and above

Syntax: `ls {number|range|list|all} linecode {ami|b8zs}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
linecode	Configure DS1 line coding. E1 circuits are fixed at hdb3 (High Density Bipolar 3).
ami	Alternate Mark Inversion
b8zs	Binary 8-Zero Substitution

Example: `ls 10 linecode b8zs`

Set LS #10 for B8ZS line coding.

LS LOOPDETECT

Name: LS Loopcode Detection

Purpose: Configure low-speed channel for detection of bit pattern loopcodes.

Security: *rw* and above

Syntax: `ls {number|range|list|all} loopdetect {on|off|niu|cbit}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
loopdetect	Configure loopcode detection
on	Enable loopcode detection
off	Disable loopcode detection
niu	Enable NIU loopcode detection only – turns off C-bit detection
cbit	Enable C-bit loopcode detection only – turns off NIU detection

Example: `ls 11 loopdetect on`

Set LS #11 to detect loopcodes.

LS METALLIC

Name: LS Metallic Loopback

Purpose: Configure metallic loopback toward low-speed side (see chapter 7). Metallic loopbacks can only be applied to a maximum of four LS channels, one per protection group.

Security: *rw* and above

Syntax: `ls {number|range|list|all} metallic {on|off}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
metallic	Send metallic loopback toward low-speed side
on	Apply metallic loopback
off	Disable metallic loopback

Example: `ls 11 metallic on`

Apply LS #11 metallic loopback.

LSMODE

Name: Low-Speed Mode

Purpose: Set the low-speed mode on the Wide Bank 28 DS3. The CLI will behave accordingly, regardless of the type of low-speed circuits present in your Wide Bank. This command allows you to configure CLI operation to respond to legacy DS1 commands or to new low-speed (LS) commands for DS1 or E1 circuit configurations. When the LSMODE is set to DS1, you must use the *DS1* commands.

Note: When the LSMODE is set to DS1, you must use the *DS1* commands. When the LSMODE is set to either DS1LS or E1LS, you must use the *LS* commands. The *LS* command operates just like the *DS1* command, except that the responses are specific to the DS1 or E1 interface type. In the DS1LS mode, the low-speed references in command responses are the same as for the DS1 mode. In E1LS mode, the low-speed references in command responses are for E1 (each E1 card has only three active circuits; the fourth, unused, circuit on an E1 card is called CIR). See *DS1 on page 8-21* and *LS on page 8-50*.

Security: *rw* and above

Syntax: `lsmode {ds1|ds1ls|e1ls}`

Field	Description
ds1	Set to DS1 mode using DS1 commands to configure the DS1 interfaces. This is the default mode and is compatible with legacy Wide Banks having only DS1 low-speed cards.
ds1ls	Set to DS1LS mode using LS commands to configure the DS1 interfaces
e1ls	Set to E1LS mode using LS commands to configure the E1 interfaces

Example: `lsmode ds1ls`

Set CLI to use LS commands to configure DS1 circuits.

Example: `lsmode ds1`

Set CLI to use legacy DS1 commands to configure DS1 circuits.

LS MOVE

Name: LS Move Channel

Purpose: Move low-speed channel to home card or spare card. Moving a circuit home does not reset the revertive state (*REVERTIVE* on page 8-67).

Security: *rw* and above

Syntax: `ls {number|range|list|all} move {home|spare}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
all	All low-speed interfaces
move	Move low-speed channel
home	Move channel to home card
spare	Move channel to spare card

Example: `ls 13 move spare`

Move LS #13 from home card to spare card.

LS PM THRESHOLD

Name: LS Performance Monitor Threshold

Purpose: Set or show the threshold value for PM statistics. When the threshold is exceeded, the Wide Bank will log a CLI event and send an automatic TL1 message. The performance threshold function complies with Telcordia GR-820-CORE.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ls {number|range|list} pm threshold [interval error value]`

Field	Description
ls pm threshold	Use the command by itself to show the current setting
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
<i>interval</i>	Specify measurement time interval (see Interval table below)
<i>error</i>	Specify error type (see Error table below)
<i>value</i>	An integer value specifying the threshold error count for the measurement interval. Set to zero to disable threshold crossing alerts.

Interval	Description
min15	15 minutes
hour	One hour
day	One day

Error	Description
cvl	Code Violations - Line. The total number of line code violations that have been detected during the measurement interval. A CVL is the occurrence of a Bipolar Violation (BPV).
esl	Errored Seconds - Line. The number of one-second intervals containing one or more CVLs or one or more Loss of Signal (LOS) defects.

Example: `ls 5 pm threshold`

The following message shows the default values defined in GR-820-CORE.

```
- LS Circuit 5
Performance Thresholds:      15 min.      1 hour      1 day
                             -----
coding violations - line:    13340      40020      133400
errored seconds - line:      65        195        648
```

Example: `ds1 1-4 pm threshold min15 cvl 32`

Set DS1 circuits 1 to 4 for PM threshold CVLs to 32 for each 15-minute report interval.

LS PROTECT

Name: LS Protection

Purpose: Configure automatic low-speed electronics protection.

Security: Set - *rw* and above
Show - *ro* and above

Syntax: `ls protect [on|off]`

Field	Description
<code>ls protect</code>	Use the command by itself to show the current setting.
<code>protect</code>	Set the electronics protection mode
<code>on</code>	Enable low-speed electronics protection. This is the default.
<code>off</code>	Disable low-speed electronics protection.

Example: `ls protect on`

Enables the DS1 Electronics Protection. This is the default.

LS SEND

Name: LS Send Code

Purpose: Configure low-speed circuit to send a code. This command permits a variety of bit pattern codes to be sent toward the low-speed or network side. Each low-speed channel includes a pseudo-random bit sequence (PRBS) code generator and detector. (see chapter 7).

Security: *rw* and above

Syntax: `ls {number|range|list|all} send {setting}`

Field	Description
<i>number</i>	Low-speed interface number, 1 to 28
<i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
<i>list</i>	A list of low-speed channels separated by commas as in 1,3,5,9
<code>all</code>	All low-speed interfaces
<code>send</code>	Send a code pattern (see settings in following table)

Setting	Description
off	Send no code or stop sending code
ais	Send alarm indication signal (AIS) toward the low-speed side
cbit loopup	Send C-bit loopup request toward the far-end low-speed circuits on the DS3 network side using DS3 C-bit FEAC code words. DS3 C-bit parity framing mode only.
cbit loopdown	Send C-bit loopdown request toward the far-end low-speed circuits on the DS3 network side using DS3 C-bit FEAC code words. DS3 C-bit parity framing mode only
cbit loopup drop	Send CSU loopup code (10000) toward the low-speed side and wait for acknowledge
csu loopup drop	Send CSU loopup code (10000) toward the low-speed side and wait for acknowledge
csu loopup network	Send a C-bit loopup code toward the far-end low-speed circuit on the DS3 csu network side. DS3 M23 framing mode only
csu loopdown drop	Send CSU loopdown code (100) toward the low-speed side and wait for acknowledge
csu loopdown network	Send a C-bit loopdown code toward the far-end low-speed circuit on the DS3 csu network side. DS3 M23 framing mode only
niu loopup	Send NIU loopup code request over DS3 toward DS1 NIU at remote end
niu loopdown	Send NIU loopdown code request over DS3 toward DS1 NIU at remote end
prbs drop	Send PRBS code toward the low-speed side. The manager monitors the low-speed receive to detect PRBS errors and will display the error count, error rate, and synchronization state (sync/no sync).
prbs network	Send PRBS code toward the network side
prbs test drop	Perform Automated PRBS Test of DS1 drop side. The Wide Bank will send PRBS for 10 seconds and then display the test result.

Example: `ls 5 send csu loopup drop`

Send ls #5 csu loopup code toward low-speed drop side.

PING

Name: Ping

Purpose: Use the Ping command (ICMP echo) to test whether or not the management node (or other host) on the network is responding.

Security: *ro* and above

Syntax: ping {*ipaddress*} [*number*] [*delay*]

Field	Description
<i>ipaddress</i>	IP address of the device to query.
<i>number</i>	The number of pings to send. If a number is not specified, the system will send one ping request.
<i>delay</i>	The delay between pings, 500 to 5000 ms. (optional)

Example: ping 172.26.100.25 3

Send three ping queries to a networked device with IP address of 172.26.100.25.

PROGRAM FLASH

Name: Program Flash Memory

Purpose: Program the flash memory with the software previously loaded into RAM by the LOAD command, if you did not choose to program the flash during the download process. See *LOAD* on page 8-49.

There are no options for this command. See *Downloading New Software* on page 6-23 for more detail.

Security: *rw* and above with basic security; *admin* and above with Security Upgrade

See *Security* on page 1-5 for an overview of basic security and the Security Upgrade option.

Syntax: program flash

RESTORE

Name: Restore Configuration

Purpose: Use this command to restore the factory default configuration, download a previously saved TFTP configuration, or retrieve the temp copy from RAM. See *SAVE* on page 8-68 and *TEMP COPY* on page 8-79.

This command will not change the Wide Banks's IP address, user names, or passwords.

Security: *rw* and above with basic security; *secu* with Security Upgrade

See *Security on page 1-5* for an overview of basic security and the Security Upgrade option.

Syntax: `restore {defaults|temp copy|tftp ipaddr "filename"}`

Field	Description
defaults	Restore the factory defaults. See table below.
temp copy	Retrieve a temp copy from RAM (see <i>TEMP COPY on page 8-79</i>)
tftp	Retrieve a previously saved configuration file from a TFTP server (see <i>SAVE on page 8-68</i>)
<i>ipaddr</i>	IP address of TFTP server where file is located, in the format xxx.xxx.xxx.xxx where xxx is a number from 0 to 255
<i>"filename"</i>	File name including path. Must be enclosed in quotes.

Example: `restore tftp 192.128.17.10 "configuration"`

Restore the configuration file from TFTP server.

Example: `restore defaults`

Restore the factory default settings (see table below).

Parameter	Default	Comments
alarmout	no	normally open contacts
alarms protected ds3_selftest	minor	standby Controller fail
arm	on	
autocopy	on	
ds1 <i>n</i>	enable	<i>n</i> = 1 to 28
ds1 <i>n</i> circuitid	"DS1 <i>n</i> "	<i>n</i> = 1 to 28
ds1 <i>n</i> equipment	off	
ds1 <i>n</i> length	dsx0	
ds1 <i>n</i> line	off	
ds1 <i>n</i> linecode	b8zs	
ds1 <i>n</i> loopdetect	off	
ds1 <i>n</i> metallic	off	
ds1 <i>n</i> send	off	
ds1 ains	off	auto in-service detection
ds1 ains delay	2	hours
ds1 protection	on	
ds3 circuitid	"DS3"	

Parameter	Default	Comments
ds3 clock	int	
ds3 clockrevert	on	
ds3 equipment	off	
ds3 framing	m23	
ds3 length	short	
ds3 line	off	
ds3 loopdetect	off	
ds3 payload	off	
ds3 protection	off	
ds3 send	off	
ds3 threshold	off	
ffo present	off	When an FFO-capable Controller is powered up or a fan faceplate is removed and reinstalled, the Controller will detect the fan faceplate and set ffo present on.
ip address		none
ip gateway		none
ip mask		none
ip nms1		none
ip nms2		none
ip nms3		none
revertive ds1	off	
revertive ds3	on	
screen	24	
security		This setting is not changed by the <i>restore defaults</i> command.
snmp contact	"Contact"	
snmp getcomm	"public"	
snmp location	"Location"	
snmp name	"Name"	
snmp setcomm	"public"	
snmp trapcomm	"public"	

Parameter	Default	Comments
tl1 networkid	""	
tl1 password	""	
tl1 portnumber	9999	

RESULTS

Name: Results of Test

Purpose: Show the results from the last test performed on an interface. Tests are activated by the *test* command (see *TEST* on page 8-79).

This command is performed automatically when the test command executes. You can also use this command at any time to display the most recent results of a test. For example, if the unit was just powered up, the *test all* option will show the results of the power-on self-test.

Security: *ro* and above

Syntax: `results {all|ds1 [number|range|all]|
ds1card [n|spare]|ds3|fan [n|all]}`

Field	Description
all	Show results for all tests
ds1 number	Show results for low-speed DS1/E1 interface number, 1 to 28
ds1 range	Show results for a range of low-speed channels. Range is separated by a hyphen as in 5-8
ds1 all	Show results for all low-speed interfaces
ds1card n	Show results for DS1 card number, 1 to 7
ds1card spare	Show results for spare card
ds3	Show results for high-speed DS3 interface
fan n	Show results for fan number, A or B
fan all	Show results for both fans

Example: `results all`

```
DS1 Card 1      Self Test: Pass
DS1 Card 2      Self Test: Pass
DS1 Card 3      Self Test: Pass
DS1 Card 4      Self Test: Pass
DS1 Card 5      Self Test: Pass
DS1 Card 6      Self Test: Pass
DS1 Card 7      Self Test: Pass
DS1 Spare Card  Self Test: Pass
```

```

DS3                Self Test: Pass

Fan A              Self Test: Fan not present
Fan B              Self Test: Fan not present
  
```

REVERTIVE

Name: Revertive Mode

Purpose: Set or show the revertive switching mode. The high-speed and low-speed can be controlled independently. When *revertive ds3* is on, *arm* is automatically turned on (see *ARM on page 8-13*).

Security: Set - *rw* and above
Show - *ro* and above

NOTE: The `revertive [on|off]` command is obsolete but will continue to work in release 2.41. Please use the new `revertive ds3 [on|off]` command to ensure future compatibility.

Syntax: `revertive ds3 [on|off]`

Syntax: `revertive ds1 [on|off|reset]`

`revertive ls [on|off|reset]`

Field	Description
revertive	Set high-speed or low-speed revertive switching mode. Use the command with DS3, DS1, or LS to show current setting.
ds3	High-speed revertive mode
ds1	Low-speed revertive mode used when LSMODE is set to DS1 (see <i>LSMODE on page 8-58</i>). Note: If three protection switches occur within a 24-hour period, the low-speed circuit on the spare will be locked out and will not revert back to home. Use reset option (see below) to remove the lockout.
ls	Low-speed revertive mode used when LSMODE is set to DS1LS or E1LS (see <i>LSMODE on page 8-58</i>). Note: If three protection switches occur within a 24-hour period, the low-speed circuit on the spare will be locked out and will not revert back to home. Use reset option (see below) to remove the lockout.
on	Enable revertive switching
off	Disable revertive switching
reset	Reset low-speed revertive lockout. When revertive switching is on, this command will also move the low-speed circuit back to the home card.

Example: `revertive ds1 on`

Turn on low-speed revertive switching.

Example: `revertive ds1`

```
revertive ds1 on
```

SAVE

Name: Save Configuration

Purpose: Save the current Wide Bank configuration to a TFTP server file. To restore a configuration file, see *RESTORE* on [page 8-63](#).

This command generates a configuration file organized into sections, with an appropriate comment preceding each section. Configuration items that regard security are NOT included (for example, security and user commands). However, configuration files can be manually edited using a text editor, and items such as security and users can be added to the file.

The configuration file contains a list of valid Wide Bank commands and settings. Comments within this file use the # character. Any text between a # and end-of-line is not processed as a configuration item. If errors are encountered while parsing the configuration file, the line numbers on which the errors occurred will be displayed. Also, if privilege restrictions are encountered (a command exists in the configuration that the current user does not have privilege to execute), those errors will be displayed as well.

Security: *rw* and above with basic security; *admin* and above with Security Upgrade

See *Security* on [page 1-5](#) for an overview of basic security and the Security Upgrade option.

Syntax: `save tftp ipaddr {"filename"}`

Field	Description
<code>tftp</code>	Save the configuration as a file on a TFTP server.
<code>ipaddr</code>	IP address of TFTP server where the file is to be saved.
<code>"filename"</code>	File name including path. Must be enclosed in quotes.

Example: `save tftp 192.128.17.10 "configuration"`

Save the configuration file to TFTP server.

SCREEN

Name: Screen Size

Purpose: Set or show the size of the CRT screen in lines. (The screen always has 80 columns.) This command allows the display to show a fixed number of lines before halting and waiting for a user prompt. A value of zero produces continuous scrolling text without stopping.

Security: *ro* and above

Syntax: `screen [lines]`

Field	Description
<code>screen</code>	Use the command by itself to show the current setting
<code>lines</code>	Set number of lines to display on each screen. A value of zero will enable continuous scrolling without stopping. Setting value to 0 will produce a continuous display (scroll) of lines. When setting is not 0, for example 24, the display stops after the specified number of lines and displays a “more” prompt. Pressing Enter key displays one more line. Pressing the Space Bar displays the next 24 lines. Pressing Escape key clears any remaining text.

Example: `screen 24`

Set the screen display to 24 lines.

Example: `screen 0`

Enable screen to scroll without stopping. (This setting is useful when capturing configuration settings and reports to a text file.)

NOTE: With continuous scrolling, it may be necessary to adjust the terminal program buffer size to capture any lines that scroll off the viewing area.

SECURITY

Name: Security Password Protection

Purpose: Enable or disable password protection.

NOTE: The factory default is usually OFF so that installers can quickly configure the unit. However, this setting can be changed or preset to ON, so that the user must enter a password if one has been defined. For added security, this setting is not affected by the *restore defaults* command.

Security: Set - *admin* and above
Show - *ro* and above

Syntax: `security [on|off]`

Field	Description
<code>security</code>	Use the command by itself to show the current setting
<code>on</code>	Enable password protection
<code>off</code>	Disable password protection

Example: `security on`
Turn on security password protection.

Example: `security`
`security on`

SECURITY CLI

Name: Security CLI Time-Out

Purpose: Set the time-out period for a CLI session. The time-out period applies to RS-232 and Telnet CLI sessions.

Security: Set - *admin* with basic security; *secu* with Security Upgrade
Show - *ro* and above

Syntax: `security cli [time]`

Field	Description
<code>security cli</code>	Use the command by itself to show the current setting.
<code>time</code>	The number of minutes of inactivity before a CLI session times out. Valid values are from 0 to 255 minutes. A value of 0 means there is no time-out period. The default is 15 minutes.

Example: `security cli 30`
CLI timeout = 30 minutes

SECURITY ETHERNET

Name: Security Ethernet Port Enable/Disable

Purpose: Disable the Ethernet port to prevent unauthorized SNMP, TCP/IP TL1, and Telnet sessions. This command is available only with the Security Upgrade option (see *Security on page 1-5*).

NOTE: If you disable the Ethernet port, you cannot also disable the RS-232 CLI port. The RS-232 CLI port must remain active to provide CLI management access.

Security: *secu*

Syntax: `security ethernet [enable|disable]`

Field	Description
<code>security ethernet</code>	Use the command by itself to show the current setting
<code>enable</code>	Enable the Ethernet port (default)
<code>disable</code>	Disable the Ethernet port

Example: `security ethernet disable`

```
Disabling this port will affect the ability to remotely
manage this unit. It will not be possible to remotely
manage this unit on IP Address nnn.nnn.nnn.nnn
```

```
Do you want to disable the Ethernet port now (y/n)?
```

SECURITY RS232CLI

Name: Security RS-232 CLI Port Enable/Disable

Purpose: Disable the 9-pin RS-232 CLI port to prevent unauthorized CLI sessions. This command is available only with the Security Upgrade option (see *Security on page 1-5*).

NOTE: If you disable the RS-232 CLI port, you cannot also disable the Ethernet port. The Ethernet port must remain active to provide CLI management access. Before disabling the CLI port, you must assign a valid IP address to the Wide Bank (cannot be null, 0.0.0.0, or 255.255.255.255). See *Configuring IP and PPP Addresses on page 6-15* for information about setting the IP address.

Security: *secu*

Syntax: `security rs232cli [enable|disable]`

Field	Description
<code>security rs232cli</code>	Use the command by itself to show the current setting
<code>enable</code>	Enable the RS-232 CLI port (default)
<code>disable</code>	Disable the RS-232 CLI port

Example: `security rs232cli disable`

Disabling this port will disable the ability to locally manage this unit. Remote management will be possible on IP Address `nnn.nnn.nnn.nnn`

Do you want to disable the CLI port now (y/n)?

SECURITY RS232TL1

Name: Security RS-232 TL1 Port Enable/Disable

Purpose: Disable the 25-pin RS-232 TL1 port to prevent unauthorized TL1 sessions. This command is available only with the Security Upgrade option (see *Security on page 1-5*).

Security: `secu`

Syntax: `security rs232tl1 [enable|disable]`

Field	Description
<code>security rs232tl1</code>	Use the command by itself to show the current setting
<code>enable</code>	Enable the RS-232 TL1 port (default)
<code>disable</code>	Disable the RS-232 TL1 port

Example: `security rs232tl1 disable`

TL1 RS-232 port disabled

SECURITY SNMP

Name: Security SNMP Enable/Disable

Purpose: Prevents SNMP sessions over the Ethernet port and over the DS3 C-bit PPP data link. This command is available only with the Security Upgrade option (see *Security on page 1-5*).

NOTE: In a PPP remote management configuration, a local Wide Bank is connected via DS3 to a remote Wide Bank. The local Wide Bank can route messages originating from the Ethernet channel to the remote Wide Bank over the C-bit link. The remote Wide Bank responds over the C-bit link to the local Wide Bank which then routes the responses back over its Ethernet channel. Disabling SNMP in the local Wide Bank does not prevent SNMP sessions over the C-bit link to the remote Wide Bank. To prevent SNMP sessions to the remote Wide Bank via the C-bit link, SNMP must be disabled for the remote Wide Bank.

Security: *secu*

Syntax: `security snmp [enable|disable]`

Field	Description
<code>security snmp</code>	Use the command by itself to show the current setting
<code>enable</code>	Enable SNMP (default)
<code>disable</code>	Disable SNMP

Example: `security snmp disable`

```
SNMP feature disabled
```

SECURITY TL1

Name: Security TL1 Enable/Disable

Purpose: Prevents TL1 sessions over the 25-pin RS-232 TL1 port, over the Ethernet port, and over the DS3 C-bit PPP data link. This command is available only with the Security Upgrade option (see *Security on page 1-5*).

NOTE: In a PPP remote management configuration, a local Wide Bank is connected via DS3 to a remote Wide Bank. The local Wide Bank can route messages originating from the Ethernet channel to the remote Wide Bank over the C-bit link. The remote Wide Bank responds over the C-bit link to the local Wide Bank which then routes the responses back over its Ethernet channel. Disabling TL1 in the local Wide Bank does not prevent TL1 sessions over the C-bit link to the remote Wide Bank. To prevent TL1 sessions to the remote Wide Bank via the C-bit link, TL1 must be disabled for the remote Wide Bank.

Security: *secu*

Syntax: `security t11 [enable|disable]`

Field	Description
<code>security t11</code>	Use the command by itself to show the current setting
<code>enable</code>	Enable TL1 (default)
<code>disable</code>	Disable TL1

Example: `security t11 disable`

TL1 feature disabled

SNMP

Name: SNMP Configuration

Purpose: Configure SNMP for trap reporting and management using the embedded SNMP agent. The *trapcom* setting is used to report traps to network management alarm systems (see *SNMP Traps on page 8-5*).

Security: *rw* and above with basic security; *admin* and above with Security Upgrade

See *Security on page 1-5* for an overview of basic security and the Security Upgrade option.

Syntax: `snmp {contact|location|name|getcom|setcom|trapcom} {"string"}`

Field	Description
<code>snmp</code>	Use the command by itself to show the current settings
<code>contact</code>	Set the contact name
<code>location</code>	Set the location name
<code>name</code>	Set the system name
<code>getcom</code>	Set the Get Community name (used for read permission)
<code>setcom</code>	Set the Set Community name (used for write permission)
<code>trapcom</code>	Set the Trap Community name (used for trap authentication)
<code>"string"</code>	An alphanumeric character string

Example: `snmp name "DS3 28 M13 Multiplexer"`

Example: snmp

```

snmp name      "DS3 28 M13 Multiplexer"
snmp location  "DS3 28 Location"
snmp contact   "DS3 28 Contact"
snmp getcomm   "public"
snmp setcomm   "public"
snmp trapcomm  "public"

```

STATUS**Name:** Status Report**Purpose:** Show the status of one or more interfaces.**Security:** *ro* and above**Syntax:** **status** {**ds1** {*number*|*range*|**all**}}**Syntax:** **status** {**ds3**|**ds3far**}**Syntax:** **status** {**ethernet**|**icmp**|**ip**|**ppp**|**tcp**|**udp**}**Syntax:** **status** {**fan** [*n*|**all**]}

Field	Description
ds1 <i>number</i>	A low-speed DS1/E1 interface number, 1 to 28
ds1 <i>range</i>	A range of low-speed channels separated by a hyphen as in 5-8
ds1 all	All low-speed channels
ds3	DS3 interface
ds3far	Far-end DS3 interface. See example below. The alarm condition code can be one of the 11 possible codes specified in ANSI T1.107.
ethernet	Ethernet port statistics. See example below. These statistics are also available via SNMP by referencing the interface group defined in RFC-1213 or RFG1573. Includes: MTU - maximum transmission unit: largest packet size, in bytes Speed - physical line speed of connection, in bits per second. Physical Address - Media Access Control (MAC) address
fan <i>n</i>	Fan number, A or B. Displays status of cooling fan, including Fan Active, Fan Fail, or Fan Not Present.
fan all	All fans. Displays status of both cooling fans.
icmp	ICMP layer statistics. See example below.
ip	IP interface statistics. See example below.
ppp	PPP interface statistics. See example below.

Field	Description
tcp	TCP layer statistics See example below.
udp	UDP layer statistics

Example: status ds3

```

Interface Receive          Transmit          Loop          Protection
-----
DS3          C-bit Traffic      Traffic          None          Electronics
    
```

Note: If there is a fault condition while using M23 framing, the message will also show the status for each DS2, as in the following example.

```

Interface Receive          Transmit          Loop          Protection
-----
DS3          Loss of Signal      RAI          None          Electronics
DS2 1          Loss of Framing
DS2 2          Loss of Framing
DS2 3          Loss of Framing
DS2 4          Loss of Framing
DS2 5          Loss of Framing
DS2 6          Loss of Framing
DS2 7          Loss of Framing
    
```

Example: status ds3far

```

Far End DS3:
Condition          No Alarm
Equipment ID       "WideBank28"
Facility ID        "DS3 Path"
Frame ID           "Frame"
Generator Number   "N/A"
Location ID        "DS3 Loc."
Port Number        "N/A"
Unit               "000000"
    
```

Example: status ethernet

```

Ethernet Interface:
MTU                  1500
Speed                10000000
Physical Address     00-E0-97-00-29-9C
Bytes Received       0
Unicast Packets (in) 0
Non-Unicast Packets (in) 0
Discarded Packets (in) 0
Errors (in)         0
Unknown Protocols (in) 0
Bytes Transmitted    0
    
```

Unicast Packets (out)	0
Non-Unicast Packets (out)	0
Discarded Packets (out)	0
Errors (out)	0

Example: status icmp

```
ICMP Interface:
  Messages Received          25
  Errors (in)                0
  Dest. Unreachable (in)    8
  Time Exceeded (in)        0
  Parameter Problems (in)   0
  Source Quenches (in)     0
  Redirects (in)            0
  Echo Requests (in)        8
  Echo Replies (in)         9
  TimeStamp Requests (in)   0
  Addr. Mask Requests (in)  0
  Messages Sent             18
  Errors (out)              0
  Dest. Unreachable (out)   0
  Time Exceeded (out)       0
  Parameter Problems (out)  0
  Echo Requests (out)       10
  Echo Replies (out)        8
  TimeStamp Replies (out)   0
  Addr. Mask Replies (out)  0
```

Example: status ip

```
IP Interface:
  Default Time-To-Live      255
  Packets Received          97831
  Incoming Header Errors    0
  Incoming Address Errors   85464
  Forwarded Datagrams       0
  Incoming Protocol Errors  0
  Incoming Packets Discarded 0
  Incoming Packets Delivered 12367
  Outgoing Packet Requests  4568
  Outgoing Packets Discarded 0
  Unroutable Outgoing Packets 0
  Reassembly Timeout        5
  Reassemblies Requested    0
  Successful Reassemblies   0
  Failed Reassemblies       0
  Successful Fragments      0
  Failed Fragments          0
  Fragments Generated       0
```

Example: status ppp

```
PPP Interface:
Operational Status          up
MTU                          1500
Speed                        28200
Bytes Received               56
Unicast Packets (in)        0
Non-Unicast Packets (in)    0
Discarded Packets (in)      0
Errors (in)                  0
Unknown Protocols (in)      0
Bytes Transmitted            66
Unicast Packets (out)        0
Non-Unicast Packets (out)   0
Discarded Packets (out)     0
Errors (out)                 0
```

Example: status tcp

```
TCP Interface:
Round Trip Algorithm Type    Van Jacobson's
Minimum Round Trip (ms)     0
Maximum Round Trip (ms)     240000
Actively Opened Connections 0
Passively Opened Connections 29
Failed Connection Attempts   0
Established Connections Reset 14
Currently Established        1
Segments Received            5179
Segments Sent                 4436
Errors (in)                  0
Retransmitted Segments       16
```

SWITCH

Name: Switch Controllers

Purpose: Toggle control between the currently active and standby Controllers. The standby Controller becomes active and takes control of the DS3 line, control logic, and power conversion. This command has no options.

Security: *rw* and above

Syntax: **switch**

TEMP COPY

Name: Temporary Copy

Purpose: Save copy of current configuration in temporary storage (volatile RAM), which is not retained if power is turned off. This command allows you to preserve a copy of the current configuration that can be restored after making temporary changes to the current configuration (see *RESTORE* on page 8-63).

Security: *rw* and above with basic security; *admin* and above with Security Upgrade

See *Security* on page 1-5 for an overview of basic security and the Security Upgrade option.

Syntax: `temp copy`

TEST

CAUTION! THIS COMMAND WILL DISRUPT SERVICE ON THE TEST INTERFACE.

Name: Test Interface

Purpose: Perform a diagnostic self-test on an interface and display the results. Test results are saved and can be viewed at a later time with the *results* command (see *RESULTS* on page 8-66).

Security: *rw* and above

Syntax: `test {all|ds3|ds1 [number|range|all] |
ds1card [n|spare] |fan[n|all]}`

Field	Description
all	Perform all self-tests
ds1 number	A low-speed DS1/E1 interface number, 1 to 28
ds1 range	A range of low-speed channels separated by a hyphen as in 5-8
ds1 all	All low-speed channels
ds1card n	A low-speed card, 1 to 7
ds1card spare	The low-speed spare card
ds3	DS3 interface (active Controller only)
fan n	Fan number, A or B. Fan power is turned on for 20 seconds. After five seconds, allowing for the fan to spin up, the rotation speed of the fans is monitored. If the fan is not rotating at the correct speed, an error is logged and a fan failure alarm (Fan A, Fan B, or all) is asserted, and the Controller Status LED blinks red.
fan all	All fans

Example: test ds1 5

```
Testing DS1 5...  
DS1 5           Self Test: Pass
```

Example: test all

Example: test ds1card spare

TIME

Name: Time

Purpose: Set or show the time of the Wide Bank system clock.

Security: Set - *rw* and above with basic security; *admin* and above with Security Upgrade
Show - *ro* and above

See *Security on page 1-5* for an overview of basic security and the Security Upgrade option.

Syntax: time [*hh:mm:ss*]

Field	Description
time	Use the command by itself to show the current setting
hh	Hour, 1 to 24. (24-hour clock)
mm	Minutes, 0 to 59
ss	Seconds, 0 to 59

Example: time

```
The time is 15:54:14 03/05/2002
```

Example: time 5:55:00

Set time to 5:55 a.m.

TL1

Name: TL1 Configuration

Purpose: Set or show TL1 setup configuration, including the TL1 network identification, administrator password, and TCP port number. It can also be used to send a simulated alarm to test the TL1 interface.

This command can be used to embed TL1 commands in quotes and pass them over the CLI channel to the Wide Bank, rather than initiating a separate TL1 session. (See Chapter 9.) This feature permits easy verification and testing of the TL1 configuration.

The networkid serves as the unit identifier in multi-unit networks. It is also the string that appears at the beginning of the command prompt and as the source identifier in TL1 messages.

Note: The TL1 password can be set but is never displayed to any user.

Security: Set - *rw* and above with basic security; *secu* with Security Upgrade
Show - *ro* and above

See *Security on page 1-5* for an overview of basic security and the Security Upgrade option.

Syntax: `tl1 [networkid {"string"}|password {"string"}|
portnumber number|send alarm|"TL1command;"]`

Field	Description
<code>tl1</code>	Use the command by itself to see current settings
<code>networkid "string"</code>	Sets network identification string. This is the string that appears at the beginning of the command prompt and as the source identifier in TL1 messages. The string must be enclosed in double quotes.
<code>password "string"</code>	Sets initial password for default TL1 user named "admin". The string must be enclosed in double quotes.
<code>portnumber number</code>	Sets the TCP port number, 1024 to 65535. The default value is 9999. The TCP port number is required for TL1 operation using the TCP interface port.
<code>send alarm</code>	Sends simulated TL1 alarm to test the interface
<code>"TL1command;"</code>	An embedded Transaction Language One (TL1) command must end in a semicolon and be enclosed in quotes. See example below.

Example: `t11 networkid "MULTIPLEXER-1"`

In addition to changing the Network ID for TL1 messages, this command also changes the command line prompt. After using the command in this example, the prompt would display as follows:

```
MULTIPLEXER-1 (A:Active)>
```

Example: `t11 "act-user::admin:::password;"`

Sends an embedded TL1 command to activate the admin user. The CLI displays the TL1 response as in the completed (COMPLD) message below. See Chapter 9 for detailed TL1 information.

```
2001-05-09 13:58:28
M 0 COMPLD
;
```

USER

Name: User Configuration

Purpose: Add and delete users, assign security levels, and set passwords.

Basic Security – With basic security (see *Security on page 1-5*), only the *admin* user can add and delete users and assign security levels. Users can change their own passwords with the *user "username" password* command.

For convenience in new installations, the *security on* command (see *SECURITY on page 8-69*) automatically logs in the *admin* user (always named "admin"). While security is on, subsequent logins require a username and an associated password (if the password is not blank). The *security off* command disables multiple-user security protection and logs off the *admin* user.

The maximum number of CLI user names is 10, including the *admin* user. The *admin* user cannot be deleted and no other user can have *admin* access.

Security Upgrade – With the Security Upgrade (see *Security on page 1-5*), only the *secu* user can use this command. Users are not permitted to change their own passwords.

For convenience in new installations, the *security on* command (see *SECURITY on page 8-69*) automatically logs in the *secu* user (always named "security"). While security is on, subsequent logins require a username and an associated password. The *security off* command disables multiple-user security protection, and logs off the *secu* user.

The maximum number of CLI user names is 10, including the *secu* user. The *secu* user cannot be deleted and no other user can have *secu* access.

Security: Set - *admin* with basic security (except that users can change their own passwords); *secu* with Security Upgrade
 Show - *ro* and above with basic security; *secu* with Security Upgrade

Syntax: `user ["username" {add|delete|level <admin|rw|ro>|password}]`

Field	Description
user	Use the command by itself to show the list of users.
<i>"username"</i>	<p>A user defined name. The string must be enclosed in double quotes.</p> <p>Basic security – With basic security, user names must include from 1 to 10 alphanumeric characters and must not contain spaces. User names are not case-sensitive when defined; however, users must log in using lower-case characters.</p> <p>With basic security, users do not require a password. If you want to assign a password, use the <i>user "username" password</i> command (described below).</p> <p>Security Upgrade – With the Security Upgrade, user names must include from 8 to 10 alphanumeric characters and must not contain spaces. User names are case-sensitive.</p> <p>With the Security Upgrade, a password is required for each user. A prompt for entering the password appears immediately after a new user name is accepted. See the following table for password requirements.</p> <p>Note: If you are upgrading firmware in an existing Wide Bank, previously defined user names and passwords that contain fewer than 8 characters will be preserved. Blank passwords are also preserved.</p>
add	Add a user name. The number of users is limited to 10.
delete	Delete a user name.
level <admin rw ro>	<p>Set a user's security level (see <i>Security Levels on page 8-4</i> for a description of the security levels). By default, a new user is assigned the level <i>ro</i>.</p> <p>Basic security – With basic security, only the levels <i>rw</i> and <i>ro</i> are assignable. The <i>admin</i> level is automatically assigned to the <i>admin</i> user, and no other user can have <i>admin</i> access.</p> <p>Security Upgrade – With the Security Upgrade, users can be assigned the levels <i>admin</i>, <i>rw</i>, or <i>ro</i>. The <i>secu</i> level is automatically assigned to the <i>secu</i> user, and no other user can have <i>secu</i> access.</p>

Field	Description
password	<p>Set or change a user's password. After entering this command, the user is prompted to enter a new password and to confirm it (see example).</p> <p>Basic security – With basic security, passwords can be from 1 to 10 alphanumeric characters and are case-sensitive. Spaces and special characters are not allowed. Up to 32 characters may be entered but only the first 10 will be used. If the password is left blank, no password is required. After successfully logging in, any user can use this command to change their own password.</p> <p>Security Upgrade – With the Security Upgrade, only the <i>secu</i> user can set or change passwords. Passwords must be from 8 to 10 characters and are case-sensitive. Passwords must contain at least one each of the following types of characters: upper-case alphabetic, lower-case alphabetic, numeric, and special characters. The acceptable characters are listed in the following table.</p>

Characters	Acceptable Values for Security Upgrade Password (Must Contain at Least One Character From Each Group)
Alphabetic Uppercase	A - Z
Alphabetic Lowercase	a - z
Numeric	0 - 9
Special Characters	! \$ % & ' () * + - . / < = > ? @ [\] ^ _ ` { } ~

Example: user

```

User          Level          Last Login
----          -
security     secu          11:39:36 06/23/2004 (Active)
john         admin         11:39:36 06/23/2004
bill         rw           11:02:52 06/23/2004
marie        rw           Never logged in
jack         ro           Never logged in
morgan       ro           11:39:14 06/23/2004
    
```

Example is from a Wide Bank with the Security Upgrade option.

Example: user "henry" add

```
New password: *****  
Confirm new password: *****  
New password accepted
```

```
Successfully added new user "henry"
```

Example is from a Wide Bank with the Security Upgrade option.

Example: user "henry" add

```
Successfully added new user "henry".
```

Example is from a Wide Bank without the Security Upgrade option.

Example: user "henry" level rw

```
Successfully set "henry"'s access level to rw.
```

Example: user "henry" password

```
New password: *****  
Confirm new password: *****  
New password accepted
```

VERSION

Name: Version of Software

Purpose: Show the current boot and software versions. If the Wide Bank has the Security Upgrade option (see *Security on page 1-5*), the software version is preceded by the word "Security."

Security: ro and above

Syntax: version [standby]

Field	Description
standby	Standby Controller. If included, shows version of software installed on standby Controller card.

Example: version

```
Boot Version 1.02  
  
Security Software Version 2.43.0
```

This response indicates that the Wide Bank has the Security Upgrade option.

Example: `version`

```
Boot Version 1.02
```

```
Software Version 2.43.0
```

This response indicates that the Wide Bank does not have the Security Upgrade option.

Example: `version standby`

```
Standby Controller Software Version 2.43.0
```

CHAPTER 9

TL1 Commands and Messages

In this Chapter

- TL1 Overview ... 9-2
- TL1 Setup and Configuration ... 9-9
- TL1 Command List ... 9-17
- TL1 Parameter Descriptions ... 9-83
- TL1 Automatic Messages ... 9-101

TL1 Overview

- General Syntax ... 9-3
- Error Responses ... 9-6
- Command Categories ... 9-7
- Command Modifiers ... 9-7
- Security Levels ... 9-8
- TL1 Shortcuts (Recall and Edit) ... 9-8

The Wide Bank 28 DS3 supports remote management using Transaction Language One (TL1) commands and responses described in Telcordia GR-833-CORE, Issue 2, November 1996, and in GR-199-CORE, Issue 2, November 1996, and TR-NWT-000835, Issue 3, January 1993.

The Wide Bank 28 DS3 also supports TL1 automatic messages that are used to automatically report alarms and other events detected by the Wide Bank. The Wide Bank supports the reporting of alarmed and non-alarmed events using the message formats defined by Telcordia GR-833-CORE, 1996. OSS's such as Telcordia's NMA system are able to use these messages to provide trouble reports to the network operations center.

General Syntax

- Command Syntax ... 9-3
- Grouping Values as Lists and Ranges ... 9-4
- Response Syntax ... 9-4
- Multiple Output Responses ... 9-5

Command Syntax

All TL1 commands have the following general format:

```
verb-modifier[-modifier]:[<tid>]:[<aid>]:[<ctag>]
[:[general block][:first parameter block]
...[:last parameter block]];
```

Field	Description
verb	A command action. See <i>Command Categories</i> on page 9-7.
modifier	A modifier to limit or focus the action. See <i>Command Modifiers</i> on page 9-7
aid	Access ID (optional). See <i>Access Identifier <aid></i> on page 9-84
ctag	Correlation Tag (optional). See <i>Correlation Tag <ctag></i> on page 9-89
tid	Target ID of network element (optional). The default value is MULTIPLEXER-1 See <i>Target Identifier <tid> and Source Identifier <sid></i> on page 9-98

NOTE: The Wide Bank ships with all configuration parameters set to factory default values unless otherwise specified. Default values appear in **bold type** in the tables following the TL1 command syntax. The Wide Bank can be restored to these default values at any time (see *STA-LOCL-RST* on page 9-80).

The parts of the command shown between square brackets are optional but some of these options may be required to successfully complete specific commands.

In the Wide Bank system, the access identifier <aid>, correlation tag <ctag>, and target identifier <tid> are optional.

If desired, you can insert the <ctag> in the command so that commands and their associated responses can be correlated.

For example, consider the Retrieve-Header command syntax:

```
RTRV-HDR:tid::ctag;
```

In the Wide Bank system, the default target identifier <tid> is MULTIPLEXER-1. Using a <ctag> value of 35 as an example, the resulting command would be:

```
RTRV-HDR:MULTIPLEXER-1::35;
```

In this example, the command parts are:

verb	RTRV
modifier	HDR
tid	MULTIPLEXER-1
ctag	35

NOTE: For simplicity, examples and responses in this document will represent the tid and ctag values by the lower-case letters tid and ctag.

Grouping Values as Lists and Ranges

Most Access IDs (aids) can be grouped together when sending commands:

- Lists – use & to enter lists, as in DS1-1&DS1-3&DS1-5
- Ranges – use && to specify a range of values, as in DS1-1&&DS1-5

Response Syntax

The general format of a command response is shown below:

```
<cr><lf><lf>  
^^^<sid>^<YYYY-MM-DD>^<HH:MM:SS><cr><lf>  
M^^<ctag>^<Completion_Code><cr><lf>  
[Text_Block<cr><lf>]*;
```

The symbol <cr> represents a carriage return, and <lf> a line feed. A space is represented by the “^” symbol. The correlation tag will be the same as the one provided in the command. If the correlation tag was omitted from the command, then the correlation tag in the response will be zero (0). Completion codes are described in *Completion Codes on page 9-87*.

Finally, there may be zero or more Text_Blocks with each block containing a <cr><lf> at the end of the response. The example below is the normal response without a text block. It is used to signify that the command was received and executed.

```
tid 2001-08-04 10:42:22  
M ctag COMPLD  
;
```

NOTE: Normal responses are not shown in the command description unless they provide more information than the basic completed (COMPLD) message.

Multiple Output Responses

In the case where the total size of a response exceeds 4096 bytes, the response is divided into multiple responses. These responses have a separate header with the same <ctag> but all except the last one use the “>” instead of the “;” terminator.

```
    tid 2001-08-04 10:42:22
M   ctag COMPLD
    <first response body line>
    .
    .
    <response body line>
>

    tid 2001-08-04 10:42:22
M   ctag COMPLD
    <response body line>
    .
    .
    <response body line>
>

    tid 2001-08-04 10:42:22
M   ctag COMPLD
    <response body line>
    .
    .
    <last response body line>
;
```

Error Responses

Error responses have the following format:

```
<cr><lf><lf>
^^^ <sid> ^ <YYYY-MM-DD> ^ <HH:MM:SS><cr><lf>
M ^^ <ctag> ^ <DENY><cr><lf>
^^^ <ERROR CODE>
(^^^/* <Optional free format error text> */<cr><lf>)
;
```

Code	Description
ERROR CODE	Valid error codes are described in Telcordia GR-833-CORE, Issue 2, November 1996, Appendix D.
Optional free format error text	Additional or more specific information

The contents of the parentheses can occur zero or more times. If more than one error is detected by the Wide Bank, it can transmit the description for each error in the same response. If the error codes for the errors are different, the error code "MERR" (multiple errors) is used.

For example, when an invalid or unsupported command is received by the Wide Bank, the following error response is transmitted:

```
tid 2001-08-04 10:42:22
M ctag DENY
IICM
/* Input, Invalid Command */
;
```

Command Categories

Security Commands

These commands are discussed in Telcordia TR-NWT-835, Issue 3, January 1993.

Transport Surveillance Commands

The syntax for these messages is defined in Telcordia GR-833-CORE, Issue 2, November 1996.

Apart from the specific error responses listed for each command, general error messages can be transmitted.

Memory Administration Commands

The syntax for these messages is defined in Telcordia GR-199-CORE, Issue 2, November 1996.

Apart from the specific error responses listed for each command, general error messages can be transmitted. See *Error Responses* and *Appendix D* in Telcordia GR-833-CORE, Issue 2, November 1996.

Network Maintenance Commands

Apart from the specific error responses listed for each command, general error messages can be transmitted. See *Error Responses* and *Appendix F* in Telcordia GR-833-CORE, Issue 2, November 1996.

Command Modifiers

In the following TL1 command list, many of the commands include command modifiers, as in the command ALW-LPBK-<FacilityType>. The Wide Bank uses three modifiers, which are described below with their permissible values.

FacilityType

Facility Types:

- E1 – for E1 circuits operating at 2.048 Mbps
- T1 – for DS1 circuits operating at 1.544 Mbps
- T3 – for DS3 circuits operating at 44.736 Mbps

LSType

Low-Speed Types:

- E1 – for E1 circuits operating at 2.048 Mbps
- T1 – for DS1 circuits operating at 1.544 Mbps

AIDType

Access Identifier Types:

- E1 – for E1 parameters
- EQPT – for Equipment parameters
- ENV – for Environmental parameters
- T1 – for DS1 parameters
- T3 – for DS3 parameters
- ALL – for ALL parameters

Security Levels

To prevent unauthorized access to the network, the administrator assigns security levels to each user account. TL1 commands have the following three security levels.

- RWA (Read-Write-Administration) for administrators (admins) with full privileges
- RW (Read-Write) for operators that need to monitor and edit data
- R (Read Only) for users that need only to monitor data

TL1 Shortcuts (Recall and Edit)

To simplify entering repetitive commands, the Wide Bank allows you to “recall” the previous ten commands entered by pressing the up and down arrow keys. Press the up arrow to recall the previous command (go backwards), and the down arrow key to go forward.

The Wide Bank also allows you to edit TL1 commands by using the backspace key to delete mistakes and retyping characters. This also allows you to easily recall and edit a previous command to change characters, and then press the semicolon key to enter the modified command.

TL1 Setup and Configuration

- Connecting and Configuring for TL1 ... 9-9
- Setting the Network/Prompt/Source/Target Identifier ... 9-10
- Setting the Initial TL1 Admin Password ... 9-11
- Activating a TL1 User Session ... 9-11
- TL1 Commands and Response Messages ... 9-11
- Adding Users ... 9-13
- Deleting Users ... 9-13
- Changing User Properties ... 9-14
- Changing User Password ... 9-14
- Retrieving Users ... 9-14
- Retrieving Alarms ... 9-15
- Retrieve Header Command ... 9-15
- Testing TL1 Alarming ... 9-16
- Canceling the TL1 User Session ... 9-16
- Error Message in Response to Commands Not Recognized or Supported ... 9-16
- Error Response to Valid Commands Received When a User Is Not Logged In ... 9-16

Connecting and Configuring for TL1

The Wide Bank 28 DS3 supports TL1 remote management and TL1 automatic messages. You can establish a TL1 session through a TCP connection to the Ethernet TCP port, the Asynchronous RS-232 TL1 port, or a terminal-to-terminal session when running in C-bit framing mode.



Figure 9-1 Connector Panel Showing Ethernet and TL1 Ports

Establishing a TL1 Session Via a TCP/IP Socket

Establish the TL1 session through TCP/IP socket `xxx.xxx.xxx.xxx:yyyy`, where `xxx.xxx.xxx.xxx` is the assigned IP address of the Wide Bank, and `yyyy` is the number of the TCP port used for TL1. The TCP port number default is 9999 but can be set by the CLI `tll portnumber` command to any value between 1024 and 65536.

Establishing a TL1 Session Via the RS-232 TL1 Port

Connect the Wide Bank's asynchronous RS-232 TL1 port to a terminal multiplexer. If an X.25 interface is desired, use an external X.25 pad to provide asynchronous RS-232 to X.25 conversion.

Establishing a TL1 Session Using Terminal-to-Terminal Link

In a point-to-point application with another Wide Bank 28 DS3 running in C-bit framing mode, the DS3 terminal-to-terminal data link can be used to remotely manage the far-end terminal. See *Configuring IP and PPP Addresses* on [page 6-15](#).

Setting the Network/Prompt/Source/Target Identifier

It is recommended that each Wide Bank 28 DS3 be assigned a network identifier for management and identification purposes. This is particularly important when many units are being managed over TCP/IP from a single server. In large networks a unique network identifier can be used to identify each unit for domain name IP address lookup.

Depending on the management interface, the network identifier is referred to as the:

- Command Line Prompt in CLI sessions
- Network Identifier in CLI commands and responses
- Target Identifier (TID) in TL1 commands and responses
- Source Identifier (SID) in TL1 autonomous event messages

NOTE: Restoring factory defaults will not change the network identifier, IP address, or security settings because that would disrupt management communications with the unit.

Using CLI to Set the Network Identifier

The network identifier is normally set during initial installation and basic configuration. After logging on through a craft terminal or Telnet session, use the following CLI command to enter or change the network ID.

```
t11 networkid "string"
```

There can be no spaces in the string, only alphanumeric characters or hyphens.

Example: (A:Active)> **t11 networkid "MULTIPLEXER-1"**

```
t11 networkid "MULTIPLEXER-1"  
MULTIPLEXER-1 (A:Active)>
```

Using TL1 to Set the Identifier

The identifier can also be set through the TL1 interface. After logging on, use the TL1 command *SET-SID* on [page 9-78](#).

Setting the Initial TL1 Admin Password

A new Wide Bank has no TL1 users in the TL1 user database. So before you can log into the TL1 interface the first time, you must set an initial TL1 administrator Password ID (pid) through the CLI interface.

Enter the initial password with the following CLI command:

```
TL1 password "password"
```

This password is valid only with the user name “admin,” which is automatically assigned to the first user to log in after installation. Logging into the TL1 interface with the user name “admin” and the initial TL1 password will start a TL1 session with administrator privileges to add other users.

Activating a TL1 User Session

The Wide Bank 28 DS3 can accommodate up to five TL1 user sessions simultaneously:

1. One session through the 25-pin RS-232 (TL1) port.
(9600 baud, 8 data bits, 1 stop bit, no flow control)
This interface has no session timeout.
2. Three TCP/IP sessions through the Ethernet port using a port address.
(Example: telnet 192.168.2.247 9999)
The default session timeout for this interface port is 31 minutes, which is configurable using the command *SET-ATTR-SECUDFLT* on [page 9-77](#).

NOTE: Address 9999 is the default TL1 port address. The TL1 port address can be set to any number between 1024 and 65535, inclusive. This value must be set using the CLI *tl1 portnumber* command (see [TL1 on page 8-81](#)). When using the Windows Telnet program, the TCP/IP port address must be entered through a separate dialog box.

NOTE: “Local Echo” must be turned on for TL1 sessions using the TL1 port number.

3. One CLI session issuing TL1 commands.
TL1 commands are entered using double-quotes following the TL1 field.
Example:

```
(A:Active)> tl1 "ACT-USER:tid:UserName:ctag::password;"
```

TL1 Commands and Response Messages

NOTE: For simplicity, examples and responses in this document use the lower-case letters *tid* and *ctag* to represent the optional Target Identifier and Correlation Tag. The target identifier is optional but if it is included in a command, must be correct or the command will be denied. The correlation tag is optional and is an alphanumeric string, which if entered in a command, will be echoed in the corresponding response message.

Activating Users

Use the *act-user* command as the login command. Use it to start a TL1 session.

```
ACT-USER:tid:UserName:ctag::password;
```

For the first login to a newly installed Wide Bank, the *UserName* field must be "admin" and the *password* must be the initial TL1 password entered through the CLI. Other users, added by the admin session, must use the correct *UserName* and *password* assigned by the admin.

As soon as at least one administrator-level user is added to the TL1 user database, the initial TL1 "admin" user name will no longer be valid and the TL1 password entered through the CLI will also no longer be valid. Subsequently, all users must log in using the correct user name and password as entered in the TL1 user database.

NOTE: If you add one or more administrator level users to the TL1 user database, the "admin" user name will be deleted at the end of the current session and the TL1 password entered through the CLI will no longer be valid. All users must then log in using the user names and passwords in the TL1 user database.

Normal Response to Activate User Command

When the first activate user command is accepted, the Wide Bank will respond with a normal completion response followed by an automatic retrieve equipment response showing the current equipment configuration:

```
tid 01-12-07 01:41:20
M ctag COMPLD
;

tid 01-12-07 01:41:20
A atag REPT EQPT
"DS3-A:ACTIVE,2.41.0"
"DS3-B:STANDBY,2.41.0"
"DS1-CARD-1:ACTIVE,"
"DS1-CARD-2:ACTIVE,"
"DS1-CARD-3:ACTIVE,"
"DS1-CARD-4:ACTIVE,"
"DS1-CARD-5:ACTIVE,"
"DS1-CARD-6:ACTIVE,"
"DS1-CARD-7:ACTIVE,"
"DS1-CARD-SPARE:ACTIVE,"
;
```

Error Response for Incorrect Password

```
      tid 01-12-07 01:42:17
M    ctag DENY
      PICC
      /* Can't login */
      ;
```

NOTE: Whenever a user logs in or out of the TL1 interface, an event is recorded in the TL1 security log and in the event log. The event log entry indicates the name of the user that logged in or out.

Adding Users

Users can be added only from an administrator session. The maximum number of TL1 user names is 10, including the administrator. Use the *ent-user-secu* command:

```
ENT-USER-SECU:MULTIPLEXER-1:NewUser:ctag::password,,uap;
```

- MULTIPLEXER-1 is the default Target ID (tid) of the network element. This field is optional.
- NEWUSER is the new users UserName, a string of up to 10 characters.
- The password is a string of up to 10 characters with at least two non-alpha characters, of which one must be non-alphanumeric. An example is PW-1.
- TL1 formatting characters (such as a colon or comma) can not be used in the user name or password.
- UAP is the user access privilege field. Valid options are: R-Read Only; RW-Read and Write; RWA-Read, Write, and Administration.

NOTE: The default "admin" user name will be deleted after entering another user with RWA privilege. It is advisable to have at least two RWA users.

Deleting Users

Users can be deleted only from an administrator session. Use the *dlt-user-secu* command:

```
DLT-USER-SECU:MULTIPLEXER-1:UserName:1;
```

NOTE: If there is only one administrator in the user database, that user cannot be deleted.

Normal Response to Delete User Command

```
MULTIPLEXER-1 01-12-07 01:41:20
M 50 COMPLD
;
```

Changing User Properties

To change a user's UserName, user password, or user privileges from an admin session, use the *ed-user-secu* command:

```
ED-USER-SECU:tid:AdminName:ctag::UserName,UserPassword,,privilege;
```

NOTE: If there is only one administrator-level user in the database, that user cannot be demoted to RW or R privileges.

Changing User Password

A user can change their own password using an ED-PID command. The password is ASCII string up to 10 characters long with at least two non-alphabetic characters with at least one special character (such as FRED-1). Entering a null removes the password requirement.

```
ED-PID:MULTIPLEXER-1:username:1::old_password,new_password;
```

Retrieving Users

Use the *rtrv-user-secu* command to retrieve a list of all users in the user data base, and their privilege levels:

```
RTRV-USER-SECU:MULTIPLEXER-1:ALL:1;
```

Below is an example response to this command:

```
MULTIPLEXER-1 2001-06-20 14-30-00
M 1 COMPLD
"ADMIN:RWA"
"OPERATOR:RW"
"MONITOR:R"
;
```

Retrieving Alarms

The *retrieve alarm all* command retrieves all outstanding alarms from the Wide Bank's alarm log without filtering for alarm specifics.

```
RTRV-ALM-ALL:MULTIPLEXER-1::23;
```

NOTE: Notification codes (alarm severities) for many conditions can be altered through the TL1 interface. See *SET-ATTR-<AIDType>* on [page 9-75](#).

Response if No Alarms are Present

```
MULTIPLEXER-1 01-12-07 01:41:20  
M 23 COMPLD  
;
```

Response if Alarms are Present

The following example represents the case where one alarm of each type is present (for brevity, not all alarms are shown):

```
MULTIPLEXER-1 01-12-07 01:41:20  
M 23 COMPLD  
"DS3-A,T3:CR,LOS,SA,01-01,01-41-19,NEND,RCV:\"Loss of Signal\",ACTIVE"  
"DS3-B,T3:CR,LOS,SA,01-01,15-39-53,NEND,RCV:\"Loss of Signal\",ACTIVE"  
"DS3-A,T3:CR,LOF,SA,01-01,19-31-32,NEND,RCV:\"Loss of Frame\",ACTIVE"  
"DS3-B,T3:CR,LOF,SA,01-01,19-32-35,NEND,RCV:\"Loss of Frame\",ACTIVE"  
"DS1-17,T1:MJ,INT,SA,01-01,17-29-48,,:\\"Internal Hardware Fault or Failure\","  
"DS1-2,T1:MJ,LOS,SA,01-01,01-05-57,NEND,RCV:\"Loss of Signal\","  
;
```

Retrieve Header Command

Use the *retrieve-header* command to test if the Wide Bank is operating. A normal response indicates that the Wide Bank is alive.

```
RTRV-HDR:MULTIPLEXER-1::34;
```

The following message represents a normal response:

```
MULTIPLEXER-1 01-12-07 01:41:20  
M 34 COMPLD  
;
```

Testing TL1 Alarming

The Wide Bank 28 DS3 provides the ability to test TL1 alarming from the command line interface without requiring you to actually initiate a network alarm. The *tl1 send alarm* CLI command sends a simulated alarm out the TL1 interface.

Canceling the TL1 User Session

The *cancel user* command terminates the TL1 command/response session, and the Wide Bank will no longer respond to the *retrieve alarm all* and *retrieve header* commands. However, the automatic messages will continue to be delivered through the same port. The TL1 session will also be closed if the power to the unit is interrupted or the active Controller is switched.

```
CANC-USER:MULTIPLEXER-1:USERID:34;
```

Error Message in Response to Commands Not Recognized or Supported

```
MULTIPLEXER-1 01-12-07 01:41:20  
M 12 DENY  
ICNV  
"Input, Command Not Valid or Not Supported"  
;
```

Error Response to Valid Commands Received When a User Is Not Logged In

```
MULTIPLEXER-1 01-12-07 01:41:20  
M 12 DENY  
PLNA  
"Login Not Active"  
;
```

TL1 Command List

- ACT-USER ... 9-18
- ALW-AUTORST ... 9-18
- ALW-LOG-SECU ... 9-19
- ALW-LPBK-<FacilityType> ... 9-20
- ALW-MSG-<AIDType> ... 9-20
- ALW-PMREPT-<FacilityType> ... 9-22
- ALW-SWTOPTN-<FacilityType> ... 9-22
- ALW-SWTOWKG-<FacilityType> ... 9-23
- CANC-USER ... 9-23
- CANC-USER-SECU ... 9-24
- CONN-LPBK-<LSType> ... 9-24
- CONN-LPBK-T3 ... 9-25
- CPY-MEM ... 9-25
- DGN-<AIDType> ... 9-26
- DISC-LPBK-<FacilityType> ... 9-27
- DLT-<LSType> ... 9-28
- DLT-USER-SECU ... 9-28
- ED-<AIDType> ... 9-29
- ED-DAT ... 9-31
- ED-PID ... 9-31
- ED-USER-SECU ... 9-32
- ENT-<LSType> ... 9-33
- ENT-USER-SECU ... 9-34
- INH-AUTORST ... 9-35
- INH-LOG-SECU ... 9-35
- INH-LPBK-<FacilityType> ... 9-36
- INH-MSG-<AIDType> ... 9-37
- INH-PMREPT-<FacilityType> ... 9-38
- INH-SWTOPTN-<FacilityType> ... 9-38
- INH-SWTOWKG ... 9-39
- INIT-LOG ... 9-39
- INIT-REG-<FacilityType> ... 9-40
- INIT-SYS ... 9-41
- INIT-REG-<FacilityType> ... 9-40
- INIT-SYS ... 9-41
- OPR-ACO-ALL ... 9-41
- OPR-ARC-<LSType> ... 9-41
- OPR-LPBK-<FacilityType> ... 9-43
- RD-MEM-FILE ... 9-43
- RLS-ARC-<LSType> ... 9-44
- RLS-LPBK-<FacilityType> ... 9-45
- RMV-<AIDType> ... 9-46
- RST-<AIDType> ... 9-46
- RTRV-<FacilityType> ... 9-47
- RTRV-ALM-<AIDType> ... 9-51
- RTRV-ALM-ENV ... 9-53
- RTRV-AO ... 9-54
- RTRV-ARC-<LSType> ... 9-55
- RTRV-ATTR-<AIDType> ... 9-56
- RTRV-COND-<AIDType> ... 9-59
- RTRV-EQPT ... 9-61
- RTRV-HDR ... 9-62
- RTRV-LOG ... 9-62
- RTRV-NETTYPE ... 9-63
- RTRV-PM-<FacilityType> ... 9-64
- RTRV-PMSCHED-<FacilityType> ... 9-67
- RTRV-STATUS ... 9-70
- RTRV-TH-<FacilityType> ... 9-71
- RTRV-TOD ... 9-72
- RTRV-USER-SECU ... 9-72
- SCHED-PMREPT-<FacilityType> ... 9-74
- SET-ATTR-<AIDType> ... 9-75
- SET-ATTR-SECUDFLT ... 9-77
- SET-SID ... 9-78
- SET-TH-<FacilityType> ... 9-79
- STA-LOCL-RST ... 9-80
- SW-TOPROTN-<FacilityType> ... 9-80
- SW-TOWKG-<FacilityType> ... 9-81
- WRT-MEM-FILE ... 9-82

ACT-USER

Name: Activate User

Purpose: Logs user into a TL1 session.

Category: Security Commands

Security: R

Syntax: ACT-USER: [<tid>]:uid: [<ctag>]::<pid>;

Field	Description
ctag	Correlation Tag (optional)
pid	Private ID (password). An ASCII string up to 10 characters long with at least two non-alphabetic characters with at least one special character, such as FRED-22. Omit if password is not required.
tid	Target ID of network element (optional)
uid	User ID (user name). Up to 10 alphanumeric characters.

Example: ACT-USER: :ADMIN;

Login first time after installation if no password has been assigned. If a password is required the first time, the default password is TEST.

Example: ACT-USER: tid:FRED:ctag: :FRED-22;

ALW-AUTORST

Name: Allow Automatic Restoration

Purpose: Enables revertive switching modes.

To disable revertive switching modes, see *INH-AUTORST* on page 9-35.

Category: Transport Surveillance Commands

Security: RW

Syntax: ALW-AUTORST: [<tid>] :: [<ctag>] ::
{E1EQPT | DS1EQPT | DS3EQPT | SYNC};

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
E1EQPT	E1 revertive switching. The E1 circuit will revert to its home card after the fault clears. However, if three protection switches occur within 24 hours, the circuit will remain on the spare card until automatic E1 restoration is reasserted.
DS1EQPT	DS1 revertive switching. The DS1 circuit will revert to its home card after the fault clears. However, if three protection switches occur within 24 hours, the circuit will remain on the spare card until automatic DS1 restoration is reasserted.
DS3EQPT	DS3 revertive switching. The DS3 circuit will revert to the primary DS3-A Controller after the fault clears.
SYNC	Clock revert. The transmit clock will revert to the original clock source when it is considered to be healthy again.

Example: ALW-AUTORST:tid::ctag::DS1EQPT;

ALW-LOG-SECU

Name: Allow Log Security

Purpose: Used by the administrator to enable the recording of security events.
To inhibit recording, see *INH-LOG-SECU* on page 9-35.

Category: Security Commands

Security: RWA

Syntax: ALW-LOG-SECU: [<tid>] : SECURITY: [<ctag>] :: ALL;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: ALW-LOG-SECU:MUTLIPLEXER-1: SECURITY: 67 :: ALL;

ALW-LPBK-<FacilityType>

Name: Allow Loopback

Purpose: Enables the detection of loop codes.
To inhibit loopbacks, see *INH-LPBK-<FacilityType>* on page 9-36.

Category: Transport Surveillance Commands

Security: RW

Syntax: ALW-LPBK- {T1 | E1 | T3 | ALL} : [<tid>] : [<facilityID>] : [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
facilityID	Facility ID depends on selected FacilityType: <ul style="list-style-type: none"> • For T1, use DS1-1 to DS1-28 • For E1, use E1-1 to E1-27 • For T3 or ALL, use ALL or omit facilityID
tid	Target ID of network element (optional).

Example: ALW-LPBK-T1:tid:DS1-1:ctag;

Allow loopback on DS1 #1.

Example: ALW-LPBK-ALL:tid::ctag;

Allow the detection of all loop codes.

ALW-MSG-<AIDType>

Name: Allow Message

Purpose: Used by the administrator to enable the transmission of automatic messages and alarms. To inhibit messages, see *INH-MSG-<AIDType>* on page 9-37. Notification codes (alarm severities) for many conditions can be altered through the TL1 interface, see *SET-ATTR-<AIDType>* on page 9-75.

Category: Transport Surveillance Commands

Security: RWA

NOTE: Only one parameter can be present in an inhibit/allow command: either the Access Identifier <aid> or the Notification Code <ntfcnclde> or the Condition Type <condtype>.

Syntax: ALW-MSG- {T1 | E1 | EQPT | T3 | ALL} : [<tid>] :
[<aid>] : [<ctag>] ;

Syntax: ALW-MSG- {T1 | E1 | EQPT | T3 | ALL} : [<tid>] :: [<ctag>] :: [<ntfncde>] ;

Syntax: ALW-MSG- {T1 | E1 | EQPT | T3 | ALL} : [<tid>] :: [<ctag>] :: [<condtype>] ;

Field	Description
aid	Access ID: T1, E1, EQPT, T3, or ALL See <i>Access Identifier <aid></i> on page 9-84
condtype	Type of alarm or condition. See <i>Condition Type <condtype></i> on page 9-87
ctag	Correlation Tag (optional)
ntfncde	Severity or class of alarm, event or condition. See <i>Notification Code <ntfncde></i> on page 9-96

Example: ALW-MSG-ALL:tid::ctag::MJ;

Enable Transmission of all Major Alarms.

Example: ALW-MSG-T1:tid::ctag::IMPROPRMVL;

Enable Transmission of a Specific Message.

Example: ALW-MSG-ALL:tid::ctag;

Enable Transmission of ALL Messages.

ALW-PMREPT-<FacilityType>

Name: Allow Performance Monitoring Report

Purpose: Allows performance reports to be sent. To inhibit reports, see *INH-PMREPT-<FacilityType>* on page 9-38.

Category: Transport Surveillance Commands

Security: RW

Syntax: ALW-PMREPT- {T3 | T1 | E1 | ALL} : [<tid>] : [<aid>] : [<ctag>] ;

Field	Description
aid	Access ID. Value must be ALL. If aid is omitted, it will default to ALL. See <i>Access Identifier <aid></i> on page 9-84
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: ALW-PMREPT-ALL:tid:ALL:ctag;

Allow Performance Reports for All Facility Type.

Example: ALW-PMREPT-T1:tid:ALL:ctag;

Allow Performance Reports for T1.

ALW-SWTOPROTN-<FacilityType>

Name: Allow Switching To Protection

Purpose: Enables the automatic electronics protection of the DS1/E1 or DS3 channels. To inhibit protection, see *INH-SWTOPROTN-<FacilityType>* on page 9-38.

Category: Transport Surveillance Commands

Security: RW

Syntax: ALW-SWTOPROTN- {T3 | T1 | E1 | ALL} : [<tid>] : ALL : [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: ALW-SWTOPROTN-T1:tid:ALL:ctag;

ALW-SWTOWKG-<FacilityType>**Name:** Allow Switching To Working**Purpose:** For the T3 modifier, this command arms the protection switch circuit. For T1 or E1, this command clears the revertive lockout flag for the DS1s (or E1s) specified in the <aid> field. To inhibit switching, see *INH-SWTOWKG* on page 9-39.**Category:** Transport Surveillance Commands**Security:** RW**Syntax:** ALW-SWTOWKG- {T3|T1|E1|ALL} : [<tid>] : [<aid>] : [<ctag>] ;

Field	Description
aid	Access ID is optional and if omitted will default to ALL: <ul style="list-style-type: none"> • ALL specifies all circuits covered by the modifier. • For T3 modifier, the only valid value is ALL. • For T1 and E1 modifiers, values can be ALL, a range, a list, or one circuit. • For T1 modifier, values are DS1-1 to DS1-28. • For E1 modifier, values are E1-1 to E1-27. See <i>Access Identifier <aid></i> on page 9-84
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: ALW-SWTOWKG-ALL:tid:ALL:ctag;**CANC-USER****Name:** Cancel User**Purpose:** Terminates the user's TL1 session.**Category:** Security Commands**Security:** R**Syntax:** CANC-USER: [<tid>] : [<uid>] : [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
uid	User ID

Example: CANC-USER:tid:FRED:ctag;

CANC-USER-SECU

Name: Cancel User Security

Purpose: Used by an administrator to terminate any active user session.

Category: Security Commands

Security: RWA

Syntax: CANC-USER-SECU: [<tid>]:<uid>: [<ctag>];

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
uid	User ID

Example: CANC-USER-SECU:tid:FRED:ctag;

CONN-LPBK-<LSType>

Name: Connect Loopback {T1|E1}

Purpose: Activates T1 or E1 loopback. To disconnect loopbacks, see *DISC-LPBK-
<FacilityType>* on page 9-27.

Category: Network Maintenance Commands

Security: RW

Syntax: CONN-LPBK-{T1|E1}: [<tid>]:<aid>: [<ctag>]::<lpsig>;

Field	Description
aid	Access ID: <ul style="list-style-type: none"> • For T1 modifier, values are DS1-1 to DS1-28. • For E1 modifier, values are E1-1 to E1-27. See <i>Access Identifier <aid></i> on page 9-84
lpsig	Looping Signal: <ul style="list-style-type: none"> • A-1 – Send CSU loopup request on line side • R-1 – Send CSU loopdown request on line side • A-2 – Send NIU loopup request on network side • R-2 – Send NIU loopdown request on network side • A-3 – Send NIU loopup request on line side • R-3 – Send NIU loopdown request on line side
tid	Target ID of network element (optional)

Example: CONN-LPBK-T1:tid:DS1-1:ctag::A-1;

CONN-LPBK-T3

Name: Connect Loopback T3

Purpose: Activates T3 loopback. To disconnect loopbacks, see *DISC-LPBK-<FacilityType>* on page 9-27.

Category: Network Maintenance Commands

Security: RW

Syntax: CONN-LPBK-T3: [<tid>] :ALL: [<ctag>] ::<lpsig>;

Field	Description
ctag	Correlation Tag (optional)
lpsig	Looping Signal: <ul style="list-style-type: none"> • A-C – Activate a line loopback at the Far NE • R-C – Release a line loopback at the Far NE
tid	Target ID of network element (optional)

Example: CONN-LPBK-T3:tid::ctag::A-C;

CPY-MEM

Name: Copy Memory

Purpose: Copies memory from one location to another

Category: Transport Surveillance Commands

Security: RW

Syntax: CPY-MEM: [<tid>] :: [<ctag>] ::<frommem>, ,<tomem>;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
frommem	The data area from which memory is to be copied: <ul style="list-style-type: none"> • ACTIVE • CONFIG • STANDBY • TEMP See <i>Memory <frommem> and <tomem></i> on page 9-94.
tomem	The data area where memory is to be copied (see above)

Example: CPY-MEM:tid::ctag::ACTIVE,,STANDBY;

Copies configuration from active to standby Controller.

Example: CPY-MEM:tid::ctag::CONFIG,,TEMP;

Creates a temporary copy of the configuration.

Example: CPY-MEM:tid::ctag::TEMP,,CONFIG

Restores the configuration from the temporary copy.

DGN-<AIDType>

Name: Diagnose

Purpose: Test one or more units on the Wide Bank. This command does not test the standby (protected) T3 interface, which is self-tested only when the standby Controller card is initialized on power-up.

Category: Transport Surveillance Commands

Security: R

NOTE: Entities must be removed from service before self-test diagnostics. See *RMV-<AIDType>* on [page 9-46](#). Entities can be restored to service after self-test. See *RST-<AIDType>* on [page 9-46](#).

Syntax: DGN- {T3|T1|E1|ENV|ALL} : [<tid>] : <aid> : [<ctag>] ;

Field	Description
AIDType	Access ID Type. Values are T3, T1, E1, ENV, ALL
aid	Access ID depends on selected AIDType. See table below.
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

AIDType	aid
T3	ALL
T1	DS1-1 to DS1-28
E1	E1-1 to E1-27
ENV	FAN-A, FAN-B
ALL	ALL

Example: DGN-T1:tid:DS1-1:ctag;

Performs diagnostic on DS1 #1.

Response: tid 2001-08-04 11:51:58
M ctag COMPLD
(^^^"<aid>:<rslt>,, "<cr><lf>)+
;

The contents of the brackets occur one or more times.

Field	Description
rslt	Result: pass, fail, or not present.

Example: DGN-T1:tid::ctag;

Diagnose ALL.

Because this command can take more than 2 seconds to execute, an "In Progress" (IP) acknowledgment will be sent upon receiving a valid command:

```
IP 109
<
```

The acknowledgment is followed by the normal response.

DISC-LPBK-<FacilityType>

Name: Disconnect Loopback {T1|E1|T3}

Purpose: Disconnects a T1, E1, or T3 loopback. To connect loopbacks, see *CONN-LPBK-<LSType>* on page 9-24 and *CONN-LPBK-T3* on page 9-25.

Category: Network Maintenance Commands

Security: RW

Syntax: DISC-LPBK-{T3|T1|E1}: [<tid>]:<aid>: [<ctag>];

Field	Description
FacilityType	T3, T1, E1
aid	Access ID depends on selected FacilityType. See table below.
ctag	Correlation Tag (optional)

FacilityType	aid
T3	ALL
T1	DS1-1 to DS1-28
E1	E1-1 to E1-27

Example: DISC-LPBK-T3:tid:ALL:ctag;

DLT-<LSType>

Name: Delete {T1|E1}

Purpose: Deletes a T1 or E1.

Category: Memory Administration Commands

Security: RW

Syntax: DLT-{T1|E1}: [<tid>]:<aid>: [<ctag>];

Field	Description
aid	Access ID: <ul style="list-style-type: none"> • For DS1s, values are DS1-1 to DS1-28 • For E1s, values are E01 to E27
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: DLT-T1:tid:DS1-7:ctag;

DLT-USER-SECU

Name: Delete User Security

Purpose: Used by the administrator to close the account of one or more users. If there is only one user with RWA access privilege, that user cannot be deleted.

Category: Security Commands

Security: RWA

Syntax: DLT-USER-SECU: [<tid>]:<uid>: [<ctag>];

The <uid> Field is the user account that is to be closed.

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
uid	User ID

Example: DLT-USER-SECU:tid:FRED:ctag;

ED-<AIDType>

Name: Edit {T3|T1|E1}

Purpose: Edits configuration of AIDs. To retrieve the configuration, see *RTRV-<FacilityType>* on page 9-47.

Category: Memory Administration Commands

Security: RW

Syntax: ED-T3: [<tid>]:ALL:[<ctag>]::
 [CKTID=<ctid>], [FMT=<fmt>], [LBO=<lbo>], [OMODE=<omode>],
 [TMG=<tmg>], TMGLOCK=<tmglock>;

Syntax: ED-T1: [<tid>]:<aid>:[<ctag>]::
 [DLCID=<dlcid>], [LBO=<lbo>], [LINECDE=<linecde>],
 [OMODE=<omode>;

Syntax: ED-E1: [<tid>]:<aid>:[<ctag>]::
 [DLCID=<dlcid>], [OMODE=<omode>;

Syntax: ;

Field	Description
aid	Access ID is optional and if omitted will default to ALL: <ul style="list-style-type: none"> • ALL specifies all circuits covered by the modifier • For T3 modifier, values are DS3-A and DS3-B • For T1 and E1 modifiers, values can be ALL, a range, a list, or one circuit • For T1 modifier, values are DS1-1 to DS1-28 • For E1 modifier, values are E1-1 to E1-27, except E1-4, E1-8, E1-12, and so on, are not allowed
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
ctid	T3 Circuit ID: ASCII string of up to 32 characters
dlcid	T1/E1 Circuit ID: ASCII string of up to 32 characters
fmt	TS/DS3 digital signal format: This parameter is only used with the T3 modifier. <ul style="list-style-type: none"> • CBIT – C-bit Parity format • M23 – M23 Framing format

TL1 Commands and Messages

TL1 Command List

Field	Description
lbo	<p>Line Build Out only applies to T1 or T3 modifiers. (E1 has no LBO.)</p> <p>For T1 modifier, values are 1 to 6 and correspond to the DSX cable lengths listed below:</p> <ul style="list-style-type: none">• 1 – DSX (0'-110')• 2 – DSX (110'-220')• 3 – DSX (220'-330')• 4 – DSX (330'-440')• 5 – DSX (440'-550')• 6 – DSX (550'-660') <p>For T3 modifier, values are 1 or 2 and correspond to the cable lengths listed below:</p> <ul style="list-style-type: none">• 1 – short (less than 50 feet)• 2 – long (50 feet or more)
linecde	<p>Line Code. Applies only to T1 modifier. Values are:</p> <ul style="list-style-type: none">• AMI – Alternate Mark Inversion• B8ZS – Bipolar with 8-zero Substitution <p>Note: E1 is hard coded to HDB3.</p>
omode	<p>Output Mode. Applies only to T3 or T1 modifier. Values are:</p> <ul style="list-style-type: none">• NORM – Normal Data• AIS – Alarm Indication Signal• Null value defaults to NORM <p>Note: QRSU is not supported.</p>
tmg	<p>Timing Source. Applies only to T3 modifier. Values are:</p> <ul style="list-style-type: none">• INT – Internal Stratum 4E clock• EXT – External Clock (44.736 Mbps)• LINE – Slave to DS3 Line
tmglock	<p>Timing Lock. Applies only to T3 modifier. Indicates whether provisioned timing source is to be locked to disable automatic source switching. Values are:</p> <ul style="list-style-type: none">• Y – yes• N – no

Example: `ED-T3:tid:ALL:ctag:::FMT=M23;`

Set T3 frame format to M23.

Example: `ED-T1:tid:DS1-8:ctag:::LINECDE=AMI;`

Set DS1 channel 8 Line Code to AMI.

Example: `ED-E1:tid:E1-3:ctag:::DLCID=WB9-E1-3;`

Set E1-3 circuit identifier to WB9-E1-3.

ED-DAT

Name: Edit Date and Time

Purpose: Sets the Wide Bank clock's date and time.

Category: Memory Administration Commands

Security: RW

Syntax: ED-DAT: [<tid>] :: [<ctag>] :: [YY-MM-DD] , [HH-MM-SS] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
YY-MM-DD	Date: <ul style="list-style-type: none"> • YY – Last 2 digits of year • MM – Month: 01 to 12 • DD – Day: 01 to 31
HH-MM-SS	Time: <ul style="list-style-type: none"> • HH – Hours: 00 to 23 • MM – Minutes: 00 to 59 • SS – Seconds: 0 to 59

Example: ED-DAT:tid::ctag::00-01-20,12-00-00;

ED-PID

Name: Edit PID

Purpose: Changes user's own private (password) identifier.

Category: Security Commands

Security: R

Syntax: ED-PID: [<tid>] :<uid>: [<ctag>] ::<old-pid>,<new-pid>;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
uid	User ID
new-pid	New Private ID (password): ASCII string up to 10 characters long with at least two non-alphabetic characters with at least one special character, such as SECRET-1. Entering a null removes the password requirement.

Field	Description
old-pid	Old Private ID

Example: ED-PID:tid:JOHNDOE:ctag::JOHN-22,SECRET-1;

ED-USER-SECU

Name: Edit User Security

Purpose: Used by the administrator to edit the security parameters associated with a particular user. (To create a new user, see *ENT-USER-SECU* on page 9-34.)

Category: Security Commands

Security: RWA

Syntax: ED-USER-SECU: [<tid>]:<uid>: [<ctag>]: :
<new-uid>,<new-pid> , ,<new-uap>;

Field	Description
ctag	Correlation Tag (optional)
new-pid	New User Private ID (password). An ASCII string up to 10 characters long with at least two non-alphabetic characters with at least one special character, such as FRED-1. Omit to remove password requirement.
new-uap	New User Access Privilege: <ul style="list-style-type: none"> • R – Read Only • RW – Read-Write • RWA – Read-Write-Administration See <i>Security Levels</i> on page 9-8. Note: If there is only one user with RWA, that user cannot be demoted or deleted.
new-uid	New User ID (user name): Up to 10 alphanumeric characters.
tid	Target ID of network element (optional)
uid	User ID. Default is admin.

Example: ED-USER-SECU:tid:ADMIN:ctag::FRED,FRED-1,,RW;

ENT-<LSType>

Name: Enter {T1|E1}

Purpose: Creates equipment DS1 or E1 parameters and puts the facility in service. To retrieve the configuration, see *RTRV-<FacilityType>* on page 9-47.

Category: Memory Administration Commands

Security: RW

Syntax: ENT- {T1|E1} : [<tid>] :<aid> : [<ctag>] : : :
 [DLCID=<dlcid>] , [LBO=<lbo>] , [LINECDE=<linecde>] ,
 [OMODE=<omode>] ;

Field	Description
aid	Access ID: <ul style="list-style-type: none"> • For T1 modifier, values are DS1-1 to DS1-28 • For E1 modifier, values are E1-1 to E1-27
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
DLCID=	T1/E1 Circuit ID: ASCII string of up to 32 characters
LBO=	Line Build Out (length) applies to T1 only (E1 has no LBO). Values are 1 to 6. <ul style="list-style-type: none"> • 1 – DSX (0'-110') • 2 – DSX (110'-220') • 3 – DSX (220'-330') • 4 – DSX (330'-440') • 5 – DSX (440'-550') • 6 – DSX (550'-660')
LINECDE=	Line Code: {AMI B8ZS} <ul style="list-style-type: none"> • AMI – Alternate Mark Inversion • B8ZS – Bipolar with 8-Zero Substitution This parameter is only used with the T1 modifier. (E1 is hard coded to HDB3.)
OMODE=	Output Mode: {NORM AIS} <ul style="list-style-type: none"> • NORM – Normal Data • AIS – Alarm Indication Signal • Null value defaults to NORM Note: QRSU is not supported.

Example: ENT-T1:tid:DS1-8:ctag:::LINECDE=AMI ;

Create DS1 #8 with Line Code set to AMI.

ENT-USER-SECU

Name: Enter User Security

Purpose: Used by the administrator to enter the security parameters associated with a particular user to create an account for that user. (To edit parameters for an existing user, see *ED-USER-SECU* on page 9-32. To view existing users, see *RTRV-USER-SECU* on page 9-72. To delete an existing user, see *DLT-USER-SECU* on page 9-28.)

The maximum number of TL1 user names is 10, including the administrators. The default "admin" user name will be deleted after entering another user with RWA privilege. It is recommended to have at least two RWA users.

Category: Security Commands

Security: RWA

Syntax: ENT-USER-SECU: [<tid>]:<uid>: [<ctag>]::<pid>, ,<uap>;

Field	Description
ctag	Correlation Tag: a number used to match Responses with Commands
pid	New User Private ID: ASCII string up to 10 characters long with at least two non-alphabetic characters with at least one special character, such as FRED-22. Omit to remove password requirement.
tid	Target ID of network element (optional)
uap	New User Access Privilege: <ul style="list-style-type: none"> • R – Read Only • RW – Read-Write • RWA – Read-Write-Administrator See <i>Security Levels</i> on page 9-8.
uid	User ID (user name): Up to 10 alphanumeric characters.

Example: ENT-USER-SECU:tid:FRED:ctag::FRED-22, ,RW;

Creates new user named FRED with password FRED-22 and access RW.

INH-AUTORST

Name: Inhibit Automatic Restoration

Purpose: Disables revertive switching modes.
To allow revertive switching modes, see *ALW-AUTORST* on page 9-18.

Category: Transport Surveillance Commands

Security: RW

Syntax: INH-AUTORST: [<tid>] :: [<ctag>] :: {DS1EQPT|DS3EQPT|SYNC};

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
DS1EQPT	Turns off DS1 revertive switching
DS3EQPT	Turns off DS3 revertive switching
SYNC	Turns off Clockrevert

Example: INH-AUTORST:tid::ctag::EQPT;

INH-LOG-SECU

Name: Inhibit Log Security

Purpose: Inhibits the recording of security events.
To allow recording, see *ALW-LOG-SECU* on page 9-19.

Category: Security Commands

Security: RWA

Syntax: INH-LOG-SECU: [<tid>] : SECURITY: [<ctag>] :: ALL;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: INH-LOG-SECU:tid:SECURITY:ctag::ALL;

INH-LPBK-<FacilityType>

Name: Inhibit Loopback

Purpose: Disables the detection of loop codes.
To allow loopbacks, see *ALW-LPBK-<FacilityType>* on page 9-20.

Category: Transport Surveillance Commands

Security: RW

Syntax: `INH-LPBK-{T1|E1|T3|ALL}: [<tid>]: [<FacilityID>]: [<ctag>];`

Field	Description
ctag	Correlation Tag (optional)
FacilityID	Facility ID depends on selected FacilityType: <ul style="list-style-type: none"> • For T1, use DS1-1 to DS1-28 • For E1, use E1-1 to E1-27 • For T3 or ALL, use ALL or omit FacilityID
tid	Target ID of network element (optional).

Example: `INH-LPBK-T1:tid:DS1-1:ctag;`

Inhibit DS1 #1 loopback.

Example: `INH-LPBK-ALL:tid:ALL:ctag;`

Inhibit the detection of all loop codes.

INH-MSG-<AIDType>

Name: Inhibit Message

Purpose: Used by the administrator to disable the transmission of automatic messages and alarms. To allow messages, see *ALW-MSG-<AIDType>* on page 9-20. Notification codes (alarm severities) for many conditions can be altered through the TL1 interface, see *SET-ATTR-<AIDType>* on page 9-75.

Category: Transport Surveillance Commands

Security: RWA

Syntax: INH-MSG-{T3|T1|E1|EQPT|ALL}:[<tid>]: [<aid>]: [<ctag>]: [<ntfcncde>], [<condtype>];

Field	Description
aid	Access ID. Values depend on facility type: T1, E1, EQPT, T3, or ALL. See <i>Access Identifier <aid></i> on page 9-84
condtype	Type of alarm or condition. • See <i>Condition Type <condtype></i> on page 9-87
ctag	Correlation Tag (optional)
ntfcncde	Severity or class of alarm, event or condition. Values are: • CR – Critical Alarm • MJ – Major Alarm • MN – Minor Alarm • CL – Condition Cleared • NA – Not Alarmed • NR – Not Reported

Example: INH-MSG-T1:tid:DS1-1:ctag::,;

Inhibits messages for DS1 #1.

Example: INH-MSG-T1:tid::ctag::MJ,;

Inhibits major DS1 messages.

Example: INH-MSG-T1:tid::ctag::,LOS;

Inhibits DS1 LOS messages.

INH-PMREPT-<FacilityType>

Name: Inhibit Performance Monitoring Report

Purpose: Inhibits any scheduled performance monitoring reports. To allow reports, see *ALW-PMREPT-<FacilityType>* on [page 9-22](#).

Category: Transport Surveillance Commands

Security: RW

Syntax: INH-PMREPT- {T3 | T1 | E1 | ALL} : [<tid>] : [<aid>] : [<ctag>] ;

Field	Description
aid	Value must be ALL. If aid is omitted, it will default to ALL. See <i>Access Identifier <aid></i> on page 9-84
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: INH-PMREPT-ALL:tid:ALL:ctag;

Inhibits Performance Reports for All Facility Types.

Example: INH-PMREPT-T1:tid:ALL:ctag;

Inhibits Performance Reports for T1.

INH-SWTOPROTN-<FacilityType>

Name: Inhibit Switching to Protection

Purpose: Disables the automatic electronics protection of the DS1/E1 or DS3 channels. To allow protection, see *ALW-SWTOPROTN-<FacilityType>* on [page 9-22](#).

Category: Transport Surveillance Commands

Security: RW

Syntax: INH-SWTOPROTN- {T3 | T1 | E1 | ALL} : [<tid>] : ALL : [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: INH-SWTOPROTN-T1:tid:ALL:ctag;

Inhibit DS1 Protection.

Example: INH-SWTOPROTN-ALL:tid:ALL:ctag;

Inhibit DS1 and DS3 Protection.

INH-SWTOWKG

Name: Inhibit Switching To Working

Purpose: Disarms the DS3 protection switch circuit. To allow switching, see *ALW-SWTOWKG-
<FacilityType>* on page 9-23.

Category: Transport Surveillance Commands

Security: RW

Syntax: INH-SWTOWKG-T3: [<tid>]:ALL: [<ctag>];

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: INH-SWTOWKG-T3:tid:ALL:ctag;

INIT-LOG

Name: Initialize Log

Purpose: Clears the contents of the specified log (see *Log Identifier <lognm>* on page 9-93)

NOTE: If you clear the event log, timestamps for any existing alarms or conditions are also cleared.

Category: Transport Surveillance Commands

Security: RW

Syntax: INIT-LOG: [<tid>]:: [<ctag>]::<lognm>;

Field	Description
ctag	Correlation Tag (optional)
lognm	Name of Log. Values are: <ul style="list-style-type: none"> • ALL – clears all logs • SECURITY – security event log • EVT – event log • EVT-STBY – event log in standby Controller
tid	Target ID of network element (optional)

Example: INIT-LOG:tid::ctag::EVT;

Clear event log.

Example: INIT-LOG:tid::ctag::ALL;

Clear all logs.

INIT-REG-<FacilityType>

Name: Initialize Register

Purpose: Clears the contents of the specified register. This command is used to clear the performance monitoring data for the DS1 and DS3 interfaces.

Category: Transport Surveillance Commands

Security: RW

Syntax: INIT-REG- {T3|T1|E1|ALL} : [<tid>] : [<aid>] :
 [<ctag>] : :ALL;

Field	Description
aid	Access ID depends on selected FacilityType. See table below.
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

FacilityType	aid
T3	ALL or null
T1	DS1-1 to DS1-32, or ALL
E1	E1-1 to E1-31, or ALL
ALL	ALL or null

Example: INIT-REG-T3:tid::ctag::ALL;

Clear DS3 Performance Monitoring Statistics.

Example: INIT-REG-T1:tid:DS1-15:ctag::ALL;

Clear DS1-15 Performance Monitoring Statistics.

INIT-SYS

Name: Initialize System

Purpose: Resets the Active Controller.

Category: Transport Surveillance Commands

Security: RWA

Syntax: INIT-SYS: [<tid>]:ALL: [<ctag>] :: [<ph>] ;

Field	Description
ctag	Correlation Tag (optional)
ph	Degree of system initialization. Because the Wide Bank 28 DS3 only supports one degree of system initialization, this parameter is ignored and may be omitted.
tid	Target ID of network element (optional)

Example: INIT-SYS:tid:ALL:ctag::;

OPR-ACO-ALL

Name: Operate Alarm Cutoff

Purpose: Initiates alarm cutoff.

Category: Transport Surveillance Commands

Security: RW

Syntax: OPR-ACO-ALL: [<tid>] :: [<ctag>] ;

Example: OPR-ACO-ALL:tid::ctag;

OPR-ARC-<LSType>

Name: Operate Automatic In-Service Detection

Purpose: Turns on the automatic in-service detection for all low-speed DS1 or E1 channels that are subsequently put in service while there is an LOS condition. This command inhibits the LOS alarm until a good signal has been received for the specified delay time. To release automatic in-service detection on all DS1 or E1 channels, see *RLS-ARC-<LSType>* on page 9-44.

Note: Following a DC power interruption, the LOS inhibit will be disabled on all channels, causing an LOS alarm on any DS1 or E1 that is enabled but not in service.

Note: A channel's LOS inhibit will also be disabled immediately if any of the following events occur:

- the channel is disabled (set out of service)
- a hardware failure occurs on the channel
- a metallic loopback is run on the channel
- the channel is manually moved to a spare
- the channel's card is removed.

However, if a channel is disabled and then re-enabled while an LOS condition is present, the automatic in-service detection will again inhibit the LOS alarm.

Automatic in-service detection is applied on a channel-by-channel basis. If service is discontinued on a channel, automatic in-service detection can be reapplied to that channel by placing it out of service (see *RMV-<AIDType>* on page 9-46) and then back in service (see *ENT-<LSType>* on page 9-33).

To quickly provision automatic in-service detection when turning up a new Wide Bank, first turn on automatic in-service detection and then place all (aid = ALL) T1s or E1s out of service and then back in service.

Category: Transport Surveillance Commands

Security: RW

Syntax: `OPR-ARC-<T1|E1>:<tid>:<aid>:<ctag>::QI, [<delay>];`

Field	Description
aid	Access ID must either be ALL or be omitted. If omitted, the default is ALL.
ctag	Correlation Tag (optional)
delay	Delay time in hours, 1 to 168 (1 week). If omitted, the current value remains unchanged. Factory default is 2 hours.
QI	Qualified Inhibition (optional). If omitted, the default is QI.
tid	Target ID of network element (optional)

Example: `OPR-ARC-T1:tid::ctag;`

Turn on automatic in-service detection.

Example: `OPR-ARC-T1:tid::ctag::QI,12;`

Turn on automatic in-service detection and set delay time to 12 hours.

OPR-LPBK-<FacilityType>

Name: Operate Loopback

Purpose: Activates the specified loopback. To release loopbacks, see *RLS-LPBK-<FacilityType>* on page 9-45.

Category: Transport Surveillance Commands

Security: RW

Syntax: OPR-LPBK-{T3|T1|E1}:[<tid>]: [<aid>]: [<ctag>]: , , , <lpbktype>;

Field	Description
aid	Access ID depends on Facility Type. See table below.
ctag	Correlation Tag (optional)
lpbktype	Loopback Type depends on selected Facility Type. See table below.
tid	Target ID of network element (optional)

Facility Type	aid	<lpbktype>
T3	ALL Note: This refers to the Active Controller	EQUIPMENT, LINE, PAYLOAD
T1	DS -01 to DS -28	EQUIPMENT, LINE, METALLIC Note: Metallic loopbacks can only be applied to four DS1s, one DS1 per protection group.
	ALL	EQUIPMENT, LINE
E1	E1-1 to E -27	EQUIPMENT, LINE, METALLIC Note: Metallic loopbacks can only be applied to three E1s, one E1 per protection group.

Example: OPR-LPBK-T1:tid:DS1-1:ctag: , , , EQUIPMENT;

Initiate DS1 #1 equipment loopback.

RD-MEM-FILE

Name: Read Memory File

Purpose: Downloads the configuration file.

Category: Transport Surveillance Commands

Security: R

Syntax: RD-MEM-FILE: [<tid>]:CONFIG: [<ctag>];

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Because this command can take more than 2 seconds to execute, an “In Progress” (IP) acknowledgment will be sent upon receiving a valid command:

Example: RD-MEM-FILE:tid:CONFIG:ctag;

Response: tid 2001-08-04 11:51:58
M ctag COMPLD
<up to 64 characters (32 bytes) of data>
;

The contents of the brackets can occur one or more times. In the case where the total size of a response exceeds 4096 bytes, the response is divided into multiple responses.

RLS-ARC-<LSType>

Name: Release Automatic In-Service Detection

Purpose: Turns off the automatic in-service detection feature for all low-speed DS1 or E1 channels. Normal LOS alarm operation will resume immediately. To enable automatic in-service detection or set the delay time, see *OPR-ARC-<LSType>* on page 9-41.

Category: Transport Surveillance Commands

Security: RW

Syntax: RLS-ARC-<T1|E1>:<tid>:<aid>:<ctag>::QI;

Field	Description
aid	Access ID must either be ALL or be omitted. If omitted, the default is ALL.
ctag	Correlation Tag (optional)
QI	Qualified Inhibition (optional). If omitted, the default is QI.
tid	Target ID of network element (optional)

Example: RLS-ARC-T1:tid::ctag;

Turn off automatic in-service detection feature.

RLS-LPBK-<FacilityType>

Name: Release Loopback

Purpose: Releases the specified loopback(s). To operate loopbacks, see *OPR-LPBK-<FacilityType>* on page 9-43.

Category: Transport Surveillance Commands

Security: RW

Syntax: RLS-LPBK- {T3 | T1 | E1 | ALL} : [<tid>] :<aid> : [<ctag>]
 [: : , , , <lpbktype>] ;

Field	Description
FacilityType	T1, E1, T3, ALL
aid	Access ID depends on selected Facility Type. See table below.
ctag	Correlation Tag (optional)
lpbktype	Loopback Type depends on selected Facility Type. See table below.
tid	Target ID of network element (optional)

Facility Type	aid	<lpbktype>
ALL	ALL	
T3	ALL Note: This refers to the Active Controller	EQUIPMENT, LINE, PAYLOAD
T1	DS -01 to DS -28 ALL	EQUIPMENT, LINE, METALLIC EQUIPMENT, LINE
E1	E1-1 to E -27	EQUIPMENT, LINE, METALLIC

Syntax: RLS-LPBK-T1 : [<tid>] : DS1-1 : 123 : : , , , EQUIPMENT ;

Release DS1 #1 equipment loopback.

Example: RLS-LPBK-ALL : tid : ALL : ctag ;

Release all loopbacks.

RMV-<AIDType>

Name: Remove {T3|T1|E1}

Purpose: Removes a T3, T1, or E1 channel from service. To put facility back in service, see *ENT-<LSType>* on page 9-33.

Note: A T3 can not actually be removed from service. The purpose of the RMV-T3 command is to allow the active T3 to be tested.

Category: Transport Surveillance Commands

Security: RW

Syntax: RMV-{T3|E1} : [<tid>] : <aid> : [<ctag>] ;

Field	Description
aid	Access ID depends on AIDType: <ul style="list-style-type: none"> • For T3 modifier, use ALL • For T1 modifier, use DS1-1 to DS1-28, or ALL • For E1 modifier, use E1-1 to E1-27, or ALL
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RMV-T1:tid:DS1-1:ctag;

RST-<AIDType>

Name: Restore {T3|T1|E1}

Purpose: Restores a T3, T1, or E1 channel to service.

Category: Transport Surveillance Commands

Security: RW

Syntax: RST-{T3|T1|E1} : [<tid>] : <aid> : [<ctag>] ;

Field	Description
aid	Access ID depends on AIDType: <ul style="list-style-type: none"> • For T3 modifier, use ALL • For T1 modifier, use DS1-1 to DS1-28, or ALL • For E1 modifier, use E1-1 to E1-27, or ALL
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RST-T1:tid:DS1-1:ctag;

RTRV-<FacilityType>

Name: Retrieve Configuration

Purpose: Retrieves current configuration settings for T3, T1, or E1 facilities. To edit the settings, use, see *ED-<AIDType>* on page 9-29.

Category: Memory Administration Commands

Security: R

Syntax: **RTRV-{T3|T1|E1}:[<tid>]: [<aid>]: [<ctag>];**

Field	Description
aid	Access ID depends on LSType: <ul style="list-style-type: none"> • For T1 modifier, use DS1-1 to DS1-28, or ALL • For E1 modifier, use E1-1 to E1-27, or ALL • For T3 modifier, use ALL
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: **RTRV-T3:tid::ctag;**

This command retrieves the configuration for the DS3.

Response: tid 2001-08-04 02:15:52
M ctag COMPLD
 "AISC=LOS&AISNAS&LOF,AIST=ONES,CKTID=DS3,
CMDMDE=FRCD,FMT=M23,IDLE=N,LBO=1,LINECDE=B3ZS,
MCOND=LOS&RAI&AISNAS&LOF&T-ERL&RTCLK&IMPROPRMVL&
IRR&CONTEQPT&BPV,OMODE=NORM,XBIT=PASS,XBITRCV=ALM1,
XPOL=ALM1,TMG=INT,TMGLOCK=N"
;

Field	Description
AISC	Specifies conditions on the input (receive) side of a connection under which AIS will be generated on the output (transmit) side of a connection. This is hard-coded in the Wide Bank to LOS&AISNAS&LOF .
AIST	Indicates the type of the AIS signal to be generated/transmitted, and the AIS signal mode expected on input should a failure condition exist. This is hard-coded in the Wide Bank to ONES .
CKTID	The circuit identification parameter contains the Common Language Circuit ID or other alias of the channel being provisioned. This is an ASCII string limited to 32 characters.

TL1 Commands and Messages

TL1 Command List

Field	Description
CMDMDE	Indicates command execution mode. This is hard-coded in the Wide Bank to FRC D which means commands may override existing parameter settings in order to execute.
FMT	Indicates DS3 digital signal format. Values for the Wide Bank are C BIT and M23 .
IDLE	Indicates DS3 idle signal is used or not used. The Wide Bank is hard-coded to N .
LBO	Indicates line build out setting. Values are 1 and 2: <ul style="list-style-type: none">• 1 – short connections (less than 50')• 2 – long connections (50' or longer)
LINECDE	Indicates DS3 line code. This is hard coded to B3ZS in the Wide Bank
MCOND	Specifies conditions to be monitored on the input side of the connection. This is hard-coded in the Wide Bank to: LOS&RAI&AISNAS&LOF&T-BERL&RTCLK &IMPROPRMVL&INT&PWR&INTERR&CONTEQPT&BPV
OMODE	Specifies what will be transmitted from the DS3 output port. Values for the Wide Bank are: <ul style="list-style-type: none">• NORM (normal)• AIS (Alarm Indication Signal)
TMG	Timing Source. Values are: <ul style="list-style-type: none">• INT – Internal Stratum 4E clock• EXT – External Clock (44.736 Mbps)• LINE – Slave to DS3 Line
TMGLOCK	Timing Lock. Indicates whether provisioned timing source is to be locked to disable automatic source switching. Values are: <ul style="list-style-type: none">• Y – yes• N – no
XBIT	Indicates how the X-bits are handled for this particular channel. This is hard-coded to PASS in the Wide Bank, meaning it will pass the X-bits with no modification.
XBITRCV	Indicates the usage of the outgoing X-bits. This is hard-coded to ALM1 in the Wide Bank, meaning all the X-bits equal to 1 for indicating incoming remove alarm.
XPOL	Indicates the value/polarity to which the outgoing X-bits are forced. This is hard-coded in the Wide Bank to ALM1 , meaning the Wide Bank will set X-bits to one for indicating alarm.

Example: `RTRV-T1:tid:DS1-2:ctag;`

This command retrieves the configuration for DS1 #2.

Response:

```

tid 2001-08-04 11:51:58
M ctag COMPLD
  "DS1-02::AISF=Y,CMDMDE=FRCD,DLCID=DS1 2,
FLMDE=BOTH,FMT=UNFR,IDLE=AIS,LBO=1,LINECDE=B8ZS,
OMODE=NORM,RVRTFLAG=UNLCKD:IS-EQ,NALMNR"
;
```

Example: `RTRV-E1:tid:E1-1:ctag;`

This command retrieves the configuration for E1 #1.

Response:

```

tid 2001-08-04 11:47:18
M ctag COMPLD
  "E1-01::AISF=Y,CMDMDE=FRCD,DLCID=E1 1,
FLMDE=BOTH,FMT=UNFR,IDLE=AIS,LINECDE=HDB3,
OMODE=NORM,RVRTFLAG=UNLCKD:IS-EQ,"
;
```

Field	Description
AISF	Indicates whether failed signal from upstream should be replaced by AIS. This is hard-coded to Y in the Wide Bank.
CMDMDE	Indicates command execution mode. This is hard-coded to FRCD in the Wide Bank. This means that existing parameter settings may be overridden in order to execute the command.
DLCID	The DS1 or E1 digital loop carrier system identifier. This is a string of ASCII characters and has a maximum length of 32 characters.
FLMDE	Indicates the fault locate mode. This is hard-coded to BOTH in the Wide Bank.
FMT	Indicates DS1 digital signal format. This is hard-coded to UNFR in the Wide Bank.
IDLE	Indicates the signal inserted for idle DS1. This is hard-coded to AIS in the Wide Bank.
LBO	Indicates the line buildout setting. Values are 1-6. Line Build Out (length) applies to T1 only (E1 has no LBO). <ul style="list-style-type: none"> • 1 – DSX (0-110 ft.) • 2 – DSX (110-220 ft.) • 3 – DSX (220-330 ft.) • 4 – DSX (330-440 ft.) • 5 – DSX (440-550 ft.) • 6 – DSX (550-660 ft.)

TL1 Commands and Messages

TL1 Command List

Field	Description
LINECDE	Indicates DS1 line code. E1 is always HDB3 (high density bipolar 3). Valid DS1 values are: <ul style="list-style-type: none">• AMI (Alternate mark inversion)• B8ZS (Bipolar with 8-zero substitution)
OMODE	Specifies what will be transmitted from the DS1 output port. The Wide Bank supports: <ul style="list-style-type: none">• NORM (Normal)• AIS (Alarm Indication Signal)
RVRTFLAG	Indicates the DS1 is locked onto the spare due to repeated unsuccessful attempts at reverting to the working card. The DS1 will remain on the spare until this flag is cleared, the DS1 card is replaced, or the DS1 is manually moved home.
state block (PST and SST)	The block following the last colon in the RTRV-T1 command response is the state block. This block contains the primary state (PST) parameter that indicates the primary state and qualifier information of the entity as defined in GR-1093-CORE and sometimes contains the optional secondary state (SST) parameter which indicates the secondary state information. Values for the PST and their meanings are: <ul style="list-style-type: none">• IS-EQ – in service (enabled) and equipped• IS-RLY – in service with relay card only (XCVR removed)• IS-UEQ – in service and unequipped• OOS-EQ – out of service (disabled) and equipped• OOS-RLY – out of service with relay card only (XCVR is removed)• OOS-UEQ – out of service and unequipped Values for the SST and their meanings are: <ul style="list-style-type: none">• NALMNR – The auto in-service feature is on and an LOS alarm is being suppressed on this DS1.• NALMCD – The auto in-service feature is on, a good signal exists, but it has not persisted for 2 minutes yet.

RTRV-ALM-<AIDType>

Name: Retrieve Alarm

Purpose: Displays active facility alarms. For environmental alarms, see *RTRV-ALM-ENV* on page 9-53.

Category: Transport Surveillance Commands

Security: R

Syntax: `RTRV-ALM- {T3 | T1 | E1 | EQPT} : [<tid>] : [<aid>] : [<ctag>] :: [<ntfncde>] , [<condtype>] ;`

Field	Description
aid	Access ID depends on AIDType: <ul style="list-style-type: none"> • For T3, use DS3-A or DS3-B or ALL • For T1, use DS1-1 to DS1-28, or ALL • For E1, use E1-1 to E1-27, or ALL • For EQPT, see <i>Access Identifier <aid></i> on page 9-84 Null value defaults to ALL
condtype	Type of alarm or condition. See <i>Condition Type <condtype></i> on page 9-87. Null value defaults to ALL.
ctag	Correlation Tag (optional)
ntfncde	Severity or class of alarm, event or condition. See <i>Notification Code <ntfncde></i> on page 9-96. Null value defaults to ALL.
tid	Target ID of network element (optional)

Example: `RTRV-ALM-T3:tid:DS3-A:ctag::CR,LOS;`

Retrieves Critical LOS alarm on DS3-A.

Response Format:

```
<cr><lf><lf>
^^^<tid>^<YYYY-MM-DD>^<HH:MM:SS><cr><lf>
M^^<ctag>^COMPLD<cr><lf>
(^^^" [<aid>] :<ntfncde> ,<condtype> ,<srveff> , [<ocrdat>] ,
 [<ocrtm>] , [<locn>] , [<dirn>] , [ : [<conddescr>] , [<aiddet>] "
<cr><lf>)*
;
```

* - the contents of the parentheses can occur zero or more times.

Example: `RTRV-ALM-T3:tid::ctag;`

Retrieve all Active DS3 Alarms.

Example: `RTRV-ALM-ALL:tid::ctag;`

Retrieve all Active Alarms. The following response is typical. (This may take a few seconds.)

Response:

```
tid 2001-08-04 11:51:58
M ctag COMPLD
"DS3-A:CR, LOS, SA, 01-01, 01-41-19, NEND, RCV: \"DS3 RX LOS\", ACTIVE"
"DS3-B:CR, LOS, SA, 01-01, 15-39-53, NEND, RCV: \"DS3 RX LOS\", ACTIVE"
"DS3-A:CR, LOF, SA, 01-01, 19-31-32, NEND, RCV: \"DS3 RX LOF\", ACTIVE"
"DS3-B:CR, LOF, SA, 01-01, 19-32-35, NEND, RCV: \"DS3 RX LOF\", ACTIVE"
"DS1-17, T1: MJ, INT, SA, 01-01, 17-29-48, , : \"Internal Hardware Fault or Failure\", "
"DS1-02, T1: MJ, LOS, SA, 01-01, 01-05-57, NEND, RCV: \"Loss of Signal\", "
"DS1-CARD-3: MJ, IMPROPRMVL, NSA, 01-01, 17-33-25, , : \"Improper Removal\", "
"DS1-CARD-MSO-6: MJ, IMPROPRMVL, NSA, 06-16, 12-41-58, , : \"Improper Removal\", "
"DS1-CARD-MSO-2: MJ, IMPROPRMVL, NSA, 06-16, 12-43-43, , : \"Improper Removal\", "
"DS1-CARD-2: MJ, FAILTOSW, SA, 06-16, 12-43-44, , : \"Conflict on Spare Card\", "
"DS1-CARD-MSO-2: MN, IMPROPRMVL, NSA, 06-16, 12-43-31, , : \"Improper Removal\", "
"DS1-CARD-SPARE: MN, IMPROPRMVL, NSA, 06-16, 12-42-42, , : \"Improper Removal\", "
"DS1-CARD-MSO-SPARE: MN, IMPROPRMVL, NSA, 06-16, 12-44-35, , : \"Improper Removal\", "
"DS3-A:MN, LOS, SA, 01-01, 15-39-44, , RCV: \"DS3 RX LOS\", STANDBY"
"DS3-B:MN, LOS, SA, 01-01, 15-47-23, , RCV: \"DS3 RX LOS\", STANDBY"
"DS3-A:MN, LOF, SA, 01-01, 19-32-48, NEND, RCV: \"DS3 RX LOF\", STANDBY"
"DS3-B:MN, LOF, SA, 01-01, 19-34-49, NEND, RCV: \"DS3 RX LOF\", STANDBY"
"DS3-A:MN, IMPROPRMVL, NSA, 01-01, 01-02-25, , : \"DS3 Card Removed\", "
"DS3-B:MN, IMPROPRMVL, NSA, 01-01, 01-44-56, , : \"DS3 Card Removed\", "
"DS3-A:MN, CONTEQPT, NSA, 01-01, 22-30-39, , : \"DS3 Card Fail\", STANDBY"
"DS3-B:MN, CONTEQPT, NSA, 01-01, 01-01-00, , : \"DS3 Card Fail\", STANDBY"
"POWER-5V-A: MN, PWR, NSA, 01-01, 01-07-51, , : \"Internal Power Failure\", "
"POWER-5V-B: MN, PWR, NSA, 01-01, 01-03-28, , : \"Internal Power Failure\", "
"DS3-A:MN, INTERR, NSA, 01-01, 01-03-31, , : \"DS3 Over Temp\", STANDBY"
"DS3-B:MN, INTERR, NSA, 01-01, 01-04-50, , : \"DS3 Over Temp\", STANDBY"
"DS3-A:MN, INTERR, NSA, 01-01, 01-07-55, , : \"DS3 Over Temp\", ACTIVE"
"DS3-B:MN, INTERR, NSA, 01-01, 01-09-51, , : \"DS3 Over Temp\", ACTIVE"
"DS1-17: MN, INT, SA, 01-01, 01-39-13, , : \"DS1 HW Failure\", "
"DS3-A:MN, LOS, SA, 01-01, 01-39-59, NEND, RCV: \"DS3 RX LOS\", STANDBY"
"EXT48V-A: MN, PWR, NSA, 01-01, 01-11-34, , : \"External Power Supply Fail or Low\", "
"EXT48V-B: MN, PWR, NSA, 01-01, 01-45-58, , : \"External Power Supply Fail or Low\", "
;
```

RTRV-ALM-ENV

Name: Retrieve Alarm Environment

Purpose: Retrieves active environment alarms. For facility alarms, see *RTRV-ALM-<AIDType>* on page 9-51.

Purpose:

Category: Transport Surveillance Commands

Security: R

Syntax: `RTRV-ALM-ENV: [<tid>]: [<envAid >]: [<ctag>]: :
 [<ntfncde>], [<almtree >];`

Field	Description
almtree	Type of alarm. See <i>Condition Type <condtype></i> on page 9-87. Null value defaults to ALL
ctag	Correlation Tag (optional)
envAid	Environmental Access ID. See <i>Environment Access Identifier (EnvAID)</i> on page 9-91. Null value defaults to ALL
ntfncde	Severity or class of alarm, event or condition. See <i>Notification Code <ntfncde></i> on page 9-96. Null value defaults to ALL
tid	Target ID of network element (optional)

Example: `RTRV-ALM-ENV:tid::ctag::;`

Retrieve All Environment Alarms.

Example: `RTRV-ALM-ENV:tid:EXT48V-A:ctag::;`

Retrieve Alarms for a Specific AID.

Example: `RTRV-ALM-ENV:tid:FAN-A:ctag::,MJ,CLFAN;`

Retrieve a Specific Alarm.

Response Format:

```
<cr> <lf> <lf>
^^^<tid>^YYYY-MM-DD^HH:MM:SS <cr> <lf>
M^^<ctag>^COMPLD <cr> <lf>
(^^"<aid>:<ntfncde>,<almtree>,<ocrdat>,<ocrtm>]
[,<almmsg>]" <cr> <lf>)*
;
```

* - the contents of the parentheses can occur zero or more times.

Response: tid 2001-08-04 11:51:58
M ctag CMPLD
"FAN-A & FAN-B:MJ,CLFAN,01-01,01-00-44,\"Fan Faceplate Not Present\""
"EXT48V-A:MN,PWR-48,01-01,01-00-49,\"Power -48V Fail or Low\""
"EXT48V-B:MN,PWR-48,01-01,01-00-49,\"Power -48V Fail or Low\""
"TEMP-A:MN,HITEMP,01-01,01-00-51,\"High Temp\""
"TEMP-B:MN,HITEMP,01-01,01-00-51,\"High Temp\""
;

RTRV-AO

Name: Retrieve Automatic Output

Purpose: Retrieves queued automatic messages or specific automatic messages when an out-of-sequence automatic tag <atag> is received.

Category: Memory Administration Commands

Security: R

Syntax: RTRV-AO: [<tid>]:: [<ctag>]:::
[ATAGSEQ=<atagseq>] , [MSGTYPE=<msgtype>] ;

Field	Description
ATAGSEQ=	Retrieve messages with a specific <atag> (see <i>Automatic Message Tag <atag> on page 9-86</i>). The value can be replaced by an integer or integers. Multiple or a range of values can be specified by using the & or && respectively. For example, ATAGSEQ=301&&320 will cause the messages with an <atag> from 301 to 320 to be retrieved.
ctag	Correlation Tag (optional)
MSGTYPE=	Retrieve messages of a specific type: ALM, EVT, ALL. (see <i>Message Type <msgtype> on page 9-94</i>). For example, MSGTYPE=ALM will retrieve all the messages reported by the "REPT ALM" message. See <i>TL1 Automatic Messages on page 9-101</i> .
tid	Target ID of network element (optional)

Example: RTRV-AO:tid::ctag:::
ATAGSEQ=100&&110,MSGTYPE=ALM;

Retrieve Alarm Messages with an <atag> from 100 to 110.

RTRV-ARC-<LSType>

Name: Retrieve Automatic In-Service

Purpose: Retrieves the automatic in-service status (on/off) and delay time (1 to 168 hours) for all low-speed T1 or E1 channels.

Category: Transport Surveillance Commands

Security: RW

Syntax: RTRV-ARC- {T1 | E1} :<tid>:<aid>:<ctag>::QI;

Field	Description
aid	Access ID must either be ALL or be omitted. If omitted, the default is ALL.
ctag	Correlation Tag (optional)
delay	Delay time in hours, 1 to 168 (1 week). The factory default is 2 hours. This parameter appears in the response message (see below) and can be changed by the command <i>OPR-ARC-<LSType></i> on page 9-41.
QI	Qualified Inhibition (optional). If omitted, the default is QI.
tid	Target ID of network element (optional)

Example: RTRV-ARC-T1:tid::ctag;

Retrieve auto in-service status.

The following response appears when automatic in-service detection is turned on. If it is turned off, the response will be a simple COMPLD with no data.

Response Format:

```
<cr><lf><lf>
^^^<tid>^<YYYY-MM-DD>^<HH:MM:SS><cr><lf>
M^^<ctag>^COMPLD<cr><lf>
^^^"ALL,T1:QI,<delay>"
;
```

Response:

```
tid 2002-06-12 11:21:32
M ctag COMPLD
"ALL,T1:QI,2"
;
```

RTRV-ATTR-<AIDType>

Name: Retrieve Attribute

Purpose: Instructs the Wide Bank to return the notification code associated with the specified alarm or event. The notification code determines whether an event is alarmed and the severity assigned to the alarm or event. All alarm and event conditions (condtype) have default severities for notification conditions (ntfcnde) but most severities can be changed by the user. The assigned severities apply to alarms and events reported in the CLI and TL1 alarm messages and by the alarm LED indicators and alarm output contacts on the unit.

- This command does not retrieve environment (ENV) conditions.
- Severities can be assigned by the command *SET-ATTR-<AIDType>* on [page 9-75](#).
- Critical (CR), Major (MJ), and Minor (MN) alarms are reported by REPT ALM messages (see *TL1 Automatic Messages* on [page 9-101](#)).
- Not Alarmed (NA) events are reported by REPT EVT messages (see *TL1 Automatic Messages* on [page 9-101](#)).
- Not Reported (NR) events can be retrieved by the RTRV-COND command (see *RTRV-COND-<AIDType>* on [page 9-59](#)).

Category: Transport Surveillance Commands

Security: R

Syntax: `RTRV-ATTR- {T3 | T1 | E1 | EQPT} : [<tid>] : [<aid>] : [<ctag>] : : <ntfcncde> , <condtype> , <locn> , <dirn> , <tmpr> ;`

Field	Description
aid	Access ID must be ALL or omitted
condtype	<p>Type of alarm or event condition. Only the following conditions are valid:</p> <ul style="list-style-type: none"> • ACTLPBK – Loopback send code is Active • AISNAS – Alarm Indication Signal, North American Standard • BER-SF – Bit error rate signal failure • BER-SD – Bit error rate signal degrade • CONTEQPT – Control equipment failure • FAILTOSW – Failure to switch • IMPROPRMVL – Improper removal • INHAUTORSTEQPT – Revertive Off • INHAUTORSTSYNC – DS3 clockrevert Off • INHLPBK – Loopdetect Off • INHSWPR – Facility protection not enabled • INHSWWKG – Equipment protection not enabled • INT – Internal hardware failure • INTERR – Internal error detected • LOF – Loss of frame • LOS – Loss of signal • LPBKEQPT – Equipment loopback • LPBKLINE – Line loopback • LPBKMETALLIC – Metallic loopback • LPBKPAYLOAD – Payload loopback • NORMAL – Normal is used only for REPT EVT “clear” condition, with clarification in the description field to indicate which condition has cleared. • PROTNA – Protection unit is not available • PWR – Power +5V failure • RAI – Remote Alarm Indication • SYNCPRI – Loss of designated clock • TRMT – Transmitter failure • T-CVL – Threshold Violation - CV Line • T-CVP-P – Threshold Violation - CV Path p-parity • T-ESL – Threshold Violation - Errored seconds line • T-ESP-P – Threshold Violation - Errored seconds path p-parity • T-LOSS-L – Threshold Violation - Loss of signal seconds line • T-SESL – Threshold Violation - Severely errored seconds line • T-SESCP-P – Threshold Violation - Severely errored seconds path • WKSWPR – Working Unit Switched to Protect Unit • WKSWBK – Working Unit Switched Back to Working
ctag	Correlation Tag (optional)
dirn	<p>Direction</p> <ul style="list-style-type: none"> • RCV – receive • TX – transmit

Field	Description
locn	Location <ul style="list-style-type: none"> • FEND – far end • NEND – near end
ntfncde	Alarm severity notification code <ul style="list-style-type: none"> • CR – Critical, *C • MJ – Major, ** • MN – Minor, * • NA – Not Alarmed, A • NR – Not Reported
tid	Target ID of network element (optional)
tmper	Time period that these statistics were gathered – not supported in this release

Response Format:

```

    <tid> <date> <time>
M <ctag> COMPLD
(^^^^<aid>,<aidType>:<ntfncde>,<condtype>,<locn>,<dirn>"
<cr><lf>)*
;

```

* - The contents of the parentheses can occur zero or more times.

Example: `RTRV-ATTR-T3:tid:DS3-A:ctag:::CR;`

Retrieve notification codes for T3 critical alarms, as in the following response.

Response:

```

tid 2001-08-04 11:51:58
M ctag COMPLD
"DS3-A, T3:CR, LOF, NEND, RCV"
"DS3-A, T3:CR, LOS, NEND, RCV"
"DS3-A, T3:CR, SYNCPRI, , "
;

```

Example: `RTRV-ATTR-T1:tid:DS1-1:ctag:::MN;`

Retrieve notification codes for T1 minor alarms for DS1 #1.

Response:

```

tid 2001-08-04 11:51:59
M ctag COMPLD
"DS1-01, T1:MN, BER-SD, NEND, RCV"
;

```

RTRV-COND-<AIDType>

Name: Retrieve Condition

Purpose: Retrieves the current status of entities in the Wide Bank.

Category: Transport Surveillance Commands

Security: R

Syntax: RTRV-COND- {T3 | T1 | E1 | ENV | ALL} : [<tid>] : [<aid>] :
 [<ctag>] : : [<typereq>] ;

Field	Description
aid	Access ID depends on AIDType (optional). See <i>Access Identifier <aid> on page 9-84</i> . Null value defaults to ALL.
typereq	Type of condition or state to be retrieved. See <i>Condition Type <condtype> on page 9-87</i> . Null value defaults to ALL
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RTRV-COND-T1:tid:DS1-1:ctag::,,;

Retrieve current condition of DS1 #1.

Response: tid 2001-08-04 05:05:51
 M ctag COMPLD
 ;

Response Format:

```

    <tid> <date> <time>
M <ctag> COMPLD
^^^"<aid>:[<ntfcncde>],<condtype>,[<srveff>],[<ocrdat>],
[<ocrtm>],[<locn>],[<dirn>],[<tmper>],[<conddescr>]"
;
  
```

Field	Description
aid	Access ID. See <i>Access Identifier <aid></i> on page 9-84
ntfncde	Severity or class of alarm, event or condition. See <i>Notification Code <ntfncde></i> on page 9-96.
condtype	Type of alarm or condition. See <i>Condition Type <condtype></i> on page 9-87
srveff	Service Effect. See <i>Service Effect of Alarm or Condition <srveff></i> on page 9-98
ocrdat	Date when the event was detected (format: mm-dd)
oortm	Time when the event was detected (format: hh-mm-ss)
locn	Location. See <i>Location of Alarm or Condition <locn></i> on page 9-92
dirn	Direction. See <i>Direction of Alarm or Condition <dirn></i> on page 9-89
tmper	Time period: <ul style="list-style-type: none"> • 15-MIN – 15 minutes • 1-HR – 1 hour • 1-DAY – 1 day
conddescr	Detailed Description of Alarm condition. A maximum of 64 characters enclosed in escaped quotes (\").

Example: `RTRV-COND-T3:tid::ctag;`

Receive severities for all T3 alarms, as in the following response:

Response:

```

tid 2001-08-04 05:05:51
M ctag COMPLD
  "DS3-A,T3:LOS,SA,01-01,04-42-21,NEND,RCV,,\"Loss of Signal\""
  "DS3-A,T3:INHLPBK,NSA,,,,,\"Loopdetect Inhibited\""
  "DS3-A,T3:INHSWPR,NSA,,,,,\"DS3 Facility Protection Not Enabled\""
  "DS3-A,T3:PROTNA,NSA,,,,,\"Protection Unit not Available\""
;
    
```

RTRV-EQPT

Name: Retrieve Equipment

Purpose: Retrieve equipment configuration settings.

Category: Transport Surveillance Messages

Security: R

Syntax: RTRV-EQPT: [<tid>] :ALL: [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RTRV-EQPT:tid:ALL:ctag;

Response:

```
tid 2001-08-04 05:08:45
M ctag COMPLD
  "DS3-A:ACTIVE,2.41.0"
  "DS3-B:STANDBY,2.41.0"
  "DS1-CARD-1:ACTIVE,"
  "DS1-CARD-2:ACTIVE,"
  "DS1-CARD-3:ACTIVE,"
  "DS1-CARD-4:ACTIVE,"
  "DS1-CARD-5:ACTIVE,"
  "DS1-CARD-6:ACTIVE,"
  "DS1-CARD-7:ACTIVE,"
  "DS1-CARD-SPARE:ACTIVE,"
;
```

RTRV-HDR

Name: Retrieve Header

Purpose: Polls the Wide Bank. If it is alive, a normal response will be sent.

Category: Transport Surveillance Commands

Security: R

Syntax: RTRV-HDR: [<tid>] :: [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RTRV-HDR:tid::ctag;

RTRV-LOG

Name: Retrieve Log

Purpose: Displays the contents of the specified log.

Category: Transport Surveillance Commands

Security: R for Event log; RWA for Security log.

Syntax: RTRV-LOG: [<tid>] :ALL: [<ctag>] ::<lognm>;

Field	Description
ctag	Correlation Tag (optional)
lognm	Name of Log. Values are: <ul style="list-style-type: none">• SECURITY – Log where Security Events are Logged• EVT – Event Log
tid	Target ID of network element (optional)

Example: RTRV-LOG:tid:ALL:ctag::EVT;

RTRV-NETTYPE**Name:** Retrieve Network Element Type**Purpose:** Retrieves the type of network element. These values are fixed in the equipment.**Category:** Transport Surveillance Commands**Security:** R**Syntax:** RTRV-NETTYPE: [<tid>] :: [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RTRV-NETTYPE:tid::ctag;**Response Format:**

```

    tid 2002-12-04 11:51:58
M   ctag COMPLD
^^^"<vendor name>,<model name>,MUX,<software release>"
;

```

Field	Description
vendor name	"Carrier Access Corporation"
model name	"Wide Bank 28 DS3 Multiplexer"
software release	"2.41.0" – value is updated for each release

RTRV-PM-<FacilityType>

Name: Retrieve Performance Monitoring Data

Purpose: Retrieves performance monitoring statistics.

Category: Transport Surveillance Commands

Security: R

Syntax: RTRV-PM-{T3|T1|E1}:[<tid>]: [<FacilityID>]:
 [<ctag>]: : [<montype>], [<monlev>], [<locn>], , ,
 [<tper>], [<mondatt>], [<montm>];

Field	Description
FacilityID	Facility ID depends on selected Facility Type: <ul style="list-style-type: none"> • For T3, use DS3-A, DS3-B, or ALL • For T1, use DS1-1 to DS1-28, or ALL • For E1, use E1-1 to E1-27, or ALL
ctag	Correlation Tag (optional)
locn	Location of the statistics: NEND or null
mondatt	Date during which the time period started
monlev	Level that must be monitored to be reported: 1-UP or null
montm	Time during which the time period started
montype	Monitored parameter type: ALL or null
tid	Target ID of network element (optional)
tper	Time period that these statistics were gathered

Example: RTRV-PM-T1:tid:ALL:ctag: , , , , 15-MIN , , ;

Retrieve PM for all DS1s at 15-minute intervals, as shown below:

Response: tid 2001-08-04 05:42:38
M ctag COMPLD
"DS1-01, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-02, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-03, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-04, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-05, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-06, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-07, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-08, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-09, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-10, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-11, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-12, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-13, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-14, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-15, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-16, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-17, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-18, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-19, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-20, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-21, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-22, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-23, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-24, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-25, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-26, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-27, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
"DS1-28, :CSS, 660, PRTL, NEND, NA, 15-MIN, , "
;

Response Format:

```

<cr><lf><lf>
^^^<sid>^<YY-MM-DD>^<HH:MM:SS><cr><lf>
A^^<atag>^REPT^PM^<FacilityType>
^^^" [<FacilityId>]:<montype>,<monval>,[<vldty>],
    [<locn>],[<dirn>],[<tper>],[<mondatt>],[<montm>]"
;
    
```

Field	Description
FacilityType	T1, E1, T3
FacilityID	Facility ID depends on Facility Type: <ul style="list-style-type: none"> • For T1, values are DS1-1 to DS1-28 • For E1, values are E1-1 to E1-27 • For T3, values are DS3-A, DS3-B
atag	Automatic message tag. A sequential value is assigned to each message by the Wide Bank. Receiving a non-sequential value indicates that some messages have been lost.
dirn	Direction of traffic: <ul style="list-style-type: none"> • TRMT – transmit • RCV – receive
locn	Location: <ul style="list-style-type: none"> • NEND – near end • FEND – far end
mondatt	Date during which the time period started
montm	Time during which the time period started
montype	Monitored parameter type
monval	Monitor Value
sid	Source Identifier
tper	Time period that these statistics were gathered <ul style="list-style-type: none"> • 15-MIN – 15 minutes • 1-HR – 1 hour • 1-DAY – 1 day
vldty	Validity <ul style="list-style-type: none"> • COMPL – complete • PRTL – partial period

RTRV-PMSCHED-<FacilityType>

Name: Retrieve Performance Monitoring Schedule

Purpose: Retrieves the schedule for automatic performance monitoring reports.

Category: Transport Surveillance Commands

Security: R

Syntax: RTRV-PMSCHED-{T3|T1|E1|ALL}: [<tid>]: [<aid>]: [<ctag>];

Field	Description
aid	Access ID depends on selected Facility Type: <ul style="list-style-type: none"> • For T3, use DS3-A, DS3-B, or ALL • For T1, use DS1-1 to DS1-28, or ALL • For E1, use E1-1 to E1-27, or ALL • Null value defaults to ALL
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RTRV-PMSCHED-T1:tid:DS1-1:ctag;

Response:

```

tid 2001-08-04 05:58:05
M ctag COMPLD
  "ds1-01:,,,0,ALL,,NEND&FEND,RCV,15-MIN,,ALW"
  "ds1-01:,,,0,ALL,,NEND&FEND,RCV,1-HR,,ALW"
  "ds1-01:,,,0,ALL,,NEND&FEND,RCV,1-DAY,,ALW"
    
```

Response Format:

```

<cr><lf><lf>
^^^<sid>^<YY-MM-DD>^<HH:MM:SS><cr><lf>
A^^<atag>^REPT^PM^<FacilityType>
^^^ [<FacilityId>]:<montype>,<monval>,<[vldty]>,<[<locn>],<[<dirn>],<[<tmper>],<[<mondat>],<[<montm>]"
; .
    
```

Field	Description
ctag	Correlation Tag (optional)
dirn	Direction of traffic: <ul style="list-style-type: none"> • TRMT – transmit • RCV – receive • NA – not applicable

TL1 Commands and Messages

TL1 Command List

Field	Description
locn	Location: <ul style="list-style-type: none">• NEND – near end• FEND – far end
monlev	Monitor Level specifies the discriminating level for the requested monitored parameter. Currently, the Wide Bank only supports 1-UP, which means we will report and performance statistics that do not have a value of zero.
montype	Monitored Type. Values are: <ul style="list-style-type: none">• CSS – Control Slip Seconds count• CVL – Coding Violation count – Line. This montype supports Threshold Cross Alerts on the DS1s and DS3.• CVP-P – Coding Violation count – Path. This montype supports Threshold Cross Alerts on the DS3 only.• DGRML – Degraded Minute count – Line• ESL – Errored Second count – Line• ES-LFE – Errored Second count – Line, Far End• ESP-P – Errored Second count Path – P-bit parity. This montype supports Threshold Cross Alerts on the DS3 only.• LOSS-L – Loss of Signal Seconds count – Line• PSC – Protection Switching Count• PSD – Protection Switching Duration in seconds• SESCO-P – Severely Errored Second count – Path, DS3 CP-bit parity. This montype supports Threshold Cross Alerts on the DS3 only.• SEFS – Severely Errored Framing Second count• SESL – Severe Errored Second count – Line. This montype supports Threshold Cross Alerts on the DS3 only.• SES-LFE – Severe Errored Second Count – Line, Far End• UASL – Unavailability Second count – Line• UAS-LFE – Unavailability Second count – Line, Far End
numrept	The number of reports the user would like scheduled. A value of zero turns reports off. Otherwise, reports are sent every reporting interval and the number of reports is decremented. Even if reporting is inhibited (see <i>INH-PMREPT-<FacilityType></i> on page 9-38), the number will continue to be decremented. If the numrept value is omitted from the command, the Wide Bank will report every reporting interval indefinitely until another schedule command is issued.
reptinvl	Reporting Interval specifies how often reports are to be generated and sent: <ul style="list-style-type: none">• 15-MIN• 1-HR• 1-DAY Omitting this field defaults to 15-MIN.

Field	Description
reptstatm	Reporting Start Time specifies the time when the reports should start being generated. Currently, the Wide Bank only supports: <ul style="list-style-type: none">• Null• 0-0• 00-00 A non-null value will start the reports immediately.
tid	Target ID of network element (optional)
tmofst	Time Offset specifies the time offset from the end of the last complete accumulation time period to the beginning of the accumulation period specified with the tmper variable. This parameter will accept only the following values but these values are ignored and the time offset defaults to the current register: <ul style="list-style-type: none">• Null• 0-1-0
tmper	Time Period: <ul style="list-style-type: none">• 15-MIN• 1-HR• 1-DAY} Note: tmper must be equal to reptinvl or omitted.

RTRV-STATUS

Name: Retrieve Status

Purpose: Retrieves the system status showing what users are currently logged on.

Category: Security Commands

Security: R

Syntax: RTRV-STATUS: [<tid>] :: [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RTRV-STATUS:tid::ctag

Response:

```
tid 2001-08-04 11:51:58
M ctag COMPLD
  ",UserID-1
  &UserID-2
  &UserID-3"
;
```

The response is a list of users currently logged on. The names of the users are separated by the '&' character, and optionally by a carriage return and line feed.

RTRV-TH-<FacilityType>

Name: Retrieve Threshold Value

Purpose: Instructs the Wide Bank to return the threshold value, that when crossed, will issue a threshold crossing alert.

Category: Transport Surveillance Commands

Security: R

Syntax: RTRV-TH-{T3|T1|E1}:[<tid>]: [<aid>]: [<ctag>]: :
[<montype>] , , [<tmper>];

Field	Description
aid	Access ID. Omitting the field defaults to ALL. <ul style="list-style-type: none"> • ALL is a valid value for any facility type. • For T3, the aid can be ALL only or omitted. • For T1, the aid can be a single DS1, a list of DS1s, or a range of DS1s. • For E1, the aid can be a single E1, a list of E1s, or a range of E1s.
ctag	Correlation Tag (optional)
montype	The type of performance monitoring statistic the threshold exists for: <ul style="list-style-type: none"> • For T3s, values are: CVL, ESL, LOSS-L, SESL, CVP-P, ESP-P, SESCO-P. • For T1s and E1's values are CVL and ESL. If omitted, the field defaults to ALL.
tid	Target ID of network element (optional)
tmper	Time period that these statistics were gathered

Response Format:

```

tid 2001-08-04 11:51:58
M ctag COMPLD
  "<aid>:<montype>, , , <thlev>, <tmper>"
;
    
```

Field	Description
aid	Access ID
montype	The type of performance monitoring statistic the threshold exists for
thlev	Threshold Level, an integer value between 0 and (2 ³¹)-1, a range from zero to more than 2 billion.
tmper	Time period that these statistics were gathered

RTRV-TOD

Name: Retrieve Time of Day

Purpose: Instructs the Wide Bank to display the date and time.

Category: Transport Surveillance Commands

Security: R

Syntax: RTRV-TOD: [<tid>] :: [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: RTRV-TOD:tid::ctag;

```
      tid 2001-08-04 11:51:58
M  ctag COMPLD
"2001,08,04,11,51,46"
;
```

RTRV-USER-SECU

Name: Retrieve User Security

Purpose: Used by the administrator to retrieve the security parameters associated with a user or a list of users.

Category: Security Commands

Security: RWA

Syntax: RTRV-USER-SECU: [<tid>] :<uid>: [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
uid	User ID. Multiple user IDs can be grouped, as in uid1&uid2. ALL will retrieve all users.

Example: `RTRV-USER-SECU:tid:ALL:ctag;`

Retrieves security parameters for all users.

Response: tid 2001-12-19 11:51:58
M ctag COMPLD
"allan:RWA"
"fred:RW"
"tester1:RW"
"tester2:RW"
"william:RW"
"sylvia:R"
;

Security	Description
RWA	Read-Write-Administration for administrators (admins) with full privileges
RW	Read-Write for operators that need to monitor and edit data
R	Read Only for users that need only to monitor data

Example: `RTRV-USER-SECU:tid:ALLAN:ctag;`

Retrieve security parameters for ALLAN.

Example: `RTRV-USER-SECU:tid:ALLAN&WILLIAM&SYLVIA:ctag;`

Retrieve security parameters for ALLAN and WILLIAM and SYLVIA.

SCHED-PMREPT-<FacilityType>

Name: Schedule Performance Monitoring Report

Purpose: Schedules a performance report for the selected FacilityType. These are automatic reports that provide performance statistics (see *Report Performance Monitoring Message Format* on page 9-105). PM reports can be allowed or inhibited (see *ALW-PMREPT-<FacilityType>* on page 9-22 and *INH-PMREPT-<FacilityType>* on page 9-38).

Category: Transport Surveillance Commands

Security: RW

Syntax: SCHED-PMREPT-**<{T3|T1|E1}>**: [**<tid>**]:**<aid>**: [**<ctag>**]:: [**<reptinvl>**], [**<reptstatm>**], [**<numrept>**], , [1-UP], [NEND], , [**<tper>**], [0-1-0];

Example: SCHED-PMREPT-T1:tid:ALL:ctag::15-MIN,,10,,,,,15-MIN;

Schedule ten T1 Performance Reports at 15-minute intervals.

Field	Description
0-1-0	Time Offset (optional) specifies the time offset from the end of the last complete accumulation time period to the beginning of the accumulation period specified with the tper variable. The Wide Bank will accept the following values but the time offset will always be zero: <ul style="list-style-type: none"> • 0-1-0 – no offset
1-UP	Monitor Level (optional) specifies the discriminating level for the requested monitored parameter. The Wide Bank currently supports the following: <ul style="list-style-type: none"> • 1-UP – report all performance statistics that do not have a value of zero
ctag	Correlation Tag (optional)
NEND	Location (optional): <ul style="list-style-type: none"> • NEND – near end and far end
numrept	The number of reports (optional) the user would like scheduled. A value of zero turns reports off. Otherwise, reports are sent every reporting interval and the number of reports is decremented. Even if reporting is inhibited (see <i>INH-PMREPT-<FacilityType></i> on page 9-38), the number will continue to decrement. If the numrept value is omitted from the command, the Wide Bank will report every reporting interval indefinitely until another schedule command is issued. <ul style="list-style-type: none"> • null – (default) report all intervals • 0 – no reports • <i>integer</i> – number of reports

Field	Description
reptinvl	Reporting Interval (optional) specifies how often reports are to be generated and sent: <ul style="list-style-type: none"> • 15-MIN – (default) • 1-HR • 1-DAY
reptstatm	Reporting Start Time (optional) specifies the time when the reports should start being generated. All selections will start reports at end of current reporting interval <ul style="list-style-type: none"> • null – (default) • 0-0 • 00-00
tid	Target ID of network element (optional)
tmper	Time Period (optional): <ul style="list-style-type: none"> • 15-MIN • 1-HR • 1-DAY} Note: tmper must be equal to reptinvl or omitted.

SET-ATTR-<AIDType>

Name: Set Attribute

Purpose: Assigns a severity to an alarm or event condition. All alarm and event conditions (condtype) have default severities for notification conditions (ntfcnde) but most severities can be changed by the user. The assigned severities apply to alarms and events reported in the CLI and TL1 alarm messages and by the alarm LED indicators and alarm output contacts on the unit.

NOTE: Notification codes can only be changed through the TL1 interface, except for the standby Controller self-test failure and communications failure (see *ALARMS STANDBY* on page 8-11).

- This command does not apply to environment (ENV) conditions.
- Transient Conditions (TC) can be assigned to Not Alarmed (NA) and Not Reported (NR) severities.
- Condition severities are retrieved with the command *RTRV-ATTR-<AIDType>* on page 9-56.
- Critical (CR), Major (MJ), and Minor (MN) alarms are reported by REPT ALM messages (see *TL1 Automatic Messages* on page 9-101).
- Not Alarmed (NA) events are reported by REPT EVT messages (see *TL1 Automatic Messages* on page 9-101).

- Not Reported (NR) events do not produce any REPT messages. However, these events are logged and can be retrieved by the RTRV-COND command (see *RTRV-COND-<AIDType>* on page 9-59).

Category: Transport Surveillance Commands

Security: RW

Syntax: SET-ATTR- {T3 | T1 | E1 | EQPT} : [<tid>] : [<aid>] : [<ctag>] :: <ntfcncde> , <condtype> , <locn> , <dirn> , <tmpr> ;

Field	Description
aid	Access ID must be ALL or omitted
condtype	Type of alarm or event condition. Only the following conditions are valid: <ul style="list-style-type: none"> • AISNAS – Alarm Indication Signal, North American Standard • BER-SF – Bit error rate signal failure • BER-SD – Bit error rate signal degrade • CONTEQPT – Control equipment failure • FAILTOSW – Failure to switch • IMPROPRMVL – Improper removal • INT – Internal hardware failure • INTERR – Internal error detected • LOF – Loss of frame • LOS – Loss of signal • PWR – Power +5V failure • RAI – Remote Alarm Indication • SYNCPRI – Loss of designated clock • TRMT – Transmitter failure
ctag	Correlation Tag (optional)
dirn	Direction – not supported in this release
locn	Location – not supported in this release
ntfcncde	Alarm severity notification code: <ul style="list-style-type: none"> • CR – Critical, *C • MJ – Major, ** • MN – Minor, * • NA – Not Alarmed, A • NR – Not Reported
tid	Target ID of network element (optional)
tmper	Time period that these statistics were gathered – not supported in this release

Example: SET-ATTR-T1:tid::ctag::MN,LOS,,,;

Assign Minor alarm severity to T1 Loss of Signal.

SET-ATTR-SECUDFLT

Name: Set Attribute Security Default Time-out

Purpose: Set the number of minutes before session inactivity times out the TL1 TCP/IP port. When the command is issued, any active sessions will be updated with the new session time-out period. Setting the tmout parameter to zero will turn off session inactivity time-outs so that sessions will never time out. The system default time-out is 31 minutes.

Note: This command applies only to TL1 sessions using the TCP/IP port on that Wide Bank. It does not affect TL1 sessions using the TL1 RS-232 port or any CLI sessions using TCP/IP or RS-232.

Category: Memory Administration Commands

Security: RWA

Syntax: SET-ATTR-SECUDFLT: [<tid>] :: [<ctag>] :: TMOUT=<tmout>;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)
tmout	Time-out period in minutes: <ul style="list-style-type: none"> • Any positive integer value • A zero value will disable timeout • Default value is 31

Example: SET-ATTR-SECUDFLT:tid::ctag::TMOUT=15;

Set user TCP/IP sessions to time-out after 15 minutes of inactivity. For description of time-out message, see *Cancel User Session Event Message Format* on [page 9-106](#).

SET-SID

Name: Set System Identification

Purpose: Set the TL1 network identification of the Wide Bank.

Category: Memory Administration Commands

Security: RWA

Syntax: SET-SID: [<tid>] :: [<ctag>] :: <newSID>;

Field	Description
ctag	Correlation Tag (optional)
newSID	New System Identification: Up to 20 alphanumeric or hyphen characters
tid	Target ID of network element (optional)

Example: SET-SID:tid::ctag::WB-1;

Set new SID to WB-1.

Response: tid 2002-01-05 11:23:48
M ctag COMPLD
;

The first response following the SET-SID command will display the original tid so that the response can be matched to the command. Subsequent commands and responses will use the new tid.

SET-TH-<FacilityType>

Name: Set Threshold Value

Purpose: Sets the threshold for supported performance monitored facility types. If threshold is exceeded, a threshold crossing alert will be sent.

Category: Transport Surveillance Commands

Security: RW

Syntax: SET-TH-{T3|T1|E1}:[<tid>]: [<aid>]: [<ctag>]: : :
[<montype>], <thlev>, , , <tmper>;

Field	Description
aid	Access ID depends on selected Facility Type: <ul style="list-style-type: none"> • For T3, use DS3-A, DS3-B, or ALL • For T1, use DS1-1 to DS1-28, or ALL • For E1, use E1-1 to E1-27, or ALL • Null defaults to ALL
ctag	Correlation Tag (optional)
montype	The type of performance monitoring statistic the threshold exists for: <ul style="list-style-type: none"> • For T3s, values are: CVL, ESL, LOSS-L, SESL, CVP-P, ESP-P, SESCO-P. • For T1s and E1s, values are CVL and ESL.
tid	Target ID of network element (optional)
thlev	Threshold Level, an integer value between 0 and (2 ³¹)-1, a range from zero to more than 2 billion. If the number monitored for the performance type exceeds the threshold value for the given time period, a threshold crossing alert will be generated. If the value is zero, no threshold crossing alerts will be generated.
tmper	Time period that these statistics were gathered

Example: SET-TH-T3:tid:ALL:ctag::CVL,100,,,15-MIN;

STA-LOCL-RST

CAUTION! THE RESTORATION COMMAND WILL DISRUPT SERVICE.

Name: Start Local Restoration

Purpose: Instructs the Wide Bank to restore the configuration parameters to their default values.

Category: Transport Surveillance Commands

Security: RW

Syntax: STA-LOCL-RST: [<tid>] :: [<ctag>] ;

Field	Description
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: STA-LOCL-RST:tid::ctag;

SW-TOPROTN-<FacilityType>

Name: Switch To Protection

Purpose: Instructs the Wide Bank to switch to the standby T3 Controller in slot B, or to move a DS1 channel to the spare card.

NOTE: If you switch T3 Controllers, your TL1 session will be terminated.

Category: Transport Surveillance Commands

Security: RW

Syntax: SW-TOPROTN-{T3|T1|E1}: [<tid>] : [<aid>] : [<ctag>] ;

Field	Description
aid	Access ID depends on FacilityType: <ul style="list-style-type: none"> • For T3, use ALL • For T1, use DS1-1 to DS1-28 • For E1, use E1-1 to E1-27
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: SW-TOPROTN-T3:tid:ALL:ctag;

Switch to Protection Controller.

Example: SW-TOPROTN-T1:tid:DS1-5:ctag;

Move DS1 #5 to Spare Card.

SW-TOWKG-<FacilityType>

Name: Switch To Working

Purpose: Instructs the Wide Bank to switch to the T3 Controller in slot A, or to move a DS1 channel to its home card.

NOTE: If you switch T3 Controllers, your TL1 session will be terminated.

Category: Transport Surveillance Commands

Security: RW

Syntax: SW-TOWKG- {T3 | T1 | E1} : [<tid>] : [<aid>] : [<ctag>] ;

Field	Description
aid	Access ID depends on FacilityType: <ul style="list-style-type: none"> • For T3, use ALL • For T1, use DS1-1 to DS1-28 • For E1, use E1-1 to E1-27
ctag	Correlation Tag (optional)
tid	Target ID of network element (optional)

Example: SW-TOWKG-T3:tid:ALL:ctag;

Switch to Working Controller.

Example: SW-TOWKG-T1:tid:DS1-5:ctag;

Move DS1 #5 Home.

TL1 Parameter Descriptions

- Access Identifier <aid> ... 9-84
- Access Identifier Types <AIDType> ... 9-85
- Additional Access Identifier Information <aiddet> ... 9-86
- Alarm Code <almcde> ... 9-86
- Alarm Message <almmsg> ... 9-86
- ATAG Segment <atagseg> ... 9-86
- Automatic Message Tag <atag> ... 9-86
- Command Mode <cmdmde> ... 9-86
- Completion Codes ... 9-87
- Condition Description <conddescr> ... 9-87
- Condition Effect <condeff> ... 9-87
- Condition Type <condtype> ... 9-87
- Correlation Tag <ctag> ... 9-89
- Data Segment <data_seg> ... 9-89
- Date <date> ... 9-89
- Direction of Alarm or Condition <dirn> ... 9-89
- DS1/E1 Properties ... 9-90
- DS3 Properties ... 9-91
- Environment Access Identifier (EnvAID) ... 9-91
- Equipment Parameters ... 9-92
- Location of Alarm or Condition <locn> ... 9-92
- Log Identifier <lognm> ... 9-93
- Loopback Type <lpbktype> ... 9-93
- Memory <frommem> and <tomem> ... 9-94
- Message Type <msgtype> ... 9-94
- Monitor Date <mondatt> ... 9-94
- Monitor Level <monlev> ... 9-94
- Monitor Time <montmt> ... 9-94
- Monitored Parameter Type <montype> ... 9-95
- Notification Code <ntfnccd> ... 9-96
- Number of Reports <numrept> ... 9-96
- Occurrence Date <ocrdat> ... 9-96
- Occurrence Time <ocrtm> ... 9-96
- Phase <ph> ... 9-96
- Private Identifier <pid> ... 9-97
- Reporting Interval <reptinvl> ... 9-97
- Reporting Start Time <reptstatm> ... 9-97
- Restoration Function Codes ... 9-97
- Security Alarm Type <secualmtype> ... 9-97
- Service Effect of Alarm or Condition <srveff> ... 9-98
- Target Identifier <tid> and Source Identifier <sid> ... 9-98
- Threshold Level <thlev> ... 9-98
- Time <time> ... 9-99
- Time Offset <tmofst> ... 9-99
- Time Period <tmper> ... 9-99
- Type or Request <typereq> ... 9-99
- User Access Privilege <uap> ... 9-99
- User Identifier <uid> ... 9-100

Access Identifier <aid>

The Access Identifier determines which entity in the Wide Bank is addressed. The Access ID is represented by <aid>.

NOTE: For commands specifying DS1 and E1 circuits, you can often use the single-ampersand notation (&) to enter lists and the double-ampersand notation (&&) to specify a range of DS1s or E1s. For example, to enter DS1 #1, #3, and #5, enter DS1-1&DS1-3&DS1-5. To specify a range from DS1 #1 through #6, enter DS1-1&&DS1-6. The & and && notation can normally be used whenever the equivalent CLI command allows you to enter a list or range.

Facility Type	AID	Description and Possible Values
E1	E1 Low Speed Cards	E1-CARD-MSO-SPARE E1-CARD-MSO- <i>{1-7}</i> E1-CARD-SPARE E1-CARD- <i>{1-7}</i>
E1	E1 Low Speed Circuits	E1-SPARE- <i>{1-4}</i> E1- <i>{01-27}</i> .
ENV	Environment	EXT48V- <i>{A,B}</i> FAN- <i>{A,B}</i> TEMP- <i>{A,B}</i>
EQPT	Equipment	POWER-5V-A POWER-5V-B DS1-SPARE- <i>{1-4}</i> DS1- <i>{01-28}</i> E1-SPARE- <i>{1-4}</i> E1- <i>{01-27}</i> DS1-CARD-MSO-SPARE DS1-CARD-MSO- <i>{1-7}</i> DS1-CARD-SPARE DS1-CARD- <i>{1-7}</i> E1-CARD-MSO-SPARE E1-CARD-MSO- <i>{1-7}</i> E1-CARD-SPARE E1-CARD- <i>{1-7}</i> DS3-A DS3-B
T1	DS1 Low Speed Cards	DS1-CARD-MSO-SPARE DS1-CARD-MSO- <i>{1-7}</i> DS1-CARD-SPARE DS1-CARD- <i>{1-7}</i>
T1	DS1 Low Speed Circuits	DS1-SPARE- <i>{1-4}</i> DS1- <i>{01-28}</i>

Facility Type	AID	Description and Possible Values
T3	DS3 High Speed Cards	DS3-A DS3-B

Error Response: Invalid Access Identifier

```
tid 2001-08-04 10:42:22
M ctag DENY
  IIAC
  /* Invalid Access Identifier */
;
```

Access Identifier Types <AIDType>

This parameter specifies the type of entity that the operating system wants to address. Fields of this type are represented by {AIDType}.

Type	Description
ALL	All Access IDs
E1	E1 Circuit
ENV	ENV Circuit
EQPT	Equipment Unit
T1	T1 (or DS1) Circuit
T3	T3 (or DS3) Circuit

Error Response: Invalid Access Identifier Type

```
tid 2001-08-04 10:42:22
M ctag DENY
  IICM
  /* Invalid Command */
;
```

Additional Access Identifier Information <aiddet>

Because there can be two Controller cards, it may be necessary to specify whether the active or standby Controller is being addressed.

Identifier	Description
ACTIVE	Active DS3 Controller
STANDBY	Standby DS3 Controller

Alarm Code <almcde>

This parameter identifies the severity of the autonomous message. Identifiers are:.

Identifier	Description
*C	Critical
**	Major
*	Minor
^A	Automatic Message

Alarm Message <almmsg>

The message is a detailed text description of the alarm. It is up to 40 characters long and enclosed with a pair of escaped quotes.

ATAG Segment <atagseg>

This parameter specifies the list of alarm tag <atag> messages to be retrieved.

Automatic Message Tag <atag>

NOTE: For simplicity, examples and responses in this document will represent the <atag> by the lower-case letters atag.

This field is represented by <atag>. This tag is used in sequence by the Wide Bank in automatic messages. If an out-of-sequence value for this tag is received by the management application, it means that some automatic messages may have been missed.

Command Mode <cmdmde>

This parameter indicates the command execution mode: NORM or FRCD. This is hard-coded to FRCD in the Wide Bank, which means that existing parameter settings may be overridden in order to execute the command.

Completion Codes

Code	Description
COMPLD	Command received, executed, and completed.
DENY	Execution denied.
PRTL	Command received but only partially executed.
RTRV	Completion code of multiple responses to RTRV commands. The final response should have the COMPLD completion code.

Condition Description <conddescr>

This is detailed text description of the condition. It is up to 64 characters long and enclosed with a pair of escaped quotes.

Condition Effect <condeff>

This is the effect of the condition on the system.

Condition Code	Description
CL	Clear – the condition effect used to clear standing conditions.
SC	Standing Condition – an event that must be cleared.
TC	Transient Condition – does not need clearing. It happens and then it is over.

Condition Type <condtype>

This parameter describes the type of alarm, event or condition. This field is represented by <condtype>.

Alarmed Condition Types

Condition	Description
ACTLPBK	Loopback send code is Active
AISNAS	Alarm Indication Signal – North American Standard
BER-SD	Bit Error Rate – Signal Degrade
BER-SF	Bit Error Rate – Signal Failure
CLFAN	Cooling Fan failure
CONTEQPT	Control Equipment failure
FAILTOSW	Failure to Switch to protection

TL1 Commands and Messages

TL1 Parameter Descriptions

Condition	Description
HITEMP	High Temperature
IMPROPRMVL	Improper card Removal
INHAUTORSTEQPT	Revertive Off
INHAUTORSTSYNC	DS3 clockrevert Off
INHLPBK	Loopdetect Off
INHSWPR	Facility protection not enabled
INHSWWKG	Equipment protection not enabled
INT	Internal hardware failure
INTERR	Internal error detected
LOF	Loss of frame
LOS	Loss of signal
LPBKEQPT	Equipment loopback
LPBKLINE	Line loopback
LPBKMETALLIC	Metallic loopback
LPBKPAYLOAD	Payload loopback
NORMAL	Normal condition is used only for REPT EVT “clear” condition, with clarification in the description field to indicate which condition has cleared.
PROTNA	Protection Unit not Available
PWR	Power +5V failure
PWR	Power -48V failure or low
RAI	Remote Alarm Indication
SYNCPRI	Loss of designated clock
TRMT	Transmitter Failure
T-x	Threshold Crossing Alert, where “x” represents a montype. For x values, see <i>Monitored Parameter Type <montype></i> on page 9-95 .
WKSWBK	Working unit switched back to working
WKSWPR	Working unit switched to protect unit

Error Response: Invalid Condition Type

```
tid 2001-11-02 01:41:20
M ctag DENY
  INUP
  /* Invalid Payload block. Invalid positional field. */
;
```

Correlation Tag <ctag>

NOTE: For simplicity, examples and responses in this document will represent the <ctag> by the lower-case letters ctag.

This field is represented by <ctag>. The correlation tag is used to match commands and responses. It is sent out as part of the command, and the Wide Bank returns it as part of the response. The correlation tag is assigned by the user issuing the command and can be arbitrarily chosen. Each command issued should be assigned a different correlation tag to prevent confusing commands and responses.

Correlation tags are optional in TL1 commands. The correlation tag can contain between zero and six alphanumeric characters. If the correlation tag is not issued with the command, the responses to that command will have a correlation tag with a value of zero.

An invalid ctag will produce the following error response.

```
      tid 2001-08-05 00:40:54
M   ctag DENY
      IICT
      /* Invalid Correlation Tag */
;
```

Data Segment <data_seg>

This parameter specifies the data to be written. The value is a hexadecimal string.

Date <date>

This parameter specifies the time. The date format is YY-MM-DD, where YY is the last two digits of the year, MM is the month, and DD is the day.

Direction of Alarm or Condition <dirn>

This parameter indicates the direction of the alarm or condition with respect to the Wide Bank.

Identifier	Description
NA	Not Applicable
RCV	Receive
TRMT	Transmit

Error Response: Invalid Direction

This parameter is used in automatic messages and is not supported in TL1 commands. If issued as part of a command, the following error response is returned.

```
tid 2001-08-04 12:06:48
M ctag DENY
  ENEQ
/* Direction (dirn) not supported */
;
```

DS1/E1 Properties

Field	Description and Possible Vales
DLCID	Circuit ID: ASCII string – up to 32 characters.
LBO	Line Build Out (length): (Applies to T1 only. E1 has no LBO.) <ul style="list-style-type: none">• 1 – DSX (0'-110')• 2 – DSX (110'-220')• 3 – DSX (220'-330')• 4 – DSX (330'-440')• 5 – DSX (440'-550')• 6 – DSX (550'-660')
LINECDE	Line Code. (Applies to T1 only. E1 is hard coded to HDB3.) <ul style="list-style-type: none">• AMI – Alternate Mark Inversion,• B8ZS – Bipolar with 8-zero Substitution
OMODE	Output Mode: <ul style="list-style-type: none">• NORM – Normal Data• AIS – Alarm Indication Signal• QRSS – Quasi-random Signal, unframed• Null value defaults to NORM.• QRSU is not supported.
RVRTFLAG	Revertive Lockout Flag: <ul style="list-style-type: none">• LCKD – Locked, DS1 will remain on spare until flag is cleared, new card is inserted, or DS1 is sent home manually.• UNLCKD – Unlocked, DS1 will stay on spare if card self-test fails, otherwise it will return to the home channel after two minutes.

Error Message: Invalid T1/E1 Parameter or Value

```
tid 2001-08-04 13:18:00
M ctag DENY
  INUP
/* Invalid Payload block. Invalid name value field. */
;
```

DS3 Properties

Field	Description and Possible Vales
CKTID	Circuit Identification Parameter: ASCII string – up to 32 characters.
FMT	DS3 digital signal format: <ul style="list-style-type: none"> • CBIT – C-bit Parity format, M23 Framing format • M23 – M23 Framing format
LBO	Line Build Out (length): <ul style="list-style-type: none"> • 1 – Short Line Length (< 50 feet) • 2 – Long Line Length (>= 50 feet)
OMODE	Output Mode: <ul style="list-style-type: none"> • NORM – Normal Data • AIS – Alarm Indication Signal • QRSS – Quasi-random Signal, unframed • Null value defaults to NORM. • QRSU is not supported.

Error Message: Invalid T3 Parameter or Value

```

tid 2001-08-04 13:18:00
M ctag DENY
INUP
/* Invalid Payload block. Invalid name value field. */
;

```

Environment Access Identifier (EnvAID)

Field	Description and Possible Values
ALL	All of following. Null value defaults to ALL.
EXT48V-A	External -48V Power Input to DS3 Controller A
EXT48V-B	External -48V Power Input to DS3 Controller B
FAN-A	Faceplate Fan A
FAN-B	Faceplate Fan B
TEMP-A	DS3 Controller A over temperature
TEMP-B	DS3 Controller B over temperature

Equipment Parameters

Field	Description and Possible Values
ID	Equipment ID: Up to 20 ASCII characters.
TMG	Timing Source: <ul style="list-style-type: none">• INT – Internal clock• EXT – External Clock, Slave to DS3 Line• LINE – Slave to DS3 Line

Error Message: Invalid Equipment Parameter Value

```
tid 2001-08-04 13:18:00
M ctag DENY
INUP
/* Invalid Payload block. Invalid name value field. */
;
```

Error Message: Invalid Test Session Number

Test session numbers are not supported.

Location of Alarm or Condition <locn>

This parameter indicates the location of the alarm condition.

Identifier	Description
FEND	Far End: At a Distant Entity connected to the Identified Entity
NEND	Near End: At the Identified Entity

Error Response: Invalid Location

```
tid 2001-08-04 11:51:58
M ctag DENY
INUP
/* Invalid Payload block. Invalid positional field. */
;
```

Log Identifier <lognm>

This indicates the name of the log.

Identifier	Description
EVT	Event Log
EVT-SBY	Event log in Standby Controller. This identifier can only be used to clear the log in the Standby Controller.
SECURITY	Log where Security Events are Logged

Error Response: Invalid Log Identifier

```
tid 2001-08-04 11:51:58
M ctag DENY
  INUP
  /* Invalid Payload block. Invalid positional field. */
;
```

Loopback Type <lpbktype>

This indicates the type of loopback.

Identifier	Description
EQUIPMENT	Equipment Loopback. Valid for T1/E1 and T3.
LINE	Line Loopback. Valid for T1/E1 and T3.
METALLIC	Metallic Line Loopback. Valid for T1/E1 only.
PAYLOAD	Payload Loopback. Valid for T3 only.

Error Response: Invalid Loopback Type

```
tid 2001-08-04 11:51:58
M ctag DENY
  INUP
  /* Invalid Payload block. Invalid positional field. */
;
```

Memory <frommem> and <tomem>

From Memory <frommem> specifies the data area from which memory is to be copied, while To Memory <tomem> specifies data area where memory is to be copied to.

Code	Description
ACTIVE	Specifies memory area in active Controller
CONFIG	Specifies configuration memory area
STANDBY	Specifies memory area in standby Controller
TEMP	Specifies temporary memory area

Message Type <msgtype>

This parameter specifies the type of autonomous message to be retrieved.

Type	Description
ALM	Alarm
DBCHG	Database Change
EVT	Event
LOG	Log
PM	Performance Monitority

Monitor Date <mondatt>

This parameter specifies the starting date of the performance monitoring (PM) or storage register period defined with the <tmper> variable.

Monitor Level <monlev>

This parameter specifies the discriminating level for the requested monitored parameter. The Wide Bank currently supports only 1-UP, which means it will report any performance statistics that do not have a value of zero.

Monitor Time <montm>

This parameter specifies the starting time of the performance monitoring (PM) or storage register period defined with the <tmper> variable.

Monitored Parameter Type <montype>

This identifies the type of parameter being monitored.

Identifier	Description
CSS	Control Slip Seconds count
CVL	Coding Violation count – Line. This montype supports Threshold Cross Alerts on the DS1s and DS3.
CVP-P	Coding Violation count – Path. This montype supports Threshold Cross Alerts on the DS3 only.
DGRML	Degraded Minute count – Line
ESL	Errored Second count – Line
ES-LFE	Errored Second count – Line, Far End
ESP-P	Errored Second count Path – P-bit parity. This montype supports Threshold Cross Alerts on the DS3 only.
LOSS-L	Loss of Signal Seconds count – Line
PSC	Protection Switching Count
PSD	Protection Switching Duration in seconds
SEFS	Severely Errored Framing Second count
SESCP-P	Severely Errored Second count – Path, DS3 CP-bit parity. This montype supports Threshold Cross Alerts on the DS3 only.
SESL	Severely Errored Second count – Line. This montype supports Threshold Cross Alerts on the DS3 only.
SES-LFE	Severe Errored Second Count – Line, Far End
UASL	Unavailability Second count – Line
UAS-LFE	Unavailability Second count – Line, Far End

Error Response: Invalid Monitored Parameter Type

```

tid 2001-08-04 12:12:07
M ctag DENY
  INUP
  /* montype must be "ALL" or NULL */
;

```

The following error occurs for invalid montype in set threshold or retrieve threshold commands.

```

2001-08-05 22:39:34
M 0 DENY
  INUP
  /* Invalid Payload block. Invalid positional field. */
;

```

Notification Code <ntfncde>

The notification code specifies the severity or class of alarm, event or condition. This field is represented by <ntfncde>.

Identifier	Description
CL	Condition Cleared
CR	Critical Alarm
MJ	Major Alarm
MN	Minor Alarm
NA	Not Alarmed
NR	Not Reported

Error Response: Invalid Notification Code

```
tid 2001-08-04 01:41:20
M ctag DENY
  INUP
  /* Invalid Payload block. Invalid positional field. */
;
```

Number of Reports <numrept>

This parameter specifies the number of reports to be generated and sent.

Occurrence Date <ocrdat>

This parameter specifies the date when the event occurred. The format is MM-DD, where MM is the month and DD is the day.

Occurrence Time <ocrtm>

This parameter specifies the time when event occurred. The format is HH-MM-SS, where HH is the hours (24-hour clock), MM is the minutes, and SS is the seconds.

Phase <ph>

This parameter specifies the degree to which the system should be initialized. This parameter is currently accepted but ignored.

Private Identifier <pid>

This parameter specifies the private password identifier. This is a string of up to ten ASCII characters and must contain at least two non-alphabetic characters, with at least one non-alphanumeric character. Example: FRED-1

Reporting Interval <reptinvl>

This parameter specifies how often reports are to be generated and sent: 15-MIN, 1-HR, or 1-DAY.

Reporting Start Time <reptstatm>

This parameter specifies the time when the reports should start being generated. The Wide Bank currently supports only NULL, 0-0, or 00-00. All of these start the reports immediately.

Restoration Function Codes

These function codes identify the area within the NE that restoration is allowed or inhibited.

Code	Description
DS1EQPT	Allow or inhibit autorestitution of a DS1 card
DS3EQPT	Allow or inhibit autorestitution of the DS3 card
SYNC	Allow or inhibit autorestitution of the clock

Security Alarm Type <secualmtype>

This parameter explains type of security alarm.

Type	Description
INTRUSION	There were 3 consecutive failed login attempts
LOGBUFR90-SECULOG	The security log is 90% full
LOGBUFROVFL-SECULOG	The security log buffer is overflowing
T-UIDAGE	A user ID has not been used over a long period of time and should be disabled. The Wide Bank does not currently support T-UIDAGE.

Service Effect of Alarm or Condition <srveff>

This field is represented by <srveff>.

Error Response: Invalid Service

Identifier	Description
NSA	Non-Service affecting Condition
SA	Service affecting Condition

Service Effect Codes are used in automatic messages and are not supported in TL1 commands. When a service effect is specified in a command, the following error response is returned:

```
tid 2001-08-04 01:41:20
M ctag DENY
  ENEQ
  /* Service effect (srveff) not supported */
;
```

Target Identifier <tid> and Source Identifier <sid>

NOTE: For simplicity, examples and responses in this document will represent the target id and source identifiers by the lower-case letters tid and sid.

The target identifier <tid> specifies the network element to which the command is sent. The source identifier <sid> is part of the response, and specifies which network element transmitted the response. Both tid and sid are alphanumeric or hyphen characters.

The target identifier is optional in TL1 commands. However, if a value is entered that does not match the target identifier stored on the network element, the following error response is returned.

```
tid 2001-08-05 00:43:22
M ctag DENY
  IITA
  /* Input, InvalidTarget Identifier */
;
```

The target identifier or source identifier is set by the command *tl1 networkid "networkid"* issued from the CLI of the network element to which the target identifier belongs. Any commands issued to that network element must contain its target identifier. That same target identifier will become the source identifier in any response that specific network element sends back.

Threshold Level <thlev>

This parameter specifies the threshold level. If this level is exceeded, the Wide Bank will send an event report for the associated parameter.

Time <time>

This parameter specifies the date. The date format is HH:MM:SS, where HH is the hour (24-hour clock), MM is the minutes, and SS is the seconds.

Time Offset <tmofst>

This parameter specifies the time offset from the end of the last complete accumulation time period to the beginning of the accumulation period specified with the <tmper> variable. The Wide Bank will accept NULL and 0-1-0 values but these values are ignored and the time offset defaults to the current register.

Time Period <tmper>

This identifies the time period for performance monitoring.

Identifier	Description
1-DAY	One Day
1-HR	One Hour
15-MIN	15 Minutes

Error Response: Invalid Time Period

```
tid 2001-08-04 11:51:58
M ctag DENY
  INUP
/* Invalid Payload block. Invalid positional field. */
;
```

Type or Request <typereq>

This parameter describes the type of condition or state to be retrieved. This field is represented by <typereq>. Values can be any specific <condtype> (see *Condition Type <condtype> on page 9-87*).

User Access Privilege <uap>

This parameter determines which commands the user can issue.

Identifier	Description
R	Monitor: Cannot change any parameters or configuration items.
RW	Operator: Can issue any command, except security commands.
RWA	Administrator: Can issue any command.

Error Response: Illegal User Access Privilege

```
      tid 2001-08-04 01:41:20
M    ctag DENY
      INUP
      /*  Invalid Payload block.  Invalid positional field.  */
;
```

Error Response: Insufficient Privilege to Execute Command

```
      tid 2001-08-04 10:42:22
M    ctag DENY
      PICC
      /*  Illegal Command Code  */
;
```

User Identifier <uid>

This parameter specifies the user identifier. This is a string of up to 10 alphanumeric characters.

TL1 Automatic Messages

- Report Alarm Message Format ... 9-101
- Report Event Message Format ... 9-104
- Report Alarm Clear Message Format ... 9-103
- Report Performance Monitoring Message Format ... 9-105
- Cancel User Session Event Message Format ... 9-106
- Message Summary Table ... 9-106

The Wide Bank 28 DS3 automatically reports alarms and events to the network management system. The Wide Bank provides default values for the severities assigned to these alarms and events. However, you can change the notification code (ntfcncde) of many alarm and events in order to alter their severity or to prevent them from being automatically reported (see *SET-ATTR-<AIDType>* on page 9-75).

NOTE: Notification codes can only be changed through the TL1 interface.

Report Alarm Message Format

Syntax:

```
<cr><lf><lf>
^^^<tid>^<YY-MM-DD>^<HH:MM:SS><cr><lf>
<almcde>^<atag>^REPT^ALM^<modifier2><cr><lf>
^^^" <aid> : <ntfcncde> , <condtype> , <srveff> ,
    <ocrdat> , <ocrtm> , <locn> , <dirn> , :
    \" <description> \" <aiddet> , "
;

```

Example:

```
tid 2001-08-04 11:51:58\
* atag REPT ALM EQPT
  "DS1-07:MN,INT,NSA,11-14,01-01-40,, :
  \"Internal hardware fault or failure\" , "
;

```

Field	Description
^	Space character
cr	Carriage Return character
lf	Line Feed character
aid	Access ID used to identify trouble interface

TL1 Commands and Messages

TL1 Automatic Messages

Field	Description
aiddet	Supplementary Access ID information used to identify location of reported trouble: <ul style="list-style-type: none">• MASTER – master Controller• SLAVE – slave Controller
almcde	Alarm code identifies priority of action: *C – Critical alarm ** – Major alarm *^ – Minor alarm A^ – Automatic message If multiple alarms occur, the alarm code will be the highest severity.
atag	Automatic message tag. A sequential value is assigned to each message by the Wide Bank. Receiving a non-sequential value indicates that some messages have been lost.
conddescr	Condition Description provides a detailed description of the trouble.
condtype	Condition Type. See Table 2-1 <i>Alarm and Event Message Parameters</i> on page 9-107 for values and descriptions.
dirn	Direction of traffic: <ul style="list-style-type: none">• TRMT – transmit• RCV – receive• NA – not applicable
HH:MM:SS	Time (24 hour) in format Hours:Minutes:Seconds
locn	Location: <ul style="list-style-type: none">• NEND – near end• FEND – far end
modifier2	Identifies interface type: <ul style="list-style-type: none">• EQPT – equipment• ENV – environment• T1 – DS1• T3 – DS3• SECU – security
ntfncde	Notification Code: <ul style="list-style-type: none">• CR – Critical alarm• MJ – Major alarm• MN – Minor alarm• CL – condition cleared
ocrdat	Occurrence Date: MM-DD <ul style="list-style-type: none">• MM – month• DD – day
oortm	Occurrence Time: HH-MM-SS <ul style="list-style-type: none">• HH – hour• MM – minutes• SS – seconds

Field	Description
sid	Source ID
srveff	Service Effect code for REPT ALM messages: <ul style="list-style-type: none"> • SA – service affecting • NSA – not service affecting
YY-MM-DD	Date in format Year-Month-Day

Report Alarm Clear Message Format

For every automatic alarm report message generated, there is a corresponding message that is generated when the alarm clears. The TL1 alarm clear message is the same as the original alarm report message except for the alarm code and notification code fields.

Example: ALARM MESSAGE

```

tid 2001-08-04 11:51:58
*C atag REPT ALM EQPT
  "DS3-A:CR,LOS,SA,08-04,11-51-58,NEND,RCV:
  \"Loss of Signal\",ACTIVE"
;
    
```

When the above alarm is cleared, the following TL1 message is sent again with the alarm code changed from critical (*C) to alert (A) and the notification code changed from critical (CR) to cleared (CL).

Example: CLEAR MESSAGE

```

tid 2001-08-04 11:52:19
A atag REPT ALM EQPT
  "DS3-A:CL,LOS,SA,08-04,11-52-19,NEND,RCV:
  \"Loss of Signal\",ACTIVE"
;
    
```

Report Event Message Format

The event message syntax is almost identical to alarm messages except that an event condition effect code <condeff> replaces the alarm service effect code <serveff>.

Syntax:

```
<cr><lf><lf>
^^^<sid>^<YY-MM-DD>^<HH:MM:SS><cr><lf>
<almcde>^<atag>^REPT^EVT^<modifier2><cr><lf>
^^^"<aid>:<condtype>,<condeff>,<ocrdat>,<ocrtm>,<locn>,<dirn>,:
  \"<description>\"<aiddet>,\"<cr><lf>
;
```

Field	Description
condeff	Condition Effect code for REPT EVT messages: <ul style="list-style-type: none"> • CL – standing condition cleared • SC – standing condition raised • TC – Transient condition • Null value defaults to TC
other fields	Same as <i>Report Alarm Message Format on page 9-101</i> .

Example:

```
tid 2001-10-19 16:26:20
A atag REPT EVT T3
  "DS3-A:RAI,SC,10-19,16-26-19,NEND,RCV,,, :
  \"Remote Alarm Indication\"";
```

Report Performance Monitoring Message Format

Performance monitoring messages are generated according to the report schedule (see *SCHED-PMREPT-
<FacilityType>* on page 9-74). These reports provide performance statistics and can be allowed or inhibited (see *ALW-PMREPT-
<FacilityType>* on page 9-22 and *INH-PMREPT-
<FacilityType>* on page 9-38).

Syntax:

```
<cr><lf><lf>
^^^<sid>^<YY-MM-DD>^<HH:MM:SS><cr><lf>
A^^<atag>^REPT^PM^<FacilityType>
^^^" [<FacilityId>]:<montype>,<monval>,<vldty>],
    [<locn>], [<dirn>], [<tmper>], [<mondat>], [<montm>]"
;
```

Field	Description
FacilityType	T1, E1, T3
FacilityID	Facility ID depends on Facility Type: <ul style="list-style-type: none"> • For T1, values are DS1-1 to DS1-28 • For E1, values are E1-1 to E1-27 • For T3, values are DS3-A, DS3-B
atag	Automatic message tag. A sequential value is assigned to each message by the Wide Bank. Receiving a non-sequential value indicates that some messages have been lost.
dirn	Direction of traffic: <ul style="list-style-type: none"> • TRMT – transmit • RCV – receive
locn	Location: <ul style="list-style-type: none"> • NEND – near end • FEND – far end
mondat	Date during which the time period started
montm	Time during which the time period started
montype	Monitored parameter type
monval	Monitor Value
sid	Source Identifier
tmper	Time period that these statistics were gathered <ul style="list-style-type: none"> • 15-MIN – 15 minutes • 1-HR – 1 hour • 1-DAY – 1 day
vldty	Validity <ul style="list-style-type: none"> • COMPL – complete • PRTL – partial period

Example:

```
tid 2001-08-04 11:51:58
A atag REPT PM T1
  "DS1-01:UASL,20,COMPL,,,15-MIN,, "
  "DS1-01:SESL,50,COMPL,,,15-MIN,, "
  "DS1-01:LOSS,0,COMPL,,,15-MIN,, "
  "DS1-01:ESL,100,COMPL,,,15-MIN,, "
  "DS1-01:CSS,0,COMPL,,,15-MIN,, "
  "DS1-01:DGRML,0,COMPL,,,15-MIN,, "
  "DS1-01:PSD,0,COMPL,,,15-MIN,, "
  "DS1-01:PSL,900,COMPL,,,15-MIN,, "
  "DS1-01:CVL,0,COMPL,,,15-MIN,, "
;
```

Cancel User Session Event Message Format

If two or more users have active sessions and one user session times out because of user inactivity, the other users will receive a CANC message. In the following example, STEVE is the user that timed out:

Example:

```
tid 2001-08-04 04:40:32
A atag CANC
  STEVE
  /* Session Timeout: STEVE */
;
```

The session time-out period can be set by the administrator. The default is 31 minutes. See *SET-ATTR-SECUDFLT* on [page 9-77](#).

DS3 Far-End Alarms

Far-end alarms are events that occur at a remote location and are reported to the Wide Bank over the DS3 link. This feature and the associated commands require the DS3 to be set for C-bit framing.

Message Summary Table

Table 2-1 summarizes the alarm and event messages provided by the Wide Bank 28 DS3.

NOTE: Table 2-1 lists the *default* values for the Notification Code alarm severities. You can assign a different alarm severity to many of the Condition Types by using the TL1 command *SET-ATTR-<AIDType>* on [page 9-75](#). Alarm severities for the standby Controller can be set using the CLI command *ALARMS STANDBY* on [page 8-11](#).

Table 2-1 Alarm and Event Message Parameters

Access Identifier	Report Message Type	Interface Type	Default Notification Code	Service or Condition Effect Code	Condition Type	Condition Description
DS3-{A,B} <aiddet>= ACTIVE	REPT ALM	EQPT	CR	SA	CONTEQPT	Control Equipment Failure
			MN	SA	INT	Internal Hardware Fault or Failure
			MJ	NSA	IMPROPRMVL	Improper Removal
			MN	NSA	PROGFLT	Software Version Mismatch Between Controllers
			CR	SA	TRMT	Transmitter Failure
	REPT ALM	T3	CR	SA	LOS	Loss of Signal
			CR	SA	LOF	Loss of Frame
			CR	NSA	SYNCPRI	DS3 Loss of Designated Clock
DS3-{A,B} <aiddet>= STANDBY	REPT ALM	EQPT	MN	NSA	CONTEQPT	Control Equipment Failure
			MN	NSA	INT	Internal Hardware Fault or Failure
			MN	NSA	IMPROPRMVL	Improper Removal
			MN	NSA	TRMT	Transmitter Failure
	REPT ALM	T3	MN	SA	LOS	Loss of Signal
			MN	SA	LOF	Loss of Frame
			MN	NSA	SYNCPRI	DS3 Loss of Designated Clock

TL1 Commands and Messages

TL1 Automatic Messages

Table 2-1 Alarm and Event Message Parameters (Continued)

Access Identifier	Report Message Type	Interface Type	Default Notification Code	Service or Condition Effect Code	Condition Type	Condition Description
DS3-{A,B} FAR END (C-bit framing only)	REPT EVT	T3		SC	RAI	Far-end DS3 Equipment Failure (NSA)
						Far-end DS3 Equipment Failure (SA)
						Far-end DS3 Loss of Signal
						Far-end DS3 Out of Frame
						Far-end DS3 Receive AIS
						Far-end DS3 Receive IDLE
						Far-end DS1 Equipment Failure (NSA)
						Far-end DS1 Equipment Failure (SA)
						Far-end Multiple DS1 LOS
Far-end Single DS1 LOS						

Table 2-1 Alarm and Event Message Parameters (Continued)

Access Identifier	Report Message Type	Interface Type	Default Notification Code	Service or Condition Effect Code	Condition Type	Condition Description	
DS3-{A,B}	REPT ALM	T3	MJ	SA	BER-SF	Signal Fail	
			MN	NSA	BER-SD	Signal Degrade	
	REPT EVT	T3			WKSWPR	Working Unit Switched to Protect Unit	
					WKSWBK	Working Unit Switched Back to Working	
	REPT EVT	T3			SC	AISNAS	Alarm Indication Signal - North American Standard
					RAI	Remote Alarm Indication	
	REPT EVT	T3			TC	T-CVL	Threshold Violation - CV Line
						T-CVP-P	Threshold Violation - CV Path p-parity
						T-ESL	Threshold Violation - Errored seconds line
						T-ESP-P	Threshold Violation - Errored seconds path p-parity
						T-LOSS-L	Threshold Violation - Loss of signal seconds line
						T-SESL	Threshold Violation - Severely errored seconds line
						T-SESCP-P	Threshold Violation - Severely errored seconds path
	Not Reported					ACTLPBK	Loopback send code is Active
						PROTNA	Protection unit is not available
						LPBKEQPT	Equipment loopback
						LPBKLINE	Line loopback
						LPBKPAYLOAD	Payload loopback
						INHAUTORSTEQPT	Revertive Off
						INHAUTORSTSYNC	DS3 clockrevert Off
INHLPBK						Loopdetect Off	
INHSWPR						Facility protection not enabled	
INHSWWKG	Equipment protection not enabled						

Table 2-1 Alarm and Event Message Parameters (Continued)

Access Identifier	Report Message Type	Interface Type	Default Notification Code	Service or Condition Effect Code	Condition Type	Condition Description	
DS1-{01-28}	REPT ALM	EQPT	MN	NSA	INT	Internal Hardware Fault or Failure	
	REPT ALM	T1	MN	NSA	BER-SD	Signal Degrade	
			MJ	SA	BER-SF	Signal Fail	
			MJ	SA	FAILTOSW	Failed to Switch	
			MJ	SA	LOS	Loss of Signal	
	REPT EVT	T1			T-CVL	Threshold Violation - CV Line	
					T-ESL	Threshold Violation - Errored seconds line	
					WKSWPR	Working Unit Switched to Protect Unit	
					WKSWBK	Working Unit Switched Back to Working	
	Not Reported					ACTLPBK	Loopback send code is Active
						INHLPBK	Loopdetect Off
						INHSWPR	Facility protection not enabled
						INHSWWKG	Equipment protection not enabled
						LPBKEQPT	Equipment loopback
						LPBKLINE	Line loopback
						LPBKMETALLIC	Metallic loopback
	PROTNA	Protection unit is not available					
DS1-CARD-{1-7}	REPT ALM	EQPT	MJ	SA	FAILTOSW	Multiple MSO Card Removal	
			MJ	SA	IMPROPRMVL	Improper Removal	
DS1-CARD-SPARE	REPT ALM	EQPT	MN	NSA	IMPROPRMVL	Improper Removal	
DS1-CARD-MSO-{1-7}	REPT ALM	EQPT	MN	NSA	IMPROPRMVL	Improper Removal	
DS1-CARD-MSO-SPARE	REPT ALM	EQPT	MN	NSA	IMPROPRMVL	Improper Removal	

Table 2-1 Alarm and Event Message Parameters (Continued)

Access Identifier	Report Message Type	Interface Type	Default Notification Code	Service or Condition Effect Code	Condition Type	Condition Description	
E1-{01-27}	REPT ALM	EQPT	MN	NSA	INT	Internal Hardware Fault or Failure	
	REPT ALM	E1	MN	NSA	BER-SD	Signal Degrade	
			MJ	SA	BER-SF	Signal Fail	
			MJ	SA	FAILTOSW	Failed to Switch	
			MJ	SA	LOS	Loss of Signal	
	REPT EVT	E1				T-CVL	Threshold Violation - CV Line
						T-ESL	Threshold Violation - Errored seconds line
						WKSWPR	Working Unit Switched to Protect Unit
						WKSWBK	Working Unit Switched Back to Working
	Not Reported					ACTLPBK	Loopback send code is Active
						INHLPBK	Loopdetect Off
						INHSWPR	Facility protection not enabled
						INHSWWKG	Equipment protection not enabled
						LPBKEQPT	Equipment loopback
						LPBKLINE	Line loopback
						LPBKMETALLIC	Metallic loopback
PROTNA	Protection unit is not available						
E1-CARD-{1-7}	REPT ALM	EQPT	MJ	SA	FAILTOSW	Multiple MSO Card Removal	
			MJ	SA	IMPROPRMVL	Improper Removal	
E1-CARD-SPARE	REPT ALM	EQPT	MN	NSA	IMPROPRMVL	Improper Removal	
E1-CARD-MSO-{1-7}	REPT ALM	EQPT	MN	NSA	IMPROPRMVL	Improper Removal	
E1-CARD-MSO-SPARE	REPT ALM	EQPT	MN	NSA	IMPROPRMVL	Improper Removal	

TL1 Commands and Messages

TL1 Automatic Messages

Table 2-1 Alarm and Event Message Parameters (Continued)

Access Identifier	Report Message Type	Interface Type	Default Notification Code	Service or Condition Effect Code	Condition Type	Condition Description
EXT48V- <i>{A,B}</i>	REPT ALM	ENV	MN		PWR-48	Power -48V Fail or Low
FAN- <i>{A,B}</i>	REPT ALM	ENV	MJ		CLFAN	Cooling Fan Fail
FAN-A&FAN-B	REPT ALM	ENV	MJ		CLFAN	Fan Faceplate Not Present
POWER-5V- <i>{A,B}</i>	REPT ALM	EQPT	MN	NSA	PWR	Power +5V Fail
SECURITY	REPT ALM	SECU	MJ	NSA	LOGBUFR90-SECULOG	TL1 Security Log 90% Full
			MJ	NSA	LOGBUFROVFL-SECULOG	TL1 Security Log Full
TEMP- <i>{A,B}</i>	REPT ALM	ENV	MN		HITEMP	High Temp
Unit Identifier <uid>		SECU	MN	NSA	INTRUSION	

CHAPTER 10

Maintenance

In this Chapter

- Card Maintenance ... 10-2
- Card Locations ... 10-2
- Removing and Installing Faceplates ... 10-3
- Replacing Low-Speed Cards ... 10-5
- Replacing DS3 Controller Cards ... 10-10
- Turning Off Unused or Unterminated Low-Speed Channels ... 10-11

Card Maintenance

The Wide Bank is equipped with one or two Controller cards for processing and high-speed connections. For Low-Speed (LS) connections the Wide Bank can have from one to seven active low-speed cards and one spare low-speed card. These cards contain all the Wide Bank circuits, and can be removed and replaced with power on (hot-swapped).



WARNING! SEE PROPER ELECTROSTATIC DISCHARGE (ESD) PROCEDURES WHEN REMOVING AND HANDLING THE LOW-SPEED AND CONTROLLER CARDS. WE RECOMMEND THAT YOU WEAR A RESISTANCE-STYLE WRIST STRAP TO GROUND YOURSELF THROUGH THE EQUIPMENT CHASSIS. SEE *STATIC-SENSITIVE EQUIPMENT HANDLING PROCEDURES* ON [page 5-3](#) FOR INSTRUCTIONS ON HOW TO USE A WRIST STRAP.

Card Locations

The following figure shows card slot and circuit locations. The Controller cards occupy the two wide slots at the top left of the chassis. Any low-speed card slot, including the spare slot, can contain either a standard LS card or an MSO card. The figure below shows both low-speed card types for purposes of identification but it is recommended that all cards be the same type.




Figure 10-1 Card Locations (front view)

Removing and Installing Faceplates

DANGER! FIRE HAZARD. STANDARD UL 1950 REQUIRES THAT ALL ACCESS COVERS BE REPLACED TO PREVENT FIRES FROM SPREADING TO NEARBY EQUIPMENT.

Wide Banks come either with a standard (no-fan) faceplate or with the fan faceplate option (FFO). The faceplate must be removed and re-installed when replacing a circuit card. If a fan fails on a fan faceplate, the entire fan faceplate must be replaced because individual fans are not replaceable.

Standard Faceplates

1. Remove the faceplate with a Phillips-head screw driver. Loosen the two captive screws on each end of the faceplate that secure the faceplate to the Wide Bank chassis.
2. When installing the faceplate, do not overtighten the captive screws. Carrier Access recommends a maximum torque of 8 to 10 inch-pounds.

Fan Faceplates

CAUTION! IN HIGH-DENSITY RACKS WITH THE POWER TURNED ON, A FAN FACEPLATE MUST BE RE-INSTALLED WITHIN 5 MINUTES TO PREVENT THE WIDE BANK FROM OVERHEATING AND INTERRUPTING SERVICE.

NOTE: Fan faceplates can only be installed on FFO-capable Controller cards equipped with fan power connectors.

Fan faceplates have two fans that provide extra cooling for high-density installations. Power for the fans is derived from connections between the faceplate and the two Controller cards. These connections also include a tachometer lead that allows the fans to be monitored and tested. Therefore, proper alignment of the power connectors is essential when installing a fan faceplate.




Figure 10-2 Fan Faceplate Installation

Maintenance

Removing and Installing Faceplates

1. Remove the fan faceplate with a Phillips-head screw driver. Loosen the two captive screws on each end of the faceplate that secure the faceplate to the Wide Bank chassis. A little force may be required to disconnect the two fan power connectors.
2. When installing the fan faceplate, use care to ensure correct alignment of the two power connectors before tightening the fastening screws at each end of the faceplate. Do not overtighten the captive screws. Carrier Access recommends a maximum torque of 8 to 10 inch-pounds.

NOTE: When a fan faceplate is installed with the Wide Bank power turned on, there is a 30-second delay before the fans are turned on.

Replacing Low-Speed Cards



WARNING! SEE PROPER ELECTROSTATIC DISCHARGE (ESD) PROCEDURES WHEN REMOVING AND HANDLING THE LOW-SPEED AND CONTROLLER CARDS. WE RECOMMEND THAT YOU WEAR A RESISTANCE-STYLE WRIST STRAP TO GROUND YOURSELF THROUGH THE EQUIPMENT CHASSIS. SEE *STATIC-SENSITIVE EQUIPMENT HANDLING PROCEDURES ON page 5-3* FOR INSTRUCTIONS ON HOW TO USE A WRIST STRAP.

Low-speed cards come in two styles: the standard card and the Maintenance Service Option (MSO) card. The procedures for swapping these cards are different, as described below. The Maintenance Service Option includes not only a different style of card but also a specific minimum level of firmware (1.47 or higher).

Maintenance Practices for Low-Speed Cards

There are two maintenance practices that you should follow when replacing low-speed cards to minimize the effects on traffic. One practice is used for standard low-speed cards and the other is used for MSO low-speed cards.

Standard Low-Speed Card Maintenance Practice

1. Plan to replace a failed low-speed card during a low-traffic period or when the circuits on the card will not be carrying traffic. Removing a low-speed card disrupts service on all four circuits on the card because there are no relays to maintain service through the spare card. So, replacing cards during off-peak traffic times will minimize service disruptions.
2. Replace a failed low-speed card at the first opportunity. This will reduce the risk that other failed circuits will be dropped because there are no spare circuits available.
3. Do not remove more than one low-speed card at the same time. Each card that is removed will disrupt traffic on four circuits.

MSO Low-Speed Maintenance Practice

1. Replace a failed low-speed MSO Electronics card at the first opportunity. This will reduce the risk that other failed circuits will be dropped because there are no spare circuits available.
2. Do not remove or replace more than one MSO Electronics card at a time. If one low-speed card is removed, all four circuits on that card will move to the spare card. But when a second low-speed card is removed, the resulting resource conflict will cause all circuits on all removed cards to be dropped.

Replacing a Standard Low-Speed Card

CAUTION! STANDARD LOW-SPEED CARDS CAN BE REMOVED AND REPLACED WITH POWER ON. HOWEVER, THE FOUR CIRCUITS ON THE CARD BEING SWAPPED WILL BE DROPPED UNTIL A CARD IS INSERTED INTO THE SLOT.



1. Use a Phillips head screwdriver to loosen the two fastening screws on the front faceplate of the Wide Bank and remove the faceplate. See Figure 10-3.
2. Locate the low-speed card you want to remove. See Figure 10-1 for low-speed card and circuit locations.
3. Pull the card ejector latch to release the card from its internal connector.
4. Carefully slide the card out of the Wide Bank.
5. Ensure that the replacement card is positioned correctly in the guide rails, then carefully slide the card into the slot.
6. Press the card ejector latch in toward the card until the connector on the card mates with the matching connector on the backplane.

NOTE: When replacing a fan faceplate, ensure that the fan power connectors are aligned and seated on the Controller board power connectors.

7. Replace the faceplate and tighten the fastening screws. Do not overtighten. Carrier Access recommends a maximum torque of 8 to 10 inch-pounds.




Figure 10-3 Replacing a Standard Low-Speed Card

Replacing an MSO Low-Speed Card



The Maintenance Service Option allows hot-swapping a low-speed card without dropping the circuits carried by that card. This is accomplished by removing only the electronics section of the two-section MSO card, leaving the relay section of the MSO card fully seated and latched in the card slot, as shown in Figure 10-4. Removing the relay section of the MSO card will drop the circuits carried by the card, just like removing a standard low-speed card.




Figure 10-4 MSO Electronics and MSO Relay Sections

The MSO card has two card ejector latch levers, a white one (the upper one) and a red one (the lower one). See Figure 10-6 and Figure 10-5 on the following pages. The white ejector latches the electronics section of the card to the relay section. The red ejector latch holds both the relay section and the electronics section of the card in the slot position.

CAUTION! WHEN HOT-SWAPPING AN MSO CARD, ALWAYS PULL THE WHITE EJECTOR LATCH LEVER TO EJECT THE MSO ELECTRONICS SECTION. DO NOT PULL THE RED EJECTOR LATCH LEVER BECAUSE IT WILL EJECT THE MSO RELAY SECTION AND INTERRUPT SERVICE ON ALL CIRCUITS OF THE CARD.

WARNING! NEVER INSERT THE RELAY SECTION OF AN MSO CARD INTO A WIDE BANK UNLESS THE ELECTRONICS SECTION OF THE CARD IS CORRECTLY LATCHED TO IT. FAILURE TO DO SO MAY DAMAGE THE RELAY SECTION.




Figure 10-5 Removing an MSO Electronics Section

Removing the Electronics Section of an MSO Card

1. Use a Phillips head screwdriver to loosen the two fastening screws on the faceplate of the Wide Bank and remove the plate. See Figure 10-5.
2. Locate the low-speed card you want to remove. See Figure 10-1 for low-speed card and circuit locations.
3. Pull out the white card ejector latch to release the electronics section of the MSO card from the relay section. Do not disturb the red ejector latch. See Figure 10-6 and Figure 10-5 for the location of the white latch (upper latch) of each MSO Quad card.
4. Slide the electronics section of the card out of the Wide Bank.

Inserting the Electronics Section of an MSO Card

1. Ensure that the replacement section is positioned correctly in the guide rails, and the white ejector latch lever is positioned to engage the roll pin on the relay section. Then carefully slide the section into the slot.
2. Press the white ejector latch inward until the connector on the electronics section mates with a matching connector on the relay section.

NOTE: If the faceplate is a fan faceplate, in the following step ensure that the fan power connectors are aligned and seated on the Controller board power connectors.

3. Replace the faceplate and tighten the fastening screws. Do not overtighten. Carrier Access recommends a maximum torque of 8 to 10 inch-pounds.




Figure 10-6 Inserting an MSO Electronic Card

Replacing DS3 Controller Cards



WARNING! THE WIDE BANK CONTAINS CIRCUIT CARDS AND COMPONENTS THAT ARE SUBJECT TO DAMAGE BY ELECTROSTATIC DISCHARGE (ESD). ALWAYS FOLLOW THE **STATIC-SENSITIVE EQUIPMENT HANDLING PROCEDURES** ON [page 5-3](#) WHEN OPENING EQUIPMENT COVERS AND HANDLING PLUG-IN CARDS.

There can be one DS3 Controller Cards installed in the Wide Bank, or there can be two. When two DS3 cards are installed, one of them can be hot-swapped without losing the DS3 connection if both power connectors A and B are supplied with -48 VDC. When only one DS3 card is installed, or when only one power connector is supplied with -48 VDC, hot-swapping will interrupt service on the DS3 interface. With two Controller cards, and both power connectors supplied with -48 VDC, use the *switch* command to switch control away from the card to be replaced (if it has not already switched). If possible, always replace the standby Controller.

NOTE: If a fan faceplate is installed, the replacement Controller card must be a version that supports the fan faceplate option. FFO-capable Controller cards have a fan power connector.




Figure 10-7 Replacing a DS3 Controller Card

1. Use a Phillips head screwdriver to loosen the two fastening screws on the faceplate of the Wide Bank and remove the faceplate. See Figure 10-7.

2. Remove the Controller card (A or B) by lifting the card ejector latches and sliding the card out of the chassis housing.
3. Ensure that the replacement card is positioned correctly in the guide rails, then carefully slide the card into the slot.
4. Press the card ejector latches in toward the card until the connector on the card mates with a matching connector on the backplane.

NOTE: If the faceplate is a fan faceplate, in the following step ensure that the fan power connectors are aligned and seated on the Controller board power connectors.

5. Replace the faceplate and tighten the two fastening screws. Do not overtighten. Carrier Access recommends a maximum torque of 8 to 10 inch-pounds.

Turning Off Unused or Unterminated Low-Speed Channels

For continued FCC Part 15A and NEBS compliance, unused and unterminated low-speed channels must be turned off by issuing the CLI *ds1* or *ls* command:

```
(A:Working) > ds1 [n|range|all] disable
```

or

```
(A:Working) > ls [n|range|all] disable
```

NOTE: For details on *ds1* and *ls* commands, see *CLI Commands and Messages on page 8-1*.

Maintenance

Turning Off Unused or Unterminated Low-Speed Channels

CHAPTER 11

SNMP

In this Chapter

- Configuration for SNMP ... 11-2
- Validate Link ... 11-4
- Carrier Access DS3 Multiplexer Enterprise MIBs ... 11-5
- SNMP Traps Supported by Wide Bank 28 DS3 ... 11-6

Configuration for SNMP

Several basic settings are required before you can use the SNMP facilities provided by the Wide Bank 28 DS3. Basic settings must be initially configured through the Command Line Interface (CLI). These settings are the Wide Bank IP address, Subnet mask, Default gateway, NMS IP Address, system name, location, and contact. The default get, set, and trap community strings are “public” and can be changed by the SNMP manager after completing the basic configuration.

The Wide Bank 28 DS3 contains an SNMP MIB agent that supports RFC 1213 (general), RFC 1406 (DS1 and E1), and RFC 1407 (DS3).

The Wide Bank also contains Enterprise MIBs that enhances the SNMP operation of the Wide Bank (see *Carrier Access DS3 Multiplexer Enterprise MIBs on page 11-5*).

In a point-to-point application with another Wide Bank 28 DS3 running in C-bit framing mode, the DS3 terminal-to-terminal data link can be used to remotely manage the far-end terminal. See *Configuring IP and PPP Addresses on page 6-15* for information on how to use PPP over the DS3 data link to establish an SNMP session with a remote Wide Bank 28 DS3.

Basic Configuration Parameters

Wide Bank IP Address

The Internet address identifies the Wide Bank on a TCP/IP based network. This field is required. Each Wide Bank on the network must have a unique IP address.

Subnet Mask

Networks that require further partitioning use subnet masks to perform subnet routing. These values indicate which part of your IP address is a network address and which part is a node address.

Default Gateway

This is the IP address of a default gateway on your logical network. A TCP/IP gateway (router) allows you to communicate outside your local network (subnet) by forwarding information to another network. The gateway must be on your logical network, and the network portion of the address should be the same as the network portion of your IP address.

Network Management Station (NMS) IP Address

This is the address of the Network Management Station (NMS) that is used to manage the SNMP sessions. This address is required by Wide Bank for reporting of trap events. There can be as many as 3 NMS addresses configured.

System Name

The system Name is a string of up to 255 characters that is the assigned administrative name for this managed node.

Location

This is a string of up to 255 characters that describes the physical location of this node.

Contact

This is a string of up to 255 characters that identifies the contact person for this managed node, together with information on how to contact this person.

Basic Configuration from the CLI

1. Configure the Wide Bank network IP interface values. For example:

```
(A:Active)> ip address 192.168.20.10
(A:Active)> ip mask 255.255.255.0
(A:Active)> ip gateway 192.168.20.1
```

2. Configure the IP Addresses of up to three NMS systems that the Wide Bank will report traps to. For example:

```
(A:Active)> ip nms1 192.168.20.3
(A:Active)> ip nms2 192.168.20.4
(A:Active)> ip nms3 192.168.20.5
```

3. Configure SNMP system group information contained in RFC-1213. Enter values for the name, location, and contact. For example:

```
(A:Active)> SNMP name "Wide Bank 28 DS3"
(A:Active)> SNMP location "Acme Corp: telephone closet"
(A:Active)> SNMP contact "John Doe, Acme Corp (303)555-5678"
```

Validate Link

Before proceeding with an SNMP management session, use the following steps to validate the Ethernet connection through your Local Area Network (LAN) to the Wide Bank.




Figure 11-1 SNMP Link

1. Verify that the IP cable is connected to the LAN.
2. From your computer or Network Management Station (NMS), send a Ping request toward the Wide Bank. For example:

```
ping 192.168.20.10
```

```
Pinging 192.168.20.10 with 32 bytes of data:  
Reply from 192.168.20.10: bytes=32 time<10ms TTL=128
```

3. Verify that the Wide Bank replies to the Ping request, as in the example above.
4. Now validate that your management station can be seen by the Wide Bank. Use the Wide Bank CLI *ping* command to send a Ping request toward the NMS. For example:

```
(A:Active)> ping 192.168.20.30
```

```
Pinging 192.168.20.30 with 32 bytes of data:  
Reply from 192.168.20.30: bytes=32 time<10ms TTL=128
```

Carrier Access DS3 Multiplexer Enterprise MIBs

The Carrier Access DS3 Multiplexer Enterprise MIB supports:

- DS3 Controller card status
- DS3 identification settings
- DS3 clock settings
- DS3 far-end status
- DS1/E1 low-speed card status
- DS1/E1 low-speed spare card allocation
- DS3 Controller status change traps
- DS1/E1 low-speed card status change traps
- External power low or missing trap
- Failed login attempt trap

NOTE: The Wide Bank 28 DS3 documentation CD-ROM includes the Carrier Access Corporation Multiplexer Enterprise MIB definition file (DS3AM.MIB) in ASN.1 Standard syntax for use by network management software.

SNMP Traps Supported by Wide Bank 28 DS3

- Interface Index (ifIndex) Numbers ... 11-6
- Standard Traps ... 11-6
- Enterprise Traps ... 11-8

Interface Index (ifIndex) Numbers

SNMP trap reports use the following index numbers to identify the interfaces in the Wide Bank.

Table 11-1 ifIndex Values for Interfaces

ifIndex	Interface
1	DS3 Controller "A"
2	DS3 Controller "B"
3-30	Low-Speed DS1/E1 1-28
31	Ethernet port
32	PPP link

NOTE: The linkup and linkdown traps are reported for each interface separately. The report shows the ifIndex number and interface for each trap, as in "#1 - DS3 CONTROLLER A, #2 DS3 CONTROLLER B, #3 DS1 1, #4 DS1 2" and so on.

Standard Traps

Authentication Failure Trap

An *authenticationFailure* trap indicates that the sending protocol entity is the addressee of a protocol message that is not properly authenticated. While implementations of the SNMP must be capable of generating this trap, they must also be capable of suppressing the emission of such traps via an implementation-specific mechanism.

Events that cause an authenticationFailure Trap:

- Change node object definition that is not supported by SNMP.

For example, at the SNMP Manager Edit object's community parameters for "get" function from "public" to "private" (if WB is set to getcomm = "public"). This will generate an authenticationFailure trap message.

Warm Start Trap

A *warmStartTrap* indicates that the sending protocol entity is re-initializing itself in a way that neither the agent configuration nor the protocol entity implementation is altered.

Events that cause a warmStartTrap:

- Turning the power off, then on again (cycle power). Also called cold start.
- Removing, then replacing all Controllers.

Link Down Trap

A *linkDownTrap* indicates that the sending protocol entity recognizes a failure in one of the communication links represented in the agent's configuration.

The Trap-PDU of type linkDownTrap contains as the first element of its variable-bindings, the name and value of the ifIndex instance for the affected interface.

Events that cause a linkDownTrap:

- Removing a DS3 link
- Removing a low-speed link
- Removing a DS3 Controller
- Removing a low-speed card
- Removing and replacing all Controllers will also trigger linkDown and linkUp traps from DS3 and all low-speed circuits

Link Up Trap

A *linkUpTrap* indicates that the sending protocol entity recognizes that one of the communication links represented in the agent's configuration has come up.

The Trap-PDU of type linkUpTrap contains as the first element of its variable-bindings, the name and value of the ifIndex instance for the affected interface.

Events that cause a linkUpTrap:

- Removing, then replacing a DS3 link
- Removing, then replacing a low-speed link
- Removing, then replacing a DS3 Controller
- Removing, then replacing a low-speed card
- Removing and replacing all Controllers will also trigger linkDown and linkUp traps from DS3 and all low-speed circuits

Enterprise Traps

DS3 Controller State Trap

The *ds3ControllerStateTrap* is an enterprise-specific trap that indicates a change in the DS3 Controller's alarm state.

The Trap-PDU contains two variable bindings: *ds3amControllerStatus*, *ds3ControllerIndex*. The first variable indicates the value of the Controller Status leaf for the affected Controller. The second variable indicates the primary or secondary DS3 Controller.

DS1 Card State Trap

A *ds1CardStateTrap* indicates a change in the DS1/E1 card's alarm state.

The Trap-PDU contains two variable bindings: *ds3amDS1CardStatus*, *ds3amDS1CardIndex*. The first variable indicates the value of the DS1/E1 Card Status leaf for the affected DS1/E1 Card. The second variable indicates the DS1/E1 card number.

Failed CLI Login Trap

The *cliLoginFailureTrap* is an enterprise-specific trap that is issued when there are three consecutive unsuccessful attempts to login to the CLI.

There are no variables bound to this trap, so the only information provided by the trap is the IP of the Wide Bank that experienced the login failures and the time the last failure occurred.

Power Status Trap

The *ext48VPowerStatusTrap* is an enterprise-specific trap that is issued whenever an "external 48V power source low or missing" event occurs or is cleared.

The Trap-PDU contains two variable bindings: *ds3amEnvExternalPowerStatus*, *ds3amEnvPowerSupplyIndex*. The first variable indicates either normal(1) or lowOrMissing(2). When the low or missing event occurs, the trap is sent and the value bound to the trap is lowOrMissing. When the event is cleared, the value bound to the trap is normal. The second variable indicates the power supply number.

DS1 Protect Switch Trap

The *ds1ProtectSwitchTrap* is an enterprise-specific trap that indicates when a DS1/E1 facility is switched to the spare card. This trap is sent with the DS1/E1 line index number bound to it.

DS1 Move Home Trap

The *ds1MoveHomeTrap* is an enterprise-specific trap that indicates when a DS1/E1 facility is switched to its home card from the spare card. This trap is sent with the DS1/E1 line index number bound to it.

DS1 Internal Hardware Failure Trap

The *ds1InternalHdwFailureSpareClearTrap* is an enterprise-specific trap that indicates when a DS1/E1 facility experiences an internal hardware failure. This trap is sent with the DS1/E1 line index number bound to it.

DS1 Internal Hardware Failure Clear Trap

The *ds1InternalHdwFailureClearTrap* is an enterprise-specific trap that indicates when a DS1/E1 facility experienced a hardware failure and is now clearing. This trap is sent with the DS1/E1 line index number bound to it.

DS1 Internal Hardware Failure Spare Trap

The *ds1InternalHdwFailureSpareTrap* is an enterprise-specific trap that indicates when a DS1/E1 spare facility experiences an internal hardware failure. This trap is sent with the DS1/E1 line index number bound to it.

DS1 Internal Hardware Failure Spare Clear Trap

The *ds1InternalHdwFailureSpareClearTrap* is an enterprise-specific trap that indicates when a DS1/E1 spare facility experienced a hardware failure and is now clearing. This trap is sent with the DS1/E1 line index number bound to it.

SNMP

SNMP Traps Supported by Wide Bank 28 DS3

CHAPTER 12

Alarm Reporting

In this Chapter

- Overview ... 12-2
- Critical, Major and Minor Alarms ... 12-2
- LEDs That Report Alarms ... 12-3
- DS3 Far-End Alarms and Control (FEAC) ... 12-4
- TL1 Automatic Messages ... 12-4

Overview

The Wide Bank reports alarms in several ways. First, there are LEDs that indicate that alarm events have occurred. Second, the alarm events that occur are entered into an event log. Third, certain SNMP traps are generated when alarms occur. Finally, the Wide Bank reports alarms via the Transaction Language One (TL1) messaging system, in compliance with:

- Telcordia GR-474, Network Maintenance: Alarm and Control for Network Elements
- Telcordia GR-820, Generic Digital Transmission Surveillance

The Wide Bank alarms are categorized as either Critical, Major, or Minor. Critical alarms are those that will adversely affect traffic at the DS3 level. Major alarms are those that adversely affect traffic at the low-speed (DS1 or E1) level. Minor alarms do not affect traffic but do affect standby circuits.

Critical, Major and Minor Alarms

NOTE: The following information and charts are based on the *default* values assigned to the alarm severities. Many of the alarm conditions can be assigned a different alarm severity by using the TL1 command *SET-ATTR-<AIDType>* on [page 9-75](#).


The chart on the following page shows the alarm conditions that generate critical and major/minor alarms.

- **Critical Alarms.** Critical alarm events cause the Critical Alarm LED to light red, the critical alarm relay contacts to activate, and the appropriate log entries to be recorded.
- **Major and Minor Alarms.** Major/ minor alarm events cause the Major/Minor Alarm LED to light red (major) or yellow (minor), the major/minor alarm relay contacts to activate, and appropriate log entries to be recorded.
- **Alarm Cleared.** When the alarm condition no longer exists, the LED and the relay contacts will deactivate.
- **Alarm Cutoff (ACO).** You can override the alarm condition, turn off the LED, and deactivate the relay contacts by pressing the ACO switch on the front control panel, or by issuing the *aco* command from the Command Line Interface. ACO is a momentary action, and does not affect subsequent alarm reporting.

LEDs That Report Alarms

The information in Table 12-1 assumes that your Wide Bank 28 DS3 is fully redundant and is using the default alarm severities for Critical, Major, and Minor alarms. Some physical configurations other than fully redundant affect the way some alarms are reported.

Table 12-1 LED Alarm Summary



DS3 Far-End Alarms and Control (FEAC)

Far-end alarms are events that occur at a remote location and are reported to the Wide Bank 28 DS3 over the DS3 link. This feature and the associated commands require the DS3 to be set for C-bit framing.

Far-End Alarm Transmission

When there is a far-end alarm condition, code words are transmitted continuously for the duration of the alarm, or for a minimum of 10 code words, whichever is longer. Only the highest priority alarm is transmitted. If a high priority alarm occurs while a low priority alarm is active, only the higher priority alarm will be sent. When no alarm is being transmitted, the far-end alarm signal contains all ones. Absence of a far-end alarm signal implies no far-end alarm exists.

Far-End Alarm Reporting

The 11 far-end alarms are treated as MINOR alarms but are reported as events in TL1 (see *Alarm and Event Message Parameters* on [page 9-107](#)). Thus, when an alarm occurs the non-critical alarm LED goes to YELLOW, the non-critical alarm contact is activated, an automatic TL1 message is generated, and the alarm is entered in the Event Log. The current far-end alarm will also be displayed by the *alarms* and *status ds3far* commands for DS3 far-end alarms.

TL1 Alarm Reporting

Transaction Language One (TL1) automatic outbound alarm messaging is a standards-based ASCII management language defined for TL1-based operations and support systems such as the Telcordia NMA™ network monitoring and fault management system. With this feature, the Wide Bank will integrate into TL1 alarm-managed networks to provide notification of network and equipment conditions. See *TL1 Automatic Messages* on [page 9-101](#).

TL1 Automatic Messages

TL1 automatic messages are used to automatically report alarms and other events detected by the Wide Bank 28 DS3. The Wide Bank supports the reporting of alarmed and non-alarmed events using the message formats defined by Telcordia GR-833-CORE, 1996. OSS's such as Telcordia's NMA system are able to use these messages to provide trouble reports to the network operations center. For a detailed description of the Wide Bank messages, see *TL1 Automatic Messages* on [page 9-101](#).

You can establish a TL1 session through a TCP connection through TCP port, the Asynchronous RS-232 TL1 port, or a terminal-to-terminal session when running in C-bit framing mode. See *Connecting and Configuring for TL1* on [page 9-9](#).

APPENDIX **A**

Connector Pinouts

In this Appendix

- DC Power Connectors ... [A-2](#)
- Alarm Contacts ... [A-3](#)
- Low-Speed DS1/E1 (DSX-1) Connector Pinouts ... [A-4](#)
- CLI RS-232 Management Port Pinout ... [A-7](#)
- TL1 RS-232 Management Port Pinout ... [A-8](#)
- Ethernet RJ-45 (10Base-T) Pinout ... [A-9](#)

DC Power Connectors

The A and B power connectors are identical, and both must be supplied with -48 VDC if the Wide Bank is operating as a redundant system.




Figure A-1 Power Connector Pinout

Table A-1 Power Connector Pinout

Pin Position	Signal
Top (C1)	Telco or safety ground
Middle (C2)	DC return, to power supply + terminal
Bottom (C3)	Power Converter/Battery Charger, or other -42 to -58 VDC power source

Alarm Contacts

Alarm Contacts on 4-Position Wiring Block Connector. Contacts are programmable as normally open or normally closed. See *ALARMOUT* on page 8-13.




Figure A-2 Alarm Contacts Pinout

Low-Speed DS1/E1 (DSX-1) Connector Pinouts




Figure A-3 Low-Speed Connector Pinouts

Low-Speed Connector Pinout Chart

Table A-2 shows wiring details for the DSX-1 low-speed cables for the LOW SPEED IN and LOW SPEED OUT connectors. The low-speed transmit and receive cables for DS1/E1 circuits are physically identical and the signal assignments are as shown. For flying lead connections, the following points apply:

- The wires are packaged within the cable in three groups:
 - Group 1 – twelve pairs, connecting low-speed circuits 1 through 12
 - Group 2 – thirteen pairs, connecting low-speed circuits 13 through 25
 - Group 3 – seven pairs, connecting low-speed circuits 26 through 28
- Four of the wire pairs in group 3 repeat the same colors as the first seven pairs in group 1.
- The wire pairs in group 3 repeat the same colors as the first seven pairs in group 1.

Table A-2 DSX-1 Connector Pinouts and Circuits

DS1/E1 Circuit	LOW SPEED IN Pins		LOW SPEED OUT Pins		DS1/E1 Card	Wire Group
	Rx Tip	Rx Ring	Tx Tip	Tx Ring		
1	33 white/blue	1 blue/white	33 white/blue	1 blue/white	1	1
2	34 white/orange	2 orange/white	34 white/orange	2 orange/white		
3	35 white/green	3 green/white	35 white/green	3 green/white		
4	36 white/brown	4 brown/white	36 white/brown	4 brown/white		
5	37 white/slate	5 slate/white	37 white/slate	5 slate/white	2	
6	38 red/blue	6 blue/red	38 red/blue	6 blue/red		
7	39 red/orange	7 orange/red	39 red/orange	7 orange/red		
8	40 red/green	8 green/red	40 red/green	8 green/red		
9	41 red/brown	9 brown/red	41 red/brown	9 brown/red	3	
10	42 red/slate	10 slate/red	42 red/slate	10 slate/red		
11	43 black/blue	11 blue/black	43 black/blue	11 blue/black		
12	44 black/orange	12 orange/black	44 black/orange	12 orange/black		

Connector Pinouts


Low-Speed DS1/E1 (DSX-1) Connector Pinouts

Table A-2 DSX-1 Connector Pinouts and Circuits (Continued)

DS1/E1 Circuit	LOW SPEED IN Pins		LOW SPEED OUT Pins		DS1/E1 Card	Wire Group	
	Rx Tip	Rx Ring	Tx Tip	Tx Ring			
13	45 black/green	13 green/black	45 black/green	13 green/black	4	2	
14	46 black/brown	14 brown/black	46 black/brown	14 brown/black			
15	47 black/slate	15 slate/black	47 black/slate	15 slate/black			
16	48 yellow/blue	16 blue/yellow	48 yellow/blue	16 blue/yellow			
17	49 yellow/orange	17 orange/yellow	49 yellow/orange	17 orange/yellow	5		
18	50 yellow/green	18 green/yellow	50 yellow/green	18 green/yellow			
19	51 yellow/brown	19 brown/yellow	51 yellow/brown	19 brown/yellow			
20	52 yellow/slate	20 slate/yellow	52 yellow/slate	20 slate/yellow			
21	53 violet/blue	21 blue/violet	53 violet/blue	21 blue/violet	6		
22	54 violet/orange	22 orange/violet	54 violet/orange	22 orange/violet			
23	55 violet/green	23 green/violet	55 violet/green	23 green/violet			
24	56 violet/brown	24 brown/violet	56 violet/brown	24 brown/violet			
25	57 violet/slate	25 slate/violet	57 violet/slate	25 slate/violet	7		3
26	58 white/blue	26 blue/white	58 white/blue	26 blue/white			
27	59 white/orange	27 orange/white	59 white/orange	27 orange/white			
28	60 white/green	28 green/white	60 white/green	28 green/white			
Not used	white/brown	brown/white	white/brown	brown/white	Not used		
Not used	white/slate	slate/white	white/slate	slate/white	Not used		
Not used	red/blue	blue/red	red/blue	blue/red	Not used		
Not used	red/orange	orange/red	red/orange	orange/red	Not used		


CLI RS-232 Management Port Pinout

Male DB9 Connector



Female DB9 Connector


This connector is the one on the Wide Bank.



Pin	Signal	Name
1	CD	(not used)
2	RD	Receive Data
3	TD	Transmit Data
4	DTR	(not used)
5	GND	Ground
6	DSR	(not used)
7	RTS	Request To Send
8	CTS	(not used)
9	RI	(not used)


TL1 RS-232 Management Port Pinout

Male DB25 Connector



Female DB25 Connector


This connector is the one on the Wide Bank.



Pin	Signal	Name
1		(not used)
2	TD	Transmitted Data
3	RD	Receive Data
4	RTS	Request To Send
5	CTS	Clear To Send
6		(not used)
7	GND	Signal Ground
8	DCD or CD	Data Carrier Detect
9-14		(not used)
15	TC	Transmit Clock
16		(not used)
17	RC	Receive Clock
18-19		(not used)
20	DTR	Data Transmit Ready
21-23		(not used)
24	xTC	(external) Transmit Clock
25		(not used)

Ethernet RJ-45 (10Base-T) Pinout

RJ-45 Connector



Pin	Signal	Color
1	TX+	White w/Orange
2	TX-	Orange
3	RX+	White w/Green
4		Blue
5		White w/Blue
6	RX-	Green
7		White w/Brown
8		Brown

Connector Pinouts

Ethernet RJ-45 (10Base-T) Pinout

GLOSSARY

Abbreviations/Acronyms

ADM	Add/Drop Multiplexer
AIS	Alarm Indication Signal
AMI	Alternate Mark Inversion
APS	Automatic Protection Switching
ARP	Address Resolution Protocol
ATM	Asynchronous Transfer Mode
B3ZS	Bipolar with 3-Zero Substitution
B8ZS	Bipolar with 8-Zero Substitution
bit	Binary digit; a pulse of data
bps	Bits Per Second
BER	Bit Error Rate
BITS	Building Integrated Timing Supply
BPV	Bipolar Violation
CCV	C-bit Coding Violation
CES	C-bit Errored Seconds
CSES	C-bit Severely Errored Seconds
CCITT	Comite Consultatif Internationale de Telegraphique et Telephonique
CEPT	Conference of Postal and Telecommunications Administrations

Glossary

CPE	Customer Premises Equipment
CRC	Cyclic Redundancy Check
CRC-6	Cyclical Redundancy Check code, 6 bits
CSU	Channel Service Unit
CV	Coding Violation
CVL	Coding Violation, Line
DCS	Digital Crossconnect System
DLC	Digital Loop Carrier
DS0	Digital Signal level 0
DS1	Digital Signal level 1
DS3	Digital Signal level 3
DSU	Data Service Unit
DSX-1	Digital Signal Crossconnect - level 1
DSX-3	Digital Signal Crossconnect - level 3
DTE	Data Terminal Equipment
E1	European CEPT digital signal 1.
ECSA	Exchange Carrier Standards Association
ESF	Extended Superframe
EXZ	Excessive Zeros
FEBE	Far End Block Error
FERF	Far End Receive Failure
IP	Internet Protocol. A network protocol providing connectionless service
LES	Line Errored Seconds
LOS	Loss of Signal

LTE	Line Terminating Equipment
Kbps	Kilobits per second; one thousand bits per second
M13	Multiplexer, DS1 to DS3
M23	Multiplexer, DS2 to DS3
Mbps	Megabits per second; one million bits per second
MUX	Multiplex or Multiplexer
NE	Network Element
NMS	Network Management System
OA&M	Operations, Administration, and Maintenance. Also called OAM&P.
OAM&P	Operations, Administration, Maintenance and Provisioning
OC-1	Optical Carrier Level 1
OC-N	Optical Carrier Level N
OOF	Out of Frame
OS	Operations System
OSI	Open Systems Interconnection
PCV	P-bit Coding Violation
PES	P-bit Errored Seconds
PING	Packet Internet Groper
POP	Point of Presence
PSES	P-bit Severely Errored Seconds
QRSS	Quasi-Random Signal Sequence
RAI	Remote Alarm Indication
RDI	Remote Defect Indication
REI	Remote Error Indication

Glossary

RFI	Remote Failure Indication
SDH	Synchronous Digital Hierarchy
SEFS	Severely Errored Framing Seconds
SF	Superframe
SNMP	Simple Network Management Protocol
SONET	Synchronous Optical Network
SPE	Synchronous Payload Envelope
STE	Section Terminating Equipment
STM	Synchronous Transfer Mode
STS-1	Synchronous Transport Signal level 1
Syntran	Synchronous Transmission
Telnet	Telecommunications Network protocol
UAS	Unavailable Seconds
UDP	User Datagram Protocol
VT	Virtual Tributary

Definitions

10Base-T

An IEEE standard for operating Ethernet local area networks (LANs) on twisted-pair cabling using the home run method of wiring (the same as the phone company uses) and a wiring hub that contains electronics performing similar functions to a central telephone switch. The full name for the standard is IEEE 802.3 10Base-T.

Add/Drop

The process where a part of the information carried in a transmission system is demultiplexed (dropped) at an intermediate point and different information is multiplexed (added) for subsequent transmission. The remaining traffic passes straight through the multiplexer without additional processing.

Add/Drop Multiplexer

ADM. A multiplexer, like a terminal multiplexer, capable of extracting and inserting lower-rate signals from a higher-rate multiplexed signal without completely demultiplexing the signal.

Address Resolution Protocol

ARP. A protocol used to map IP addresses to Ethernet addresses.

Alarm Indication Signal

AIS. The DS3 AIS is framed with “stuck stuffing.” This implies that it has a valid Msubframe alignment bits, M-frame alignment bits, and P bits. The information bits are set to a 1010 sequence, starting with a one (1) after each M-subframe alignment bit, M-frame alignment bit, X bit, P bit, and C bit. The C bits are all set to zero giving what is called “stuck stuffing.” The X bits are set to one. The DS3 AIS defect is declared after DS3 AIS is present in contiguous M-frames for a time equal to or greater than T, where $0.2 \text{ ms} \leq T \leq 100 \text{ ms}$. The DS3 AIS defect is terminated after AIS is absent in contiguous M-frames for a time equal to or greater than T.

Alternate Mark Inversion

AMI. An AMI encoded signal is a bipolar pseudo-ternary signal conveying binary digits (bits) in which successive “marks” are normally of alternating, positive and negative, polarity. This is the traditional method of line encoding used with bipolar DS1 (T1) signals. However, use of AMI does not preclude long strings of zeros being sent in the signal entering the public network from the DTE in violation of the pulse density requirements mandated in FCC Rules Part 68 and AT&T Publication 62411.

Asynchronous

A network where transmission system payloads are not synchronized and each network terminal runs on its own clock.

Asynchronous Transfer Mode

ATM. A multiplexing/switching technique in which information is organized into fixed-length cells with each cell consisting of an identification header field and an information field. The transfer mode is asynchronous in the sense that the use of the cells depends on the required or instantaneous bit rate.

Attenuation

Reduction of signal magnitude or increased signal loss, usually expressed in decibels (dB).

Authentication

Process whereby a received message is associated with a specific originating entity.

Authorization	Process whereby an access policy determines if an entity is permitted to perform an operation.
Automatic Protection Switching	APS. The ability of a network element to detect a failed working line and switch the service to a spare (protection) line. 1+1 APS pairs a protection line with each working line. 1:n APS provides one protection line for every n working lines.
Bandwidth	Information-carrying capacity of a communication channel expressed in bits or bytes per second. Analog bandwidth is the range of signal frequencies that can be transmitted by a communication channel or network.
Bidirectional	Operating in both directions. Bidirectional APS allows protection switching to be initiated by either end of the line.
Bipolar Violation	BPV. A violation of the T1 bipolar AMI transmission pattern in which succeeding “ones” (pluses) are sent at opposite polarities. A BPV normally indicates a transmission error. However, B8ZS patterns contain bipolar violations, which are not counted as errors. For B3ZS (or HDB3) coded signals, a bipolar violation error event is the occurrence of a pulse of the same polarity as the previous pulse without being part of the zero substitution code. For B3ZS (or HDB3) coded signals, a bipolar violation error event may also include other error patterns such as three (four) or more consecutive zeros and incorrect polarity.
Bipolar with 3-Zero Substitution	B3ZS. An AMI line code with the substitution of a unique code to replace occurrences of three consecutive zero signal elements. Each block of three successive zeros is replaced by 00V or B0V, where B represents an inserted non-zero signal element conforming to the AMI rule, and V represents a non-zero signal element that is a bipolar violation. The choice of 00V or B0V is made so that the polarity of successive V elements alternatives to avoid introducing a DC component to the signal. An equivalent specification is that the number of B pulses between consecutive V pulses is odd.
Bipolar with 8-Zero Substitution	B8ZS. A line coding scheme used to avoid long strings of zeros in a bipolar DS1 signal entering the network from the DTE. Every string of eight zeros is replaced by a special code (token) for transmission over networks that are sensitive to long strings of zeros. The code contains a pattern of bipolar violations that is identified by the recipient and then removed in the decoding process to recreate the original string of zeros.
Bit Error Rate	BER. The number of coding violations detected in a unit of time, usually one second. BER is the ratio of errored bits received to the total bits transmitted. Bits Per Second The transmission rate for digital information.
Building Integrated Timing Supply	BITS. A master timing supply for a network in a building or office. The BITS receives timing from a source outside the building and provides DS1 and DS0 synchronization throughout the building’s network.
C-bit Coding Violation	CCV. For C-bit Parity and Syntran DS3 applications, this is the count of coding violations reported via the C-bits. For C-bit Parity, it is a count of CP-bit parity errors occurring in the accumulation interval. For SYNTRAN, it is a count of CRC-9 errors occurring in the accumulation interval.

C-bit Errored Seconds	CES. A second with one or more CCVs OR one or more Out of Frame defects OR a detected incoming AIS. This count is only for the SYNTRAN and C-bit Parity DS3 applications. This gauge is not incremented when UASs are counted.
C-bit Parity Framing	A DS3 frame format with overhead communications bits. Unlike M23 framing, C-bit parity framing does not require a stuffing indicator (stuffing is always present), so the C-bits are used to carry alarms, data, and status information. See Stuffing.
C-bit Severely Errored Seconds	CSES. A second with 44 or more CCVs OR one or more Out of Frame defects OR a detected incoming AIS. This count is only for the SYNTRAN and C-bit Parity DS3 applications. This gauge is not incremented when UAS are counted.
Channel	The smallest subdivision of a circuit that provides a type of communication service; usually a path with only one direction.
Circuit	A communications path or network; usually a pair of channels providing bi-directional communication.
Circuit Identifier	A character string assigned by the circuit vendor, which is useful when communicating with the vendor during the troubleshooting process.
Circuit Switching	Basic switching process whereby a circuit between two users is opened on demand and maintained for their exclusive use for the duration of the transmission.
Coding Violation	CV. A transmission error detected by the difference between the transmitted and the locally calculated bit-interleaved parity.
Comite Consultatif Internationale de Telegraphique et Telephonique	CCITT. The technical organs of the United Nations specialized agency for telecommunications, now the International Telecommunications Union - Telecom. They function through international committees of telephone administrations and private operating agencies.
Community Name	String that defines an administrative relationship between SNMP entities.
Conference of Postal and Telecommunications Administrations	CEPT. The European CEPT format defines the 2.048 Mbps European E1 signal made up of 30 voice-frequency channels.
CRC-6	A six-bit Cyclical Redundancy Check code embedded in the ESF frame and used to verify data transmission. If the transmitted and received CRC-6 codes match, it is highly probable that the ESF field arrived without error; however, if the CRC-6s do not match, one or more errors have occurred during the transmission of that particular ESF field. CRC-6 error events are logged into internal pairs of registers within the CSU and may be recalled through the 4 Kbps Facility Data Link (FDL) by the customer and the carrier.

Customer Premises Equipment	CPE. Items of telecommunications equipment, such as key systems, PBXs, answering machines, and CSU/DSUs, which reside on the customer's premises past the network interface.
Cyclic Redundancy Check	CRC. A technique for using overhead bits to detect transmission errors.
Data Terminal Equipment	DTE. In the EIA/TIA 232E standard specification, the RS-232 interface is connected between the DCE (Data Circuit-Terminating Equipment) and the DTE. The main difference between the DCE and the DTE is the pins two and three are reversed. The ABII uses an RS-232 port for management and asynchronous and synchronous data transmission.
Defect	A limited interruption in the ability of an item to perform a required function.
Demultiplexing	A process applied to a multiplex signal for recovering signals combined within it and for restoring the distinct individual channels of the signals.
Digital Crossconnect System	DCS. An electronic crossconnection that has access to lower-rate channels in higher-rate multiplexed signals and can electronically rearrange (crossconnect) those channels.
Digital Loop Carrier	DLC. Digital Loop Carriers are specialized SONET back-to-back mux systems providing circuit concentration in the local loop market. The elements used are similar to the Terminal Mux but transmission speed is normally limited to 155 Mbit/s (OC-3).
Digital Signal	An electrical or optical signal that varies in discrete steps. Electrical signals are coded as voltages, optical signals are coded as pulses of light.
DS0	Digital Signal level 0. The basic digital signal at 64,000 bits per second (bps) used to transport 8,000 data bytes or voice samples per second over telecommunications networks.
DS1	Digital Signal level 1. A digital signal at 1.544 million bits per second (Mbps) in North America and at 2.048 Mbps elsewhere.
DS3	Digital Signal level 3. A digital signal at 44.736 million bits per second (Mbps), the equivalent of 28 DS1 signals.
DSX-1	Digital Signal Crossconnect level 1. Refers to equipment that crossconnects DS1 rate signals, typically over short distances from zero to 660 feet.
DSX-3	Digital Signal Crossconnect level 3. Refers to equipment that crossconnects DS3 rate signals, typically over short distances from zero to 660 feet.
E1	The European CEPT digital signal similar to the North American DS1 except that the E1 information rate is 2.048 Mbps and transports 30 DS0 signals, compared to the 24 DS0 signals in the North American DS1. E1 uses separate 64 Kbps channels for synchronization and signaling, so all 8 bits of the DS0 are used to code the wave shape of the digitized voice sample.

Exchange Carrier Standards Association	ECSA. An organization that specifies telecommunications standards for ANSI.
Extended Superframe	ESF. A North American format for DS1 rate signals at 1.544 Mbps that extends the capability of the Superframe format to include a 4 Kbps facility data link channel by using less of the 8 Kbps overhead for synchronization.
Failure	A termination of the ability of an item to perform a required function. A failure is caused by the persistence of a defect.
Far End Block Error	FEBE. A message sent back upstream that receiving network element is detecting errors, usually a coding violation.
Far End Receive Failure	FERF. A signal to indicate to the transmit site that a failure has occurred at the receive site.
Far End SEF/AIS	A Far End SEF/AIS defect (Yellow Alarm) is the occurrence of the two X-bits in a M-frame set to zero. The Far End SEF/AIS defect is terminated when the two X-bits in a M-frame are set to one.
Fixed Stuff	A bit or byte whose function is reserved. Fixed stuff locations, sometimes called reserved locations, do not carry overhead or payload.
Framing	Method of distinguishing digital channels that have been multiplexed together.
Frequency	The number of cycles of periodic activity that occur in a discrete amount of time.
Grooming	Consolidating or segregating traffic for efficiency.
Interleave	The ability of SONET to mix together and transport different types of input signals in an efficient manner, thus allowing higher-transmission rates.
Internet Protocol	IP. A network protocol providing connectionless service.
IP Address	The IPv4 standard specifies a 32-bit internet address. This quantity is displayed as four decimal digits, each with a decimal range of 0 to 255, separated by decimal periods.
Jitter	Short waveform variations caused by vibration, voltage fluctuations, control system instability, and so on.
Line	An electrical path (two wires) connecting between a central office and a subscriber.
Line Errored Seconds	LES. A Line Errored Second is a second in which one or more CVs occurred OR one or more LOS defects.

Line Terminating Equipment	LTE. Network elements such as add/drop multiplexers or digital cross-connect systems which can access, generate, and process Line Overhead.
Loss of Signal	LOS. The DS3 LOS defect is declared upon observing 175 ± 75 contiguous pulse positions with no pulses of either positive or negative polarity. The DS3 LOS defect is terminated upon observing an average pulse density of at least 33% over a period of 175 ± 75 contiguous pulse positions starting with the receipt of pulse.
M23 Framing	A DS3 frame format that uses the overhead C-bits to indicate stuffing. All three Cbits in a subframe are set to one (1) if stuffing occurs, or to zero (0) if stuffing does not occur. See Stuffing.
Megabits per second	Mbps. one million of bits per second.
Multiplex	MUX. To transmit two or more signals over a single channel.
Multiplexer	A device for combining several channels to be carried by one line or fiber.
Narrowband	Services requiring up to 1.5 Mbps transport capacity.
Operations System	Sophisticated applications software that overlooks the entire network.
Orderwire	A channel used by installers to expedite the provisioning of lines.
OSI Seven-Layer Model	An Open System Interconnection (OSI) standard architecture for data communications. Layers define hardware and software required for multi-vendor information processing equipment to be mutually compatible. The seven layers from lowest to highest are: physical, link, network, transport, session, presentation, and application.
Out of Frame	OOF. A DS3 defect that is detected when any three or more errors in sixteen or fewer consecutive F-bits occur within a DS3 M-frame. An OOF defect may also be called a Severely Errored Frame (SEF) defect. An OOF defect is cleared when reframe occurs. A DS3 Loss of Frame (LOF) failure is declared when the DS3 OOF defect is consistent for 2 to 10 seconds. The DS3 OOF defect ends when reframe occurs. The DS3 LOF failure is cleared when the DS3 OOF defect is absent for 10 to 20 seconds.
Overhead	Extra bits in a digital stream used to carry information besides traffic signals. Orderwire, for example, would be considered overhead information.
P-bit Coding Violation	PCV. For all DS3 applications, a coding violation error event is a P-bit Parity Error event. A P-bit Parity Error event is the occurrence of a received P-bit code on the DS3 M-frame that is not identical to the corresponding locally-calculated code.
P-bit Errored Seconds	A second with one or more PCVs OR one or more Out of Frame defects OR a detected incoming AIS. This gauge is not incremented when UASs are counted.
P-bit Severely Errored Seconds	PSES. A PSES is a second with 44 or more PCVs OR one or more Out of Frame defects OR a detected incoming AIS. This gauge is not incremented when UASs are counted.

Packet Switching	An efficient method for breaking down and handling high-volume traffic in a network. A transmission technique that segments and routes information into discrete units. Packet switching allows for efficient sharing of network resources as packets from different sources can all be sent over the same channel in the same bit stream.
Parity Check	An error-checking scheme which examines the number of transmitted bits in a block which hold the value one. For even parity, an overhead parity bit is set to either one or zero to make the total number of transmitted ONES an even number. For odd parity, the parity bit is set to make the total number of ONES transmitted an odd number.
Path	A logical connection between two points in a network, which may follow many physical paths.
Payload	The portion of the digital signal, excluding overhead, that is available to carry voice and data services to the subscriber.
Ping	An Internet application used to test IP-level connectivity. Ping sends packets toward an Internet device address and then measures the round-trip delay time required for the device to reply.
Point of Presence	POP. A point in the network where inter-exchange carrier facilities like DS3 or OC-N meet with access facilities managed by telephone companies or other service providers.
Poll	An individual control message from a central controller to an individual station on a multipoint network inviting that station to send.
Remote Alarm Indication	RAI. A code sent upstream in a DS _n network as a notification that a failure condition has been declared downstream. (RAI signals were previously referred to as Yellow signals.)
Remote Defect Indication	RDI. A signal returned to the transmitting Terminating Equipment upon detecting a Loss of Signal, Loss of Frame, or AIS defect. RDI was previously known as FERF.
Remote Error Indication	REI. An indication returned to a transmitting node (source) that an errored block has been detected at the receiving node (sink). This indication was formerly known as Far End Block Error (FEBE).
Remote Failure Indication	RFI. A failure is a defect that persists beyond the maximum time allocated to the transmission system protection mechanisms. When this situation occurs, an RFI is sent to the far end and will initiate a protection switch if this function has been enabled.
Severely Errored Framing Seconds	A second with one or more Out of Frame defects OR a detected incoming AIS.
Simple Network Management Protocol	SNMP. An application layer providing connection-less protocol and running over UDP (User Datagram Protocol), that functions as TCP's stack network management protocol between a management station and a SNMP agent resident in a managed device. For managing TCP/IP-based networks, SNMP is the de facto standard. SNMP is designed to implement an automated network-management system for controlling and performance

Slip	An overflow (deletion) or underflow (repetition) of one frame of a signal in a receiving buffer.
Stratum	Stratum or Stratum Level refers to the accuracy of the clock source used to synchronize SONET communications systems. Accuracy is important in maintaining communications across a network. During local network failures, a backup clock source is used to maintain network timing. But when the backup clock becomes temporarily isolated because of an equipment or line failure, the clock phase will drift slowly until the communications link eventually falls out of synchronization. Stratum 1 is the primary SONET clock source obtained from a Cesium beam time standard located in Paris, France. Stratum 2 is less accurate but can keep a network synchronized for 3 to 5 days. Stratum 3 and Stratum 4 are each less accurate (and less expensive) and can provide backups for shorter time periods.
STS-1	Synchronous Transport Signal level 1. The basic SONET building block signal transmitted at 51.84 Mb/s data rate.
STS-N	Synchronous Transport Signal level N. The signal obtained by multiplexing integer multiples (N) of STS-1 signals together.
Stuffing	M13 multiplexing uses bit stuffing to bring each asynchronous DS1/DS2 up to a common data rate for transmission. M13 multiplexing forces the seven DS2s to be synchronous to each other at a rate that causes 100-percent pulse stuffing in the M23 frame. This allows the “stuff” indicator bits in the M23 frame to be used as a maintenance link between the end points. The C-bit frame does not have a “stuff” indicator because stuffing is always present.
Subnet Mask	A bit-mapped number, in xxx.xxx.xxx.xxx format, indicating which bits in an IP address identify the physical network and which bits should be ignored.
Superframe	SF. Any structure made of multiple lower-rate frames. A DS1 frame format (also called D4) comprising 193 bit positions used to multiplex 24 DS0 channels.
Synchronous	A network where transmission system payloads are synchronized to a master (network) clock and traced to a reference clock.
Synchronous Digital Hierarchy	SDH. The ITU-T defined world standard of transmission whose base transmission rate is 52 Mb/s (STM-0) and is equivalent to SONET's STS-1 or OC-1 transmission rate. SDH standards were published in 1989 to address interworking between the ITU-T and ANSI transmission hierarchies.
Synchronous Optical Network	SONET. A standard for optical transport that defines optical carrier levels and their electrically equivalent synchronous transport signals. SONET allows for a multi-vendor environment and positions the network for transport of new services, synchronous networking, and enhanced OAM&P.
Syntran	Synchronous Transmission of restructured DS3 signals in North American format at 44.736 Mbps.
Telnet	A telecommunications network application protocol providing virtual terminal service within the Internet protocol suite.

Terminal Multiplexer	Terminal Multiplexers provide simple add/drop multiplexing of SONET and standard DS1/DS3 channels onto a single SONET bearer.
Trap	A system event that results in a message being sent to a Network Management System.
Unavailable Seconds	UAS. The number of seconds that an interface is unavailable. The DS3 interface is said to be unavailable from the onset of 10 contiguous PSEs, or the onset of the condition leading to a failure. If the condition leading to the failure was immediately preceded by one or more contiguous PSEs, then the DS3 interface unavailability starts from the onset of these PSEs. Once unavailable, and if no failure is present, the DS3 interface becomes available at the onset of 10 contiguous seconds with no PSEs. Once unavailable, and if a failure is present, the DS3 interface becomes available at the onset of 10 contiguous seconds with no PSEs, if the failure clearing time is less than or equal to 10 seconds. If the failure clearing time is more than 10 seconds, the DS3 interface becomes available at the onset of 10 contiguous seconds with no Press, on the onset period leading to the successful clearing condition, whichever occurs later. With respect to the DS3 error counts, all counters are incremented while the DS3 interface is deemed available. While the interface is deemed unavailable, the only count that is incremented is UASs.
User Datagram Protocol	UDP. A transport protocol offering connectionless-mode service within the Internet protocol suite.
Wideband	Services requiring 1.5 to 50 Mb/s transport capacity.

INDEX

Symbols

& (TL1 list notation) 9-4, 9-84
&& (TL1 range notation) 9-4, 9-84

Numerics

10Base-T Glossary-5

A

Access

Levels 6-8, 6-11
Levels, Setting 6-9, 6-13
Service Aisle 3-7
Access Identifier <aid> 9-84
Access Identifier Types <AIDType> 9-85
ACCUNET T1.5 3-7
ACO 7-3, 8-11

Activate

Error Response for Incorrect Password 9-13
Far-End Loopbacks in C-Bit Framing Mode ... 7-27
Far-End Loopbacks in M23 Framing Mode ... 7-27
TL1 User Session 9-11
Users 9-12

ACT-USER 9-18

Add/Drop Glossary-5

Add/Drop Multiplexer Glossary-5

Adding Users 9-13

Additional Access Identifier Information <aiddet> 9-86

Address Resolution Protocol Glossary-5

Address, Network Management Station (NMS) 11-2

ADM Glossary-1

AIC Bit, Description 2-10

AID 9-84

Entering Groups, Lists, and Ranges 9-4

Type 9-85

AIDType 9-8

AIS Glossary-1

Aisle, Service Access 3-7

Alarm

Connector Description 2-7
Contacts A-3
Cut Off 8-11
Far-End Reporting 12-4
Far-End Transmission 12-4
Indication Signal Glossary-5
Relay Contacts 2-3, 3-5

Relay Output Contacts 8-13
Reporting 12-1
Reporting, Far End 12-4
Severity, Other Controller Bad 8-11
Severity, Standby DS3 Self-Test 8-11
TL1 Messages 12-4
TL1 Reporting 12-4
Alarm Code <almcde> 9-86
Alarm Cut Off
LED and Pushbutton 7-3
Alarm Level, Set Attribute 9-75
Alarm Message <almmsg> 9-86
Alarmed Condition Types 9-87
ALARMOUT 8-13
ALARMS 8-11
Alarms
Critical 12-2
Critical (CR) 7-4
DS3 Far-End 12-4
LEDs 12-3
Major 12-2
Major/Minor (MJ/MN) 7-4
Minor 12-2
ALARMS STANDBY 8-11
Alarms Standby, DS3 Self-Test 8-11
Alarms Standby, Other Controller Bad 8-11
Alternate Mark Inversion Glossary-5
Altitude, Limitation 4-3
ALW-AUTORST 9-18
ALW-LOG-SECU 9-19
ALW-LPBK-<FacilityType> 9-20
ALW-MSG-<AIDType> 9-20
ALW-PMREPT-<FacilityType> 9-22
ALW-SWTOPROTN-<FacilityType> 9-22
ALW-SWTOWKG-<FacilityType> 9-23
AMI Glossary-1
ANSI
T1.102 3-7
T1.107 3-7
T1.403 3-7
T1.404 3-7
APS Glossary-1
Architecture, Redundant 2-4
ARM 8-13
ARP Glossary-1

Index

Asynchronous Glossary-5
 Transfer Mode Glossary-5
AT&T 54017 3-7
AT&T 62411 3-7
ATAG Segment <atagseg> 9-86
ATM Glossary-1
Attenuation Glossary-5
Authentication Glossary-5
Authentication Failure Trap 11-6
Authorization Glossary-6
AUTOCOPY 8-14
Autocopy, Verifying 6-22
Automatic
 Messages 9-101
 Protection Switching Glossary-6
 Protection Test, DS3 7-40
 Redundancy Mode 8-13
Automatic Message Tag <atag> 9-86

B

B3ZS Glossary-1
B8ZS Glossary-1
Backup copy. See Temporary Copy 6-5
Bandwidth Glossary-6
Banks, DS1 NIU Loopback Using Two Wide 7-23
Basic Configuration 6-2
 SNMP 11-2
Battery Unit
 Mounting 4-11
 Mounting Template 4-13
 Part Number 4-2
 Rack Mounting 4-14
BER Glossary-1
 Definition 2-15
BERT
 DS3 Loopup Network with PRBS 7-17
 Looptests Using Built-in PRBS 7-15
 Low-Speed CSU Loopup Drop with PRBS 7-15
 Low-Speed NIU Loopup Network with PRBS 7-16
Bidirectional Glossary-6
Bipolar
 Violation Glossary-6
 with 3-Zero Substitution Glossary-6
 with 8-Zero Substitution Glossary-6
Bit Glossary-1
 Error Rate Glossary-6
 Error Rate, Definition 2-15
BITS Glossary-1
Block Errors, Far End 2-34
bps Glossary-1

BPV Glossary-1
 Definition 2-15
Build Out, Line 2-3
Building Integrated Timing Supply Glossary-6
Built-in PRBS BERT, Looptests Using 7-15

C

Cable, External Clock 5-9
Cabling Layout 5-5
CAN 3-7
CAN/CSA-C22.2 3-7
Canadian Standards Association v
Cancel User Session Event Message 9-106
Canceling the TL1 User Session 9-16
CANC-USER 9-23
CANC-USER-SECU 9-24
Capacity, Channel 3-2
Card
 Locations 10-2
 Maintenance 10-2
 Replacing 10-6
 Replacing DS3 10-10
 Replacing MSO 10-7
 Self-Test, DS3 7-12
 Self-Test, Low-Speed 7-12
Caution Notice vi
C-bit
 Coding Violation Glossary-6
 Errored Seconds Glossary-7
 Severely Errored Seconds Glossary-7
C-bit Framing, Activating Far-End Loopbacks in .. 7-27
C-bit Framing, DS3
 Line Loopback with 7-36
 Payload Loopback with 7-36
 Test with 7-33
C-bit Parity
 Errors 2-34
 Framing Glossary-7
 Loopback Control 2-8
 Mode 2-8
CCITT 3-7, Glossary-1
CCV Glossary-1
CEPT Glossary-1
CES Glossary-1
Changing User Password 9-14
Changing User Properties 9-14
Channel Glossary-7
 Capacity 3-2
Circuit Glossary-7
 Identifier Glossary-7
 Low-Speed Tests 7-29

-
- Self-Test, Low-Speed 7-11
 - Switching Glossary-7
 - CLEAR 8-14
 - Clearance
 - Cooling 4-6
 - Maintenance 4-3
 - CLI
 - Command List 8-9
 - Commands 8-1
 - Messages 8-1
 - RS-232 Management Port Pinout A-7
 - Clock Cable 5-9
 - Clock Connector, External 2-7
 - Clocking, T1 1-4
 - Codes, Far-End Loop 7-37
 - Coding
 - Violation Glossary-7
 - Comite Consultatif Internationale de Telegraphique et
Telephonique Glossary-7
 - Command
 - Categories 9-7
 - Line Interface 8-6
 - List
 - TL1 9-17
 - Modifiers 9-7
 - Syntax 9-3
 - Command Line Interface, Using 8-6
 - Command Mode <cmdmde> 9-86
 - Community Name Glossary-7
 - Completion Codes 9-87
 - Compliance iv
 - Condition Description <conddescr> 9-87
 - Condition Effect <condeff> 9-87
 - Condition LED, High Speed (HS) Line 7-5
 - Condition Type <condtype> 9-87
 - Conference of Postal and Telecommunications
 - Administrations Glossary-7
 - CONFIG 8-15
 - Configuration
 - Basic 6-2
 - Management 1-5
 - Overview 6-2
 - Restoring 6-5
 - Saving 6-19
 - SNMP 11-2
 - Temporary Copy 6-5
 - Configuring
 - DS3 6-17
 - PPP 6-15
 - SNMP IP addresses 6-15
 - TL1 9-9
 - Connecting
 - TL1 9-9
 - Connector 2-6
 - External Clock 2-7
 - Panel 2-6
 - Pinouts A-1
 - Power 5-4
 - CONN-LPBK-<LSType> 9-24
 - CONN-LPBK-T3 9-25
 - Contact, SNMP 11-3
 - Context Sensitive Help 8-7
 - CONTROLLER 8-17
 - Controller Cards, Part Number 4-2
 - Controller Status (CS) LED 7-5
 - Cooling Clearance 4-6
 - COPY 8-18
 - Copying Configuration Manually 6-22
 - Correlation Tag <ctag> 9-89
 - CP-01 v
 - CPE Glossary-2
 - CPY-MEM 9-25
 - CR, Critical Alarm 7-4
 - CRC Glossary-2
 - CRC-6 Glossary-2, Glossary-7
 - Critical (CR) Alarms 7-4
 - Critical Alarm 12-2
 - Critical Alarm Definition 2-15
 - CS, Controller Status 7-5
 - CS-03 3-7
 - CSA 22.2 v, 3-7
 - CSA-C22.2 v, 3-7
 - CSES Glossary-1
 - CSU Glossary-2
 - CSU Loopback Toward Drop, DS1 Send 7-24
 - CSU Loopup Drop with PRBS BERT, Low-Speed 7-15
 - Current Limiting 5-14
 - Customer Premises Equipment Glossary-8
 - Cutoff (ACO) LED and Pushbutton, Alarm 7-3
 - CV Glossary-2
 - CVL 8-29, 8-60, Glossary-2
 - Cyclic Redundancy Check Glossary-8
- D**
- Danger Notice vi
 - Data
 - Link, DS3 Path Maintenance 7-7
 - Link, Functional Description of DS3 Path Maintenance 7-7
 - Rate 3-2
 - Terminal Equipment Glossary-8
 - Data Segment <data_seg> 9-89
-

Index

- Datapath Transmission Verification 2-29
- DATE 8-18
- Date <date> 9-89
- Date Setting 6-7
- DAY 8-19
- DB25 Connector A-8
- DB9 Connector A-7
- DC Power Connectors A-2
- DCS Glossary-2
- Default Values 8-63
- Defaults, Restoring 6-6
- Defect Glossary-8
- Deleting Users 9-13
- Demultiplexing Glossary-8
- Description of DS3 Path Maintenance Data Link,
 Functional 7-7
- Design Philosophy 1-2
- Determining Performance and Status 7-7
- DGN-<AIDType> 9-26
- Digital
 - Crossconnect System Glossary-8
 - Loop Carrier Glossary-8
- Digital Signal Glossary-8
 - Crossconnect level 1 Glossary-8
 - Crossconnect level 3 Glossary-8
 - level 0 Glossary-8
 - level 1 Glossary-8
 - level 3 Glossary-8
- Dimensions, Wide Bank 28 2-2
- Direction of Alarm or Condition <dirn> 9-89
- DISC-LPBK-<FacilityType> 9-27
- DLC Glossary-2
- DLT-<LSType> 9-28
- DLT-USER-SECU 9-28
- Download Firmware 6-23
- Drop with PRBS BERT, Low-Speed CSU Loopup 7-15
- Drop, DS1 Send CSU Loopback Toward 7-24
- Drop, DS1 Send NIU Loopup Code Toward 7-25
- Drop, Testing the Network to the Far-End Through a
 Low-Speed 7-28
- DS0 Glossary-2, Glossary-8
- DS1 8-21, Glossary-2, Glossary-8
 - Card State Trap 11-8
 - Connection Cables 1-4
 - Connector Pinout A-4
 - Drain Wires 5-7
 - Equipment Loopback 7-20
 - Hardware Failure 2-32
 - Internal Hardware Failure Clear Trap 11-9
 - Internal Hardware Failure Spare Clear Trap 11-9
 - Internal Hardware Failure Spare Trap 11-9
 - Internal Hardware Failure Trap 11-9
 - Line Code 3-4
 - Line Coding 2-3
 - Line Loopback 7-20
 - Line Rate 3-4
 - Loopback Latency 3-4
 - Maximum Cable Length 3-4
 - Metallic Loopback 7-21
 - Move Home Trap 11-8
 - NIU Loopback 7-22
 - NIU Loopback Using Two Wide Banks 7-23
 - Ports 1-3, 1-4
 - Properties 9-90
 - Protect Switch Trap 11-8
 - Range Notation (&&) 9-84
 - Receive Sensitivity 3-4
 - Send CSU Loopback Toward Drop 7-24
 - Send NIU Loopup Code Toward Drop 7-25
 - Send NIU Loopup Code Toward Network 7-26
 - Standby 2-3
 - Transmit Amplitude 3-4
 - Transmit Jitter 3-4
- DS1 AINS 8-22
- DS1 CIRCUITID 8-23
- DS1 ENABLE/DISABLE 8-23
- DS1 EQUIPMENT 8-24
- DS1 LENGTH 8-25
- DS1 LINE 8-25
- DS1 LINECODE 8-26
- DS1 LOOPDETECT 8-27
- DS1 METALLIC 8-27
- DS1 MOVE 8-28
- DS1 PROTECT 8-30
- DS1 SEND 8-30
- DS1/E1 Line Status LEDs (one per span),
 Low-Speed 7-6
- DS1/E1 Test, The 7-12
- DS3 8-32, Glossary-2, Glossary-8
 - Alarms 2-34
 - Automatic Protection Test 7-40
 - Card Replacing 10-10
 - Configuring 6-17
 - Connectors 2-6
 - Controller State Trap 11-8
 - Electronics Protection Test 7-43
 - Enterprise MIB 11-5
 - Equipment Loopback 2-33, 7-35
 - Far-End Alarms 9-106
 - Far-End Alarms and Control (FEAC) 12-4
 - Far-End Statistics 7-7
 - Far-End with Loopback Tests, Testing the 7-37

-
- Framing and Loop Timing, Testing 7-32
 - Framing Formats 3-3
 - Idle Code to Network 2-9
 - Input Port 2-2
 - Interfaces, Testing 7-32
 - Line Code 3-3
 - Line Loopback 2-32
 - Line Loopback with C-bit Framing 7-36
 - Line Loopback with M23 Framing 7-35
 - Line Rate 3-3
 - Loopup Network with PRBS BERT 7-17
 - Manual Switch Test 7-40
 - Multiframe Structure 2-9
 - Near-End with Loopback Tests, Testing the ... 7-35
 - Network Protection Test 7-42
 - Non-Redundant Test Setup 7-32
 - Path Maintenance Data Link 7-7
 - Path Maintenance Data Link, Functional
 - Description of 7-7
 - Payload Loopback 2-33
 - Payload Loopback with C-bit Framing 7-36
 - Payload Loopback with M23 Framing 7-36
 - Ports 1-3, 1-4
 - Processors 2-4
 - Properties 9-91
 - Receive Sensitivity 3-3
 - Redundancy Description 2-2
 - Redundancy, Testing 7-39
 - Revertive Switching Test 7-41
 - Test Setup 7-39, 7-42
 - Test with C-bit Framing 7-33
 - Test with M23 Framing 7-33
 - Tests with Line Timing 7-34
 - Transmit Amplitude 3-3
 - Transmit Jitter 3-3
 - DS3 Card Self-Test 7-12
 - DS3 CIRCUITID 8-33
 - DS3 CLOCK 8-33
 - DS3 CLOCKREVERT 8-34
 - DS3 EQUIPMENT 8-34
 - DS3 EQUIPMENTID 8-35
 - DS3 FACILITYID 8-35
 - DS3 FRAMEID 8-35
 - DS3 FRAMING 8-36
 - DS3 GENNUMBER 8-36
 - DS3 LENGTH 8-37
 - DS3 LINE 8-37
 - DS3 LOCATIONID 8-37
 - DS3 LOOPDETECT 8-38
 - DS3 PAYLOAD 8-38
 - DS3 PM THRESHOLD 8-39
 - DS3 PORTNUMBER 8-41
 - DS3 PROTECT 8-41
 - DS3 Self-Test, Alarm Severity 8-11
 - DS3 SEND 8-42
 - DS3 THRESHOLD 8-42
 - DS3 UNIT 8-43
 - DSU Glossary-2
 - DSX-1 Glossary-2, Glossary-8
 - Cable Part Number 5-7
 - DSX-3 Glossary-2, Glossary-8
 - DTE Glossary-2
 - E**
 - E1 Glossary-2, Glossary-8
 - Connector Pinout A-4
 - Line Coding 1-4, 2-3
 - Line Rate 3-4
 - Ports 1-3
 - Properties 9-90
 - Transmit Amplitude 3-4
 - Transmit Jitter 3-4
 - Transmit Pulse Shape 3-4
 - ECSA Glossary-2
 - ED-<AIDType> 9-29
 - ED-DAT 9-31
 - ED-PID 9-31
 - ED-USER-SECU 9-32
 - Electronics
 - and Network Protection 2-19
 - and Network Protection, Testing 7-42
 - Protection Mode 2-17, 2-18
 - Protection Test, DS3 7-43
 - Protection, Testing 7-39
 - Electrostatic Discharge Guidelines vii
 - ENT-<LSType> 9-33
 - Enterprise MIB 1-8
 - ENT-USER-SECU 9-34
 - Environment Access Identifier (EnvAID) 9-91
 - Environment Requirements 4-3
 - EQUIPMENT 8-43
 - Equipment
 - Command 6-6
 - Loopback, DS1 7-20
 - Loopback, DS3 7-35
 - Parameters 9-92
 - Error
 - C-bit parity 2-34
 - Far-End Block 2-34
 - P-bit parity 2-34
 - Error Message
 - Invalid Equipment Parameter Value 9-92

- Invalid T1/E1 Parameter or Value 9-90
- Invalid T3 Parameter or Value 9-91
- Invalid Test Session Number 9-92
- Response to Commands Not Recognized 9-16
- Response to Commands Not Supported 9-16
- Error Response
 - Format 9-6
 - Illegal User Access Privilege 9-100
 - Insufficient Privilege to Execute Command .. 9-100
 - Invalid Access Identifier 9-85
 - Invalid Access Identifier Type 9-85
 - Invalid Condition Type 9-88
 - Invalid Direction 9-90
 - Invalid Location 9-92
 - Invalid Log Identifier 9-93
 - Invalid Loopback Type 9-93
 - Invalid Monitored Parameter Type 9-95
 - Invalid Notification Code 9-96
 - Invalid Service 9-98
 - Invalid Time Period 9-99
 - User Is Not Logged In 9-16
- ESD Guidelines vii
- ESF Glossary-2
- ESL 8-29, 8-60
- Ethernet
 - Connector 2-6
 - Port 1-3, 3-5
 - RJ-45 Pinout A-9
- Ethernet Status LED 7-6
- Excessive Zeros 2-34
- Exchange Carrier Standards Association Glossary-9
- EXIT 8-45
- Extended Superframe Glossary-9
- External
 - Alarm Wiring 5-12
 - Clock Cable 5-9
 - Clock Connector 2-7
- EXZ Glossary-2
- EXZ, Definition 2-15
- F**
- Faceplates
 - Fan, Removing and Installing 10-3
- Faceplates, Standard, Removing and Installing 10-3
- FacilityType 9-7
- Factory Defaults, Restoring 6-2, 6-6
- Failed CLI Login Trap 11-8
- Failure Glossary-9
- Fan Faceplate, Installing 10-3
- Fan Faceplates, Removing and Installing 10-3
- Far-End
 - Alarm Bit 2-11
 - Alarm Bit Status Channel Codes 2-11
 - Alarm Reporting 12-4
 - Alarm Transmission 12-4
 - Alarms 2-34
 - Alarms and Control (FEAC) 12-4
 - Alarms, Automatic Receipt 2-8
 - Alarms, Controlled Receipt 2-8
 - Block Error Glossary-9
 - Block Errors 2-34
 - DS1 Loss of Signal 2-32
 - Loop Codes 7-37
 - Loopbacks in C-Bit Framing Mode, Activating 7-27
 - Loopbacks in M23 Framing Mode, Activating 7-27
 - Receive Failure Glossary-9
 - SEF/AIS Glossary-9
 - Statistics, DS3 7-7
 - Testing, DS3 7-37
 - Testing, Low-Speed 7-27, 7-28
- FCC
 - Regulations 3-7
 - Requirements, Part 15 iv
 - Requirements, Part 68 Exhibit J1 iv
- FEAC 12-4
- Features 2-2
- FEBE Glossary-2
- FERF Glossary-2
- Ferrite
 - RF Suppressors, Installing 5-10
 - RFI Suppressors, Part Number 5-5
- FFO PRESENT 8-45
- FFO Test and Monitoring 7-13
- Firmware Download
 - Ethernet 6-35
 - Non-redundant Wide Bank 28 6-32
 - Redundant Wide Bank 28 6-26
 - RS-232 6-35
 - Xmodem 6-32
- Fixed Stuff Glossary-9
- Framing Glossary-9
 - and Loop Timing, Testing DS3 7-32
 - Bit Errors 2-34
 - DS3 Line Loopback with C-bit 7-36
 - DS3 Line Loopback with M23 7-35
 - DS3 Payload Loopback with C-bit 7-36
 - DS3 Payload Loopback with M23 7-36
 - DS3 Test with C-bit 7-33
 - DS3 Test with M23 7-33
 - Formats, DS3 3-3

Mode, Activating Far-End Loopbacks in C-Bit	7-27
Mode, Activating Far-End Loopbacks in M23	7-27
Modes	
C-bit Parity	2-8
Description	2-8
M23	2-8
Transparency of Low-Speed	1-4
Frequency	Glossary-9
Functional Description of DS3 Path Maintenance Data	
Link	7-7
Fuse, Power	5-15
G	
Gateway	
Default	11-2
SNMP/Telnet	11-2
Ghost Unit, Part Number	4-2
GR-1089-CORE	3-7
GR-253-CORE	3-7
GR-499-CORE	3-7
GR-63-CORE	3-7
Grooming	Glossary-9
H	
Hardware Configuration Overview	6-2
HELP, ?	8-46
Help, Context Sensitive	8-7
High Speed (HS) Line Condition LED	7-5
HOUR	8-47
HS, High Speed Line Condition	7-5
I	
Idle Sequences	2-34
indicator	
Test and Status	2-14
Indicators, LED Test and Status	7-2
Industry Canada	
CS-03	3-7
Requirements	v
INH-AUTORST	9-35
INH-LOG-SECU	9-35
INH-LPBK-<FacilityType>	9-36
INH-MSG-<AIDType>	9-37
INH-PMREPT-<FacilityType>	9-38
INH-SWTOPTN-<FacilityType>	9-38
INH-SWTOWKG	9-39
INIT-LOG	9-39
INIT-REG-<FacilityType>	9-40
INIT-SYS	9-41
Inserting the Electronic Section of an MSO Card ..	10-9
Installation Requirements	4-3
Interface	
DS3 Redundant	8-3
Management	8-2
Operation, Testing Low-Speed	7-18
Telnet	8-3
Testing, DS3	7-32
interface	
DS1, Standby	2-3
Interleave	Glossary-9
Internet Protocol	Glossary-9
IP	8-48, Glossary-2
Address	Glossary-9
Address, NMS	11-2
Address, SNMP	11-2
Addresses, Configuring	6-15
J	
Japan Approvals Institute (JATE)	vi
Jitter	Glossary-9
K	
Kbps	Glossary-3
L	
LCV	
Definition	2-15
Description	2-15
LED	2-14
Alarm Reporting	12-3
and Pushbutton, Alarm Cutoff (ACO)	7-3
Controller Status (CS)	7-5
Ethernet Status	7-6
High Speed (HS) Line Condition	7-5
Low-Speed DS1/E1 Line Status	7-6
Power	7-3
Test and Status Indicators	7-2
LES	Glossary-2
Limitations of Warranty	viii
Line	Glossary-9
Build Out	2-3
Code	
DS1	2-3, 3-4, 6-19
DS3	3-3
E1	2-3, 3-4, 6-19
Violations	2-15, 2-34
Condition LED, High Speed (HS)	7-5
Errored Seconds	Glossary-9
Impedance	3-3
Loopback with C-bit Framing, DS3	7-36
Loopback with M23 Framing, DS3	7-35

Index

- Loopback, DS1 7-20
- Rate
 - DS1 3-4
 - DS3 3-3
 - E1 3-4
- Status LEDs (one per span), Low-Speed DS1/E1 7-6
- Terminating Equipment Glossary-10
- Timing, DS3 Tests with 7-34
- Link
 - Down Trap 11-7
 - DS3 Path Maintenance Data 7-7
 - Functional Description of DS3 Path Maintenance Data 7-7
 - Up Trap 11-7
- List 4-2
- List Notation (&) 9-4
- LOAD 8-49
- Location of Alarm or Condition <locn> 9-92
- Location, SNMP 11-3
- LOG 8-50
- Log Identifier <lognm> 9-93
- Log Number 9-93
- Logging Off 6-22
- Logging On 6-4
- Login
 - Rules 6-8, 6-11
 - Rules, with Security On 6-8, 6-11
- Loop Codes, Far-End 7-37
- Loop Tests
 - Low-Speed Far-End 7-27
 - Low-Speed Near-End 7-19
 - Timing and DS3 Framing 7-32
- Loopback
 - C-bit Framing, DS3 Line 7-36
 - C-bit Framing, DS3 Payload 7-36
 - DS1 Equipment 7-20
 - DS1 Line 7-20
 - DS1 Metallic 7-21
 - DS1 NIU 7-22
 - DS3 Equipment 7-35
 - Latency, DS1 3-4
 - M23 Framing, DS3 Line 7-35
 - M23 Framing, DS3 Payload 7-36
 - Tests, Testing the DS3 Far-End 7-37
 - Tests, Testing the DS3 Near-End 7-35
 - Toward Drop, DS1 Send CSU 7-24
 - Using Two Wide Banks, DS1 NIU 7-23
- Loopback Type <lpbktype> 9-93
- Loopbacks in C-Bit Framing Mode, Far-End 7-27
- Loopbacks in M23 Framing Mode, Far-End 7-27
- Looptests Using Built-in PRBS BERT 7-15
- Loopup Code Toward Drop, DS1 Send NIU 7-25
- Loopup Code Toward Network, DS1 Send NIU 7-26
- Loopup Drop with PRBS BERT, Low-Speed CSU 7-15
- Loopup Network with PRBS BERT, DS3 7-17
- Loopup Network with PRBS BERT, Low-Speed NIU 7-16
- LOS Glossary-2
- Loss of Signal Glossary-10
 - DS1 2-32
 - DS3 2-16, 2-34
- Low-Speed
 - Cards, Part Number 4-2
 - Connector Description 2-6
 - Connector Pinout A-4
 - Low-Speed Card Self-Test 7-12
 - Low-Speed Channels
 - Turning Off 6-22
 - Unterminated 6-22
 - Unused 6-22
 - Low-Speed Circuit Self-Test 7-11
 - Low-Speed Circuit, Running Maintenance Tests on a 7-29
 - Low-Speed CSU Loopup Drop with PRBS BERT 7-15
 - Low-Speed Drop, Testing the Network to the Far-End 7-28
 - Low-Speed DS1/E1 Line Status LEDs (one per span) 7-6
 - Low-Speed Far-End with Loop Tests, Testing the . 7-27
 - Low-Speed Interface Operation, Testing 7-18
 - Low-Speed Near-End with Loop Tests, Testing 7-19
 - Low-Speed NIU Loopup Network with PRBS BERT 7-16
- LS 8-50
- LS AINS 8-51
- LS CIRCUITID 8-53
- LS ENABLE/DISABLE 8-53
- LS EQUIPMENT 8-54
- LS LENGTH 8-55
- LS LINE 8-56
- LS LINECODE 8-56
- LS LOOPDETECT 8-57
- LS METALLIC 8-57
- LS MOVE 8-59
- LS PM THRESHOLD 8-59
- LS PROTECT 8-61
- LS SEND 8-61
- LSMODE 8-58
- LSType 9-7
- LTE Glossary-3

M

- M13 Glossary-3
 - M23 Glossary-3
 - Framing Glossary-10
 - Framing Mode 2-8
 - Framing Mode, Activating Far-End Loopbacks
 - 7-27
 - Framing, DS3 Line Loopback with 7-35
 - Framing, DS3 Payload Loopback with 7-36
 - Framing, DS3 Test with 7-33
 - Maintenance 10-1
 - Card 10-2
 - Clearances 4-3
 - Data Link, DS3 Path 7-7
 - Data Link, Functional Description of DS3 Path 7-7
 - MSO 10-5
 - Practices for Low-Speed Cards 10-5
 - Tests on a Low-Speed Circuit, Running 7-29
 - Major Alarm Definitions 2-15
 - Major Alarms 12-2
 - Major/Minor (MJ/MN) Alarms 7-4
 - Management
 - Interfaces 8-2
 - Introduction 1-5
 - NMS Address 11-2
 - Overview 8-2
 - Port Connections 6-3
 - Ports
 - CLI RS-232 3-5
 - Ethernet 3-5
 - TL1 3-5
 - Manual Switch Test, DS3 7-40
 - Materials List, Packing 4-2
 - Maximum Cable Length, DS1 3-4
 - Mbps Glossary-3
 - Megabits per second Glossary-10
 - Memory <frommem> and <tomem> 9-94
 - Memory Administration Commands 9-7
 - Message Summary Table 9-106
 - Message Type <msgtype> 9-94
 - Messages
 - Alarm 9-86
 - Automatic 9-101
 - CLI 8-1
 - Metallic Loopback, DS1 7-21
 - MIB 1-8
 - Carrier Access Enterprise 1-8
 - DS3 Enterprise 11-5
 - Minor Alarm Definition 2-15
 - Minor Alarms 12-2
 - MJ/MN, Major/Minor Alarms 7-4
 - Mode, Activating Far-End Loopbacks in C-Bit Framing
 - 7-27
 - Mode, Activating Far-End Loopbacks in M23 Framing
 - 7-27
 - Modifiers, Command 9-7
 - Monitor Date <mondatt> 9-94
 - Monitor Level <monlev> 9-94
 - Monitor Time <montm> 9-94
 - Monitored Parameter Type <montype> 9-95
 - Monitoring, FFO Test and 7-13
 - MSO Card
 - Inserting 10-9
 - Low-Speed Maintenance Practice 10-5
 - Removing 10-8
 - Multiple Output Responses 9-5
 - Multiplex Glossary-10
 - Multiplexer Glossary-10
 - MUX Glossary-3
- N**
- Narrowband Glossary-10
 - National Electrical Code v, 3-7
 - NE Glossary-3
 - Near-End with Loop Tests, Testing Low-Speed 7-19
 - Near-End with Loopback Tests, Testing the DS3 .. 7-35
 - NEBS 3-7
 - NEBS Requirements vi, 3-8
 - Network
 - Equipment Building System (NEBS) Requirements
 - vi
 - Identifier, Setting 9-10
 - Interface Unit 2-2
 - Loopup
 - DS1 Send NIU Code 7-26
 - PRBS BERT, DS3 7-17
 - PRBS BERT, Low-Speed NIU 7-16
 - Maintenance Commands 9-7
 - Management Station (NMS) IP address 11-2
 - Protection Test, DS3 7-42
 - Protection, Testing Electronics and 7-42
 - Settings, Verifying 6-16
 - Testing, Far-End Through a Low-Speed Drop 7-28
 - NIU
 - Functionality 2-2
 - Loopback Using Two Wide Banks, DS1 7-23
 - Loopback, DS1 7-22
 - Loopcode Detection 2-31
 - Loops, Introduction 1-3
 - Loopup Code Toward Drop, DS1 Send 7-25
 - Loopup Code Toward Network, DS1 Send 7-26

Loopup Network with PRBS BERT, Low-Speed 7-16

NMS Glossary-3

NMS address 11-2

Non-Redundant Test Setup, DS3 7-32

Normal Response to

 Activate User Command 9-12

 Delete User Command 9-14

Notices vi

 Caution vi

 Danger vi

 Note vi

 Warning vi

Notification Code <ntfncde> 9-96

Number of Reports <numrept> 9-96

O

OA&M Glossary-3

OAM&P Glossary-3

OC-1 Glossary-3

Occurrence Date <ocrdat> 9-96

Occurrence Time <ocrtm> 9-96

OC-N Glossary-3

OOF Glossary-3

OpenView 1-8

Operation, Testing Low-Speed Interface 7-18

Operations System Glossary-10

OPR-ACO-ALL 9-41

OPR-ARC-<LSType> 9-41

OPR-LPBK-<FacilityType> 9-43

Orderwire Glossary-10

OS Glossary-3

OSI Glossary-3

 Seven-layer Model Glossary-10

Other Controller Bad, Alarm Severity 8-11

Out of Frame 2-34, Glossary-10

Over-Current Protection 2-2

Overhead Glossary-10

Overview 12-2

 Wide Bank 28 1-2

Over-Voltage Protection 2-2

P

Packet Switching Glossary-11

Packing Materials List 4-2

Parameter Descriptions, TL1 9-83

Parameters, System 3-2

Parity Check Glossary-11

Parity Errors

 C-bit 2-34

 P-bit 2-34

Part Number

 Battery Charger 4-2

 Battery Unit 4-2

 Controller Card 4-2

 DS1 Cards 4-2

 DSX-1 Cable 5-7

 E1 Cards 4-2

 Ghost Unit 4-2

 Mounting Brackets 4-4

 MSO Cards 4-2

 Power Converter v

 Power Cube Tray 4-2

 Vertical Mounting Bars 4-2

Part Numbers 4-2

Password

 Changing 6-8, 6-11, 9-14

 Incorrect Error Response 9-13

 Protection 6-8, 6-11

 Default 6-4, 6-8, 6-11

 Enabling 6-8, 6-11

Path Glossary-11

Path Maintenance Data Link

 Terminal-to-Terminal 2-8

Path Maintenance Data Link, DS3 7-7

Path Maintenance Data Link, Functional Description of DS3 7-7

Payload Glossary-11

Payload Loopback with C-bit Framing, DS3 7-36

Payload Loopback with M23 Framing, DS3 7-36

P-bit

 Coding Violation Glossary-10

 Errored Seconds Glossary-10

 Parity Errors 2-34

 Severely Errored Seconds Glossary-10

PCV Glossary-3

Performance and Status, Determining 7-7

PES Glossary-3

Phase <ph> 9-96

PING 8-63, Glossary-3

Ping Glossary-11

Pintouts

 Connector A-1

Point of Presence Glossary-11

Point-to-Point Protocol 6-17

 Link Status 2-8

 Over C-bit Link 2-8

 Status 7-8

Poll Glossary-11

POP Glossary-3

Port Management Connections 6-3

-
- Power
- Applying 5-16
 - Battery Charger Part Number 4-2
 - Battery Charger, Mounting 4-14
 - Connectors 2-7
 - Connectors, Wiring 5-14
 - Consumption 2-2
 - Converter
 - Location 4-3
 - Mounting 4-11
 - Part Number v
 - Rack Mounting 4-14
 - Cube Tray Part Number 4-2
 - Description 2-2
 - LED 7-3
 - Redundancy 2-7
 - Status Trap 11-8
 - Turning On 5-16
- PPP Addresses, Configuring 6-15
- PRBS BERT
- DS3 Loopup Network with 7-17
 - Looptests Using Built-in 7-15
 - Low-Speed CSU Loopup Drop with 7-15
 - Low-Speed NIU Loopup Network with 7-16
- Precautions, Safety vi
- Private Identifier <pid> 9-97
- PROGRAM FLASH 8-63
- Programing FLASH, Options 6-34
- Prompt Identifier, Setting 9-10
- Protection
- Electronics 2-17, 2-18
 - Electronics and Network 2-19
 - Over-Current 2-2
 - Over-Voltage 2-2
 - Test, DS3 Automatic 7-40
 - Test, DS3 Electronics 7-43
 - Test, DS3 Network 7-42
 - Testing Electronics 7-39
 - Testing Electronics and Network 7-42
- Protocol Status, Point-to-Point 7-8
- PSES Glossary-3
- Pushbutton, Alarm Cutoff (ACO) LED and 7-3
- Q**
- QRSS Glossary-3
- R**
- Rack Mounting Brackets, Part Number 4-2
 - RAI Glossary-3
 - Range Notation (&&) 9-4, 9-84
 - Rate, Data 3-2
 - RDI Glossary-3
 - RD-MEM-FILE 9-43
 - Receive Sensitivity
 - DS1 3-4
 - DS3 3-3
 - Redundancy
 - Architecture 2-4
 - Description 2-2
 - DS3 and Controllers 2-17
 - DS3 Network Interfaces 8-3
 - Testing DS3 7-39
 - Reframe Time 3-2
 - REI Glossary-3
 - Relay Contacts 3-5
 - Remote
 - Alarm Indication 2-34, Glossary-11
 - Defect Indication Glossary-11
 - Error Indication Glossary-11
 - Failure Indication Glossary-11
 - Removing
 - Electronic Section of an MSO Card 10-8
 - Fan Faceplates 10-3
 - Replacing
 - DS3 Controller Cards 10-10
 - Low-Speed Cards 10-5
 - MSO Low-Speed Card 10-7
 - Standard Low-Speed Card 10-6
 - Report
 - Alarm Clear Message Format 9-103
 - Performance Monitoring Message Format 9-105
 - Reporting
 - Alarms 12-1, 12-4
 - Reporting Interval <reptinvl> 9-97
 - Reporting Start Time <reptstatm> 9-97
 - Requirements
 - Altitude 4-3
 - Canadian Standards Association v
 - Electrostatic Discharge vii
 - Environmental 4-3
 - FCC Part 15 iv
 - FCC Part 68 Exhibit J1 iv
 - Industry Canada v
 - Installation 4-3
 - Japan Approvals Institute (JATE) vi
 - National Electrical Code v
 - Network Equipment Building System (NEBS) vi
 - Safety v
 - Underwriters Laboratories v
 - Reserved Network Application Bit 2-10
 - Response Syntax 9-4
 - Restoration Function Codes 9-97
-

Index

-
- RESTORE 8-63
Restore Defaults Command 6-6
Restoring
 Factory Defaults 6-2
 Temporarily saved configuration 6-5
RESULTS 8-66
Retrieve
 Alarms 9-15
 Alarms Response if Alarms are Present 9-15
 Alarms Response if No Alarms are Present 9-15
 Header Command 9-15
 Users 9-14
Return Warranty ix
REVERTIVE 8-67
Revertive Switching Test, DS3 7-41
RF Suppressors 5-10
RFC
 1213 1-8
 1406 1-8
 1407 1-8
RFI Glossary-4
RFI Suppressors
 Part Number 5-5
RJ-45 Ethernet Connector A-9
RJ-45 Ethernet Pinout A-9
RLS-ARC-<LSType> 9-44
RLS-LPBK-<FacilityType> 9-45
RMV-<AIDType> 9-46
RS-232
 CLI Management Port Pinout A-7
 CLI Port 3-5
 Management Cable, Connecting 5-10
 Management Description 2-6
 Port 1-3
 Port Setup 5-10
 TL1 Connector Description 2-6
 TL1 Port 3-5
 TL1 Port Pinout A-8
RST-<AIDType> 9-46
RTRV-<FacilityType> 9-47
RTRV-ALM-<AIDType> 9-51
RTRV-ALM-ENV 9-53
RTRV-AO 9-54
RTRV-ARC-<LSType> 9-55
RTRV-ATTR-<AIDType> 9-56
RTRV-COND-<AIDType> 9-59
RTRV-EQPT 9-61
RTRV-HDR 9-62
RTRV-LOG 9-62
RTRV-NETTYPE 9-63
RTRV-PM-<FacilityType> 9-64
RTRV-PMSCHED-<FacilityType> 9-67
RTRV-STATUS 9-70
RTRV-TH-<FacilityType> 9-71
RTRV-TOD 9-72
RTRV-USER-SECU 9-72
Running Maintenance Tests on a Low-Speed Circuit
 7-29
- S**
Safety
 Precautions vi
 Requirements for Telecommunications Equipment v
 UL1950 1-3
SAVE 8-68
Saved Configuration, Restoring 6-5
Saving Controller Configurations 6-19
SCHED-PMREPT-<FacilityType> 9-74
SCREEN 8-69
SDH Glossary-4
SECURITY 8-69
Security 6-8, 6-11
 Commands 9-7
 Integrity 8-5
 Levels 8-4, 9-8
 Login 6-8, 6-11
Security Alarm Type <secualmtype> 9-97
SECURITY CLI 8-70
SECURITY ETHERNET 8-71
SECURITY RS232CLI 8-71
SECURITY RS232TL1 8-72
SECURITY SNMP 8-73
SECURITY TL1 8-73
SeeDS3 2-15
SEFS Glossary-4
Self-Test
 DS3 Card 7-12
 Low-Speed Card 7-12
 Low-Speed Circuit 7-11
 The Complete 7-14
Self-Test Power-Up Test, Complete 7-14
Self-Tests 2-2, 2-34, 7-11
Send
 CSU Loopback Toward Drop, DS1 7-24
 NIU Loopup Code Toward Drop, DS1 7-25
 NIU Loopup Code Toward Network, DS1 7-26
Service Access 3-7
Service Effect of Alarm or Condition <srveff> 9-98
Session Timeout 9-77
SET-ATTR- 9-75
SET-ATTR-SECUDFLT 9-77
SET-SID 9-78

-
- SET-TH-<FacilityType> 9-79
 - Setting
 - Clock Time 6-7
 - Date 6-7
 - System Date 6-7
 - Time 6-7
 - User Level 6-9, 6-13
 - Setup
 - DS3 Non-Redundant Test 7-32
 - DS3 Test 7-39, 7-42
 - Overview 6-2
 - Severely Errored Framing Seconds Glossary-11
 - SF Glossary-4
 - Shielded Cables, Requirements 5-2
 - Shut-Down, Thermal 7-10
 - Simple Network Management Protocol Glossary-11
 - Size of Wide Bank 28 2-2
 - Slip Glossary-12
 - SNMP 8-74, Glossary-4
 - Community Strings, Default 11-2
 - Configuration 11-2, 11-3
 - Configuration Parameters 11-2
 - IP Address 11-2
 - Subnet Mask 11-2
 - Traps 8-5
 - Traps Supported by Wide Bank 28 DS3 11-6
 - SNMPC 1-8
 - SONET Glossary-4
 - Source Identifier, Setting 9-10
 - Spare Low-Speed Card 1-2
 - SPE Glossary-4
 - Speed (HS) Line Condition LED, High 7-5
 - STA-LOCL-RST 9-80
 - Standard
 - Compliance 1-3, 3-7
 - Maintenance Practice 10-5
 - Standby DS1 interfaces 2-3
 - Standby DS3 Self-Test, Alarm Severity 8-11
 - Static-Sensitive Equipment Handling Procedures 5-3
 - Statistics, DS3 Far-End 7-7
 - STATUS 8-75
 - Status
 - Determining Performance and 7-7
 - Indicators, LED Test and 7-2
 - LED, Controller 7-5
 - LED, Ethernet 7-6
 - LEDs (one per span), Low-Speed DS1/E1 Line 7-6
 - Point-to-Point Protocol 7-8
 - STE Glossary-4
 - STM Glossary-4
 - Stratum Glossary-12
 - STS-1 Glossary-4, Glossary-12
 - STS-N Glossary-12
 - Stuffing Glossary-12
 - Subnet Mask Glossary-12
 - Subnet Mask, SNMP/Telnet 11-2
 - SunNet Manager 1-8
 - Superframe Glossary-12
 - SWITCH 8-78
 - Switch Test, DS3 Manual 7-40
 - Switching Test, DS3 Revertive 7-41
 - SW-TOPROTN-<FacilityType> 9-80
 - SW-TOWKG-<FacilityType> 9-81
 - Synchronous Glossary-12
 - Digital Hierarchy Glossary-12
 - Optical Network Glossary-12
 - Transport Signal level 1 Glossary-12
 - Transport Signal level N Glossary-12
 - Syntran Glossary-4, Glossary-12
 - System
 - Management Ports 1-3
 - Name, SNMP 11-2
 - Parameters 3-2
 - Parameters, Verifying 6-20
- T**
- T1
 - Clocking 1-2
 - Range notation (&&) 9-84
 - T1.102 3-7
 - T1.107 3-7
 - T1.403 3-7
 - T1.404 3-7
 - Target Identifier <tid> and Source Identifier <sid> 9-98
 - Target Identifier, Setting 9-10
 - Telnet Glossary-4, Glossary-12
 - Interface 8-3
 - Sessions 3-5
 - TEMP COPY 8-79
 - Temp Copy Command 6-5
 - Temporarily Saving Configuration 6-5
 - Terminal Multiplexer Glossary-13
 - TEST 8-79
 - Test
 - Complete Self-Test (Power-Up) 7-14
 - DS1/E1 7-12
 - DS3 7-12
 - DS3 Automatic Protection 7-40
 - DS3 Electronics Protection 7-43
 - DS3 Manual Switch 7-40
 - DS3 Network Protection 7-42
 - DS3 Revertive Switching 7-41
-

DS3 Setup	7-39, 7-42	Parameter Descriptions	9-83
DS3, C-bit Framing	7-33	Ranges Using &&	9-4
DS3, M23 Framing	7-33	RS-232 Port Connector Pinout	A-8
FFO Monitoring	7-13	Session	
Setup, DS3 Non-Redundant	7-32	RS-232 TL1 Port	9-10
Status Indicators	2-14	TCP/IP Socket	9-9
Status Indicators, LED	7-2	Terminal-to-Terminal	9-10
Testing		Setup and Configuration	9-9
DS3 Far-End with Loopback Tests	7-37	Shortcuts	9-8
DS3 Framing and Loop Timing	7-32	Testing Alarming	9-16
DS3 Interfaces	7-32	Transmit	
DS3 Near-End with Loopback Tests	7-35	Amplitude	
DS3 Redundancy	7-39	DS1	3-4
Electronics and Network Protection	7-42	DS3	3-3
Electronics Protection	7-39	E1	3-4
Low-Speed Far-End with Loop Tests	7-27	Jitter	
Low-Speed Interface Operation	7-18	DS1	3-4
Low-Speed Near-End with Loop Tests	7-19	DS3	3-3
Network to the Far-End Through a Low-Speed Drop		E1	3-4
.....	7-28	Line Rate, DS3	3-3
TL1 Alarming	9-16	Transport Surveillance Commands	9-7
Tests		Trap	Glossary-13
DS3 Far-End with Loopback	7-37	Authentication Failure	11-6
DS3 Line Timing	7-34	DS1	
DS3 Near-End with Loopback	7-35	Card State	11-8
Low-Speed Circuit, Running Maintenance	7-29	Internal Hardware Failure	11-9
Low-Speed Far-End	7-27	Internal Hardware Failure Clear	11-9
Low-Speed Near-End with Loop	7-19	Internal Hardware Failure Spare	11-9
Thermal Shut-Down	7-10	Internal Hardware Failure Spare Clear	11-9
Threshold Level <thlev>	9-98	Move Home	11-8
Through a Low-Speed Drop, Testing the Network to the		Protect Switch	11-8
Far-End	7-28	DS3 Controller State	11-8
TIME	8-80	Failed CLI Login	11-8
Time <time>	9-99	Link Down	11-7
Time Offset <tmofst>	9-99	Link Up	11-7
Time Period <tmper>	9-99	Power Status	11-8
Time, Setting	6-7	Supported by Wide Bank 28	11-6
Timeout, Session	9-77	Warm Start	11-7
Timing	3-2	Trivial File Transfer Protocol (TFTP)	6-24
DS3 Framing	7-32	TR-NWT-000499	3-7
DS3 Line Tests	7-34	Troubleshooting, General	7-9
TL1	8-81, 9-11	Turning Off Unused Channels	10-11
Alarm Messages	12-4	Type of Request <typereq>	9-99
Alarm Reporting	12-4	U	
Automatic Messages	9-101	UAS	Glossary-4
Command List	9-17	UDP	Glossary-4
Commands and Messages	9-1	UL 60950	v, 3-7
Commands and Response Messages	9-11	UL 1950	v
Description	1-9	Current-Limiting Compliance	5-14
Lists Using &	9-4	Unavailable Seconds	Glossary-13
Overview	9-2		

Underwriters Laboratories	v
Unused Channels	10-11
USER	8-82
User Access Privilege <uap>	9-99
User Datagram Protocol	Glossary-13
User Identifier <uid>	9-100
User Level, Setting	6-9, 6-13
Using the Command Line Interface	8-6
V	
Validate Link	11-4
Validating Equipment	6-6
Verification, Datapath Transmission	2-29
Verifying Autocopy	6-22
VERSION	8-85
Vertical Mounting Bar, Ppart Number	4-2
Violations, Line Code	2-34
Volatile Storage, Configuration	6-5
VT	Glossary-4
W	
Warm Start Trap	11-7
Warning Notice	vi
Warranty	viii
Limitations	viii
Product Returns	ix
Remedies	viii
Wide Bank 28	
Cables	5-7
Overview	1-2
Size of	2-2
Wideband	Glossary-13
Working Configuration	6-6, 6-7
Saving	6-19
WRT-MEM-FILE	9-82
X	
X-bits	
Abnormal States	2-10
Error Messages from Rar-End	2-10
Xmodem	6-24
Z	
Zeros, Excessive	2-34

