

GRACE Vinylwriter Pico
DIGITAL AUDIO



User Guide
GDI-VW00

CONTENTS

| | |
|--|-----------|
| IMPORTANT SAFETY INSTRUCTIONS | 3 |
| PRECAUTIONS | 4 |
| BEFORE USE | 5 |
| TURNTABLE PARTS | 5 |
| LISTENING TO A RECORD | 5 |
| HOW to REPLACE the TURNTABLE STYLUS (NEEDLE) | 6 |
| RECORD YOUR VINYL to PC using WINDOWS SYSTEM | 6 |
| - SOFTWARE INTRODUCTION | 6 |
| - SOFTWARE INSTALLATION and USB CONNECTION | 6 |
| - RECORDING OPERATION STEPS | 11 |
| - CONVERTING RECORDED FILES to .WAV and .MP3 FILE FORMATS | 13 |
| RECORD YOUR VINYL to PC using a MAC SYSTEM | 19 |
| TIPS for BETTER TURNTABLE PERFORMANCE | 21 |
| SPECIFICATIONS | 22 |
| CUSTOMER SERVICE & SUPPORT | 22 |

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed. Please refer below:

1. Read Instructions - All safety and operating instructions should be read before operated.
2. Retain Instructions - Safety and operating instructions should be retained for future reference.
3. Follow Warnings - All warnings on the product and in the manual should be adhered to.
4. Follow Instructions - All operating and user instructions should be followed.
5. Cleaning - Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners instead use a damp cloth for cleaning.
6. Attachments - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
7. Water and Moisture - Avoid exposing the product to water and moisture.
8. Accessories - Securely place this unit before use. The product may fall if not properly placed causing serious injury to child or adult and may damage the product. Use only with a stand, bracket, or table recommended by the manufacturer. If the product needs to be mounted, you should follow the manufacturer's instructions and should use a mounting accessory recommended by them.
9. Transporting - This product should be moved with care to avoid damage or injury.
10. Ventilation - Slots and openings in the cabinet are provided for ventilation. This is to ensure reliable operation of the product and to protect it from overheating. Openings must not be blocked or covered. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
11. Power Sources - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the instruction manual.
12. Power-Cord Protection - Power-supply cords should be properly secured so that they are not likely to be entangled in any way.
13. Lightning - For added protection for this product during a lightning storm, or when it is left unattended for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
14. Overloading - Do not overload wall outlets and extension cords, as this can result in a risk of fire or electric shock.
15. Object and Liquid Entry - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock.
16. Servicing - Do not attempt to repair this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
17. Damage Requiring Service - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a. If the power-supply cord or plug is damaged.
 - b. If liquid or objects have fallen into the product.
 - c. If the product has been exposed to rain or water.
 - d. If the product does not operate and you have followed the manual for troubleshooting.
 - e. If the product has been dropped or damaged in any way, and the product exhibits a distinct change in performance may indicate a need for service and/or repair.
18. Replacement Parts - If a part needs to be replaced, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
19. Safety Check - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
20. Wall or Ceiling Mounting-The product should be mounted to a wall or ceiling only as



recommended by the manufacturer.

21. Heat-The product should be situated away from heat sources such as radiators, heat registers, stoves or other products (including amplifiers) that produce heat.

PRECAUTIONS

1. In order to shut off the unit completely, unplug the power cord from the wall outlet, be sure to unplug the unit if you do not intend to use it for a long period of time.
2. Incorrect use of controls, adjustments and performance other than those specified herein may result in hazardous radiation exposure.
3. Should this product malfunction, discontinue use and contact a qualified service center.

| | |
|--|---|
| WARNING | |
| To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture. | |
| CAUTION | |
| RISKS OF ELECTRIC SHOCK- DO NOT OPEN! | |
| To reduce the risk of electric shock, do not remove casing. No user serviceable parts inside. Refer servicing to qualified service personnel. | |
|  | The light flash with arrowhead symbol, within an equilateral triangle, is intended to alert User to the presence of “dangerous voltage” which may be of sufficient magnitude to cause electric shock to persons. |
| The User to the presence literature |  exclamation point inside an equilateral triangle is intended to alert of important operating and maintenance (servicing) instructions in the that may accompany the appliance. |
| This product may contain chemicals listed in Proposition 65 (http://www.oehha.ca.gov/prop65/prop65_list/Newlist.html) That may be known to cause cancer, birth defects or other reproductive harm | |

CAUTION: To prevent shock, match wide blade of plug to wide slot, fully inserted

BEFORE USE

1. Choose a safe location and avoid placing the unit in direct sunlight or near any heat source.
2. Avoid locations subject to vibrations, excessive dust, cold or moisture.
3. Do not open the cabinet as this may result in electrical shock. If a foreign object is inserted accidentally contact your dealer.
4. When removing the power plug from the wall outlet, pull directly on the plug, NOT the cord.
5. Do not attempt to clean the unit with chemical solvents as this might damage the finishing. A clean, dry cloth is recommended for cleaning.
6. In order to completely turn off the unit, unplug the power cord from the wall outlet.
7. Keep this manual for future reference.

TURNTABLE PARTS

1. Dust Cover
2. Platter
3. 45 rpm Adapter
4. Tone Arm
5. Lift Lever
6. Speed Selection
7. Auto Stop Control
8. Tone Arm Rest
9. USB Jack
10. RCA Output

11. AC Power Cord
12. Turntable Feet
13. Style (Needle) Cartridge

LISTENING to a RECORD

1. Raise the dust cover _
2. Connect the AC power cord 11 to an electrical outlet (120V~60Hz)
3. Use a RCA cable to connect unit's RCA output 10 with your powered speaker. Make sure the red RCA and white cables are inserted in the red and white jacks accordingly.
4. Place a record on the turntable and select the player speed (33/45/78) 6 according to the desired record speed. NOTE: when playing a 45 rpm record, use the 45 rpm adapter _.
5. Remove the tone arm from the rest 8, push Lift Lever backward 5 to raise the tone arm and gently move the tone arm to the desired position over the record. The turntable will begin to spin when the arm is moved toward the record. Push the Lift Lever 5 forward lower the tone arm slowly onto the desired position on the record to begin playing the record.
6. If Auto Stop Control 7 is turned ON, record will stop automatically when finished.
If Auto Stop Control 7 is turned OFF, record will NOT stop automatically when finished.
7. For best performance and product maintenance, unplug the Turntable when not in use.

HOW to REPLACE the TURNTABLE STYLUS (NEEDLE)

To replace the turntable stylus (needle), please refer on the instructions below:

REMOVING the STYLUS from the CARTRIDGE

1. Place a screwdriver at the tip of the stylus and push downward as shown in direction "A".
2. Remove the stylus by pulling the stylus forward and pushing downward.

INSTALLING the STYLUS (NEEDLE)

1. Hold the tip of the stylus and insert the stylus by pressing as shown in direction "B".
2. Push the stylus upward as in direction "C" until the stylus locks into the tip position.



RECORD



YOUR

VINYL TO PC in WINDOWS SYSTEM

SOFTWARE INTRODUCTION

Audacity application software is included with your Vinylwriter and is designed to record and save music from the photograph to a computer. The software then allows for the same recorded files to be converted and edited to .WAV and/or .MP3 file formats. The recorded music can then be played using Windows Media Player and other applications that support .WAV and .MP3

formats.

SOFTWARE INSTALLATION and USB CONNECTION


To install the Audacity software in your computer, please follow the instructions below.

1. Insert the Audacity software (included) into your computer's disc tray.



The Audacity Setup Wizard will appear. Click on "Next" to install the software.




2. Select "I accept the agreement" and click on Next





3. Continue to click on the "Next" button until the software installation begins.





4. Click on the "Install" button to start the Audacity software installation.






5. Click on "Finish" to complete installation.




6. You can now open the Audacity software and start recording your files.




RECORDING OPERATION STEPS

1. Connect the USB cable to your turntable and your computer. No extra driver is required to drive the USB.
2. Power and play your record by lifting the tone arm towards the platter.
3. Double click the Audacity program and you will see this interface screen on your computer.



4. Adjust the output and input volume.



5. Select the RECORD button  to start recording.




6. Select the  to skip to start.

7. Select the  button to go to end.

8. Select the PAUSE  button to pause the recording.

9. Select the STOP  button to stop the recording.

10. You can see the recorded file on your computer and convert the recorded file to other formats including .WAV and MP3.



11. Play the saved file.




Put the saved file in the Audacity program and press the PLAY button to play the file.

CONVERTING RECORDED FILES to .WAV and .MP3 FILE FORMATS


Please make sure that you have properly connected the Vinylwriter USB to your computer and follow the instructions below to convert your files to “.wav and .mp3” file formats

1. Make sure that the Audacity installation disc is still inserted in your computer. Go to your Desktop and double click on the "My Computer" icon.
2. Locate the CD ROM Drive and double click on the icon.
3. Copy the lame_enc.dll file and paste it to your Desktop.





4. After copying the file, open the Audacity Software. Click on the "RECORD" Button to start the recording process. Make sure that a vinyl record is playing on the turntable and the USB cable is connected to the turntable and your computer.


5. You may press the Stop Button at any desired time. Once you have the recorded file that will be converted, press the "Edit" tab and select "Preferences"




6. Locate "File Format" tab and click on the "Find Library" button




7. Click "Yes" button, then go to your Desktop and highlight the lame_enc.dll. Next, click on the "Open" button.




8. Click on the "OK" button and return to the default window of the Audacity Software.




9. Click on the "File" tab and the option will be given to export the recorded file as ".wav", ".mp3" or ".ogg" file formats.




10. Once you have selected the desired file format to export your recorded music, enter the file name and location where you want to save the file on your computer. Once finished, click on the "Save" button.



11. Enter the title, artist and any other information about the MP3 file that you have created and click on the "OK" button.



12. Next, go to the location of the file you have converted. You can play the converted file on any application that supports .WAV or MP3 formats.



NOTE: Converted files can be transferred (burned) to a CD. Please refer to the manufacturer's instructions provided with your CD burner or computer for additional details.


RECORD YOUR VINYL to PC using a MAC

1. Plug your Vinylwriter's power cord into a power outlet.
2. Connect your Vinylwriter to your MAC using the supplied USB cable.
3. Press the power button on your Vinylwriter.


4. Open “System Preferences” on your MAC: Applications > System Preferences
5. Under ‘Hardware’ click on ‘Sound’ (icon of speaker)




6. Select ‘Input’ and choose the AK5371 USB device.




7. Close the System Preferences window.
8. Ensure the Audacity Software has been downloaded and installed to your computer. Audacity can be downloaded here: <http://audacity.sourceforge.net/download/mac>
9. Launch Audacity Software from the saved location (commonly saved under ‘Applications’)
10. Open Preferences for the Audacity Software under the Audacity Menu.




11. Refer to the ‘Audio I/O tab’ and under ‘Recording’ select AK5371 and press ‘OK’.



12. Press the RECORD button in the Audacity Software (NOTE: recordings will begin as soon as you release the RECORDING button). Position the needle on your vinyl record where you would like the recording to begin.



13. Press the STOP button when you would like the recording to end.



14. You can edit your recorded track(s) using the Audacity features.

15. You can save your recordings as various file types under the File Menu.

TIPS for BETTER TURNTABLE PERFORMANCE

1. When opening or closing the turntable cover, handle it gently, moving it either at the center or equally from both sides.
2. Do not touch the stylus (needle) tip with your fingers; avoid bumping the stylus on the

- turntable or record's edge
3. Clean the stylus tip frequently - use a soft brush in a 'back-to-front' motion only.
 4. If you must use a stylus cleaning fluid, use very sparingly.
 5. Wipe the dust cover and turntable housing gently with a soft cloth. Use only a small amount of mild detergent solution to clean the turntable and dust cover.
 6. Never apply harsh chemicals or solvents to any part of the turntable system.
 7. Always unplug the unit from the AC outlet and secure the tone arm before moving



SPECIFICATIONS:

| | |
|-----------------------------|---|
| Power Requirements: | AC 120V~50Hz |
| Power Consumption: | 8W |
| Motor: | EG-530SD-3F |
| Drive System: | Belt |
| Speeds: | 33-1/3, 45, 78 rpm |
| S/N Ratio: | 35 dB |
| Tone Arm: | Straight Plastic & Aluminum |
| Cartridge/ Stylus (Needle): | Ceramic Stereo/ Jewel Stylus |
| Base & Platter: | MDF Cabinet Base, Plastic Core & Platter |
| Dimensions (LxDxH): | 10.7 x 13.1 x 4.0 inches (approx.) |
| Weight: | 4.5 lbs (approx.) |
| Accessories: | User Guide, 45rpm Adapter, USB & RCA Cords, Audacity Software |

CUSTOMER SERVICE & SUPPORT

Should you have any questions regarding your Vinylwriter please visit us at www.gracedigitalaudio.com or send us an email to info@gracedigital.net or call Toll-Free 866-446-0961

Our Customer Service hours are scheduled for Monday to Friday 8:30AM to 5:00PM Pacific Standard Time

Thank you for your purchase with Grace Digital Audio. All Grace Digital Audio products purchased in the United States of America are supported by a conditional warranty.

WARRANTY

This item is guaranteed by Grace Digital Inc. for a period of 1 year from the original date of purchase.

This guarantee covers the replacement of equipment that proves to be faulty as a result of manufacturing faults only. No liability can be accepted for faults arising from accident or misuse.

In the event your equipment requires warranty attention and/or service, please contact Grace Digital Inc. at [866] 446 - 0961 or at their website www.gracedigitalaudio.com.

In the event a replacement is required and there is a shortage of stock, Grace Digital Inc. reserves the right to replace faulty items with similar equipment of equivalent value.

CONDITIONS

1. This Warranty will be granted when the original invoice or sales receipt (with proof of date of purchase, product type and dealer's name) is presented together with the defective product.
2. This guarantee will not reimburse nor cover the damage resulting from adaptations or adjustments which may be made to the product.
3. This guarantee will not include any or some of the following:
 - i. Maintenance and/or repair of parts due to normal wear and tear.
 - ii. Changes to the product from its normal purpose as described in the instruction manual.
 - iii. Transportation costs, home service costs and all related risks and costs of transport.
4. Damage resulting from any of the following:
 - i. Misuse including using for a purpose other than intended, installation or use of the product in a manner inconsistent with the technical or safety standards, improper or incorrect installation.
 - ii. Repair done by non-authorized establishment or individual.
 - iii. Accidents including lightning, water, fire, improper ventilation or any cause beyond the control of Grace Digital Inc.

Grace Digital Inc. is an exclusive distributor of Grace Digital Audio Products; San Diego, CA

Grace Digital Audio
San Diego, CA 92129

